

TIME TABLE

CLASS

WESTWARD

SECOND CLASS

**The**  
**Denver and Rio Grande Western Railroad**  
**Company**

**GRAND JUNCTION**  
**DIVISION**

**TIME-TABLE**  
**No. 110**

**Takes Effect Sunday, June 16, 1935**

**at 12:01 A. M.**

**Standard Time, 105th Meridian**

**Superseding Time-Table No. 109**

**NOTE IMPORTANT CHANGES IN**  
**TIME-TABLE RULES**

**For the exclusive guidance of Employees; not for**  
**the information of the Public**

**The Management reserves the right to vary**  
**from it at pleasure**

**A. C. SHIELDS**  
**Vice President and**  
**General Manager**

**L. F. WILSON**  
**Assistant General Manager**

**R. K. BRADFORD**  
**Superintendent Transportation**

**W. R. McPHERSON**  
**Superintendent**

**R. L. Brown**  
**Assistant Superintendent**  
**Sub-Divisions 3, 3-A, 3-B, 4, 4-A and 4-B**  
**Salida**

**Walter Allen**  
**Trainmaster**  
**Sub-Divisions 5, 5-A, 16 and 16-A**  
**Grand Junction**

**V. H. McGinnis**  
**Road Foreman of Equipment**  
**Grand Junction**

**C. J. Graff**  
**Chief Dispatcher**  
**Grand Junction**

(Signed) W. R. McPHERSON  
 W. R. McPHERSON

(Signed) W. K. BRADFORD  
 W. K. BRADFORD

# WESTWARD

# MAIN LINE

SECOND CLASS			FIRST CLASS					
61 California Fast Freight			1 Scenic Limited			15 Passenger		
Leave Daily			Leave Daily			Leave Daily		
		6 15 PM			2 28 PM			2 45 AM
		6 27			2 35			2 52
		6 35			2 40			2 57
		6 49			2 49			3 06
		6 59			2 57	s		3 15
		7 06			3 02			3 20
		7 15			s 3 12	s		3 30
		7 25			3 19			3 37
		7 31			3 24	f		3 42
		7 42			3 33	f		3 50
		7 58 <sup>38</sup>			3 42	s		3 59
		8 05			3 46			4 04
		8 12			3 51	f		4 10
		8 20			3 56	f		4 15
		8 40			s 4 10	s		4 27
		8 48			4 16			5 12
		9 11 <sup>10</sup>			4 23			5 20
		9 45 PM			s 4 39 PM	s		5 33 AM

Trains operated by Signal Indication between Tennessee Pass and Deen.

		10 10 PM			4 56 PM			5 50 AM
		10 17			5 01	s		5 55
		10 39			5 16	s		6 10
		10 47			5 22	s		6 18
		10 55			5 27	f		6 25
		11 50 PM			5 40 PM	f		6 38 AM
Arrive Daily			Arrive Daily			Arrive Daily		
		5.35 15.6			3.12 27.2			3.08 26.9

Sub-Division 3  
STATIONS  
TIME-TABLE No. 110  
JUNE 16, 1935

s	SALIDA	3.3	JA	WOTRN	21
	BELLEVIEW	3.8			21
	BROWN CANON	5.5			22
	ARENA	5.1			22
	NATHROP	3.4			23
	MIDWAY	4.1			23
BY	BUENA VISTA	4.4		WDN	24
	AMERICUS	3.0			24
	RIVERSIDE	4.3			24
	PRINCETON	5.3			25
	YALE	2.5			25
	HARVARD	3.5			25
	KOBE	3.2			26
	SNOWDEN	4.5			26
MY	MALTA	2.5		JWCTDN	27
	LEADVILLE JCT.	3.5			27
	KEELDAR	3.9			27
FR	TENNESSEE PASS	1.0		WYN	28
	EAST MITCHELL	2.6			28
	WEST MITCHELL	2.2			28
	DEEN	1.7			28
	PANDO	5.5		WY	28
NO	RED CLIFF	2.1		D	28
	BELDEN	1.9			28
	REX	4.0			28
ND	MINTURN	4.0		WOTRN	28

(85.9)

Schedule Time  
Average Speed per Hour

Nos. 15 and 16 between Malta and Leadville Jct. operate via Sub-Division 3-A.

3.3  
1.5  
4.8  
3.1

# MAIN LINE

# EASTWARD

Capacity of Siding	Miles from Minturn	Sub-Division 3		FIRST CLASS				SECOND CLASS			
		STATIONS		2	16			36	38		
		TIME-TABLE No. 110		Seems Limited	Passenger			Fast Freight	Fast Freight		
		JUNE 16, 1935		Arrive Daily	Arrive Daily			Arrive Daily	Arrive Daily		
Yard	86.9	s	SALIDA 3.3	2 00 PM	11 55 PM			12 30 PM	9 30 PM		
100	83.6		BELLEVUE 3.8	1 50	11 45			12 15	9 15		
100	79.8		BROWN CANON 5.5	1 45	11 39			12 08 PM	9 08		
101	74.3		ARENA 6.1	1 36	11 30			11 54	8 54		
100	69.2		NATHROP 3.4	1 29	11 21			11 44	8 44		
100	65.8		MIDWAY 4.1	1 24	11 13			11 38	8 38		
88	61.7	BY	BUENA VISTA 4.4	s 1 19	s 11 06			11 30	8 30		
100	57.3		AMERICUS 8.0	1 12	10 57			11 22	8 22		
100	54.3		RIVERSIDE 4.3	1 08	10 51			11 16	8 16		
126	50.0		PRINCETON 5.3	1 02	10 44			11 08	8 08		
123	44.7		YALE 2.5	12 55	10 34			10 58	7 58 61		
108	42.2		HARVARD 3.5	12 51	10 28			10 53	7 53		
100	38.7		KOBE 3.2	12 46	10 22			10 46	7 46		
100	35.5		SNOWDEN 4.5	12 42	10 16			10 30	7 30		
Yard	31.0	MY	MALTA 2.5	s 12 35	s 10 08			10 22	7 22		
	28.5		LEADVILLE JCT. 3.6	12 26	9 22			10 16	7 16		
100	24.9		KEELDAR 3.9	12 21	9 11 61			10 08	7 08		
1-100 2-103	21.0	FS	TENNESSEE PASS 1.0	s 12 15 PM	s 9 05 PM			10 00 AM	7 00 PM		
	20.0	EAST MITCHELL 2.6		Trains operated by Signal Indication between Deen and Tennessee Pass.							
	17.4	WEST MITCHELL 2.2									
	15.2	DEEN 1.7		11 54 AM	8 30 PM			9 24 AM	6 24 PM		
100	13.5		PANDO 5.5	11 50	8 14			9 18	6 18		
	8.0	NO	RED CLIFF 2.1	11 33	8 03			8 58	5 58		
	5.9		BELDEN 1.9	11 28	7 53			8 50	5 50		
	4.0		REX 4.0	11 24	7 47			8 44	5 44		
Yard		RD S	MINTURN 3.7	11 15 AM	7 35 PM			8 30 AM	5 30 PM		
			(86.9)	Leave Daily	Leave Daily			Leave Daily	Leave Daily		
			Schedule Time	2.45	3.24			4.00	4.00		
			Average Speed per Hour	31.6	23.7			31.7	21.7		

Nos. 15 and 16 between Malta and Leadville Jct. operate via Sub-Division 3-A.

## WESTWARD

## LEADVILLE BRANCH

## EASTWARD

FIRST CLASS				Miles from Denver	Sub-Division 3-A			Miles from Leadville Jct.	Capacity of Siding	FIRST CLASS			
15					STATIONS					16			
Passenger					TIME-TABLE No. 110					Passenger			
Leave Daily				JUNE 16, 1935			Arrive Daily						
			4 27 AM	271.0	MY	MALTA 2.3	8.1	Yard	10 08 PM				
			f 4 35	273.3		EILERS 2.5	5.8	Yard	f 9 58				
			s 5 00	275.8	Q	LEADVILLE 3.3	3.3	Yard	s 9 50				
			5 12 AM	279.1		LEADVILLE JCT. 8.1			9 22 PM				
			Arrive Daily			Schedule Time			Leave Daily				
			0.45			Average Speed per Hour			0.46				
			10.8						10.6				

# WESTWARD

# MAIN LINE

## SECOND CLASS

## FIRST CLASS

Sub-Division 4

STATIONS  
TIME-TABLE No. 110

JUNE 16, 1935

Miles from Denver  
Capacity of Sidings

SECOND CLASS			FIRST CLASS				
	77 California Fast Freight	75 California Fast Freight	61 California Fast Freight		5 The Panoramic	1 Sonic Limited	15 Passenger
	Leave Daily	Leave Daily	Leave Daily		Leave Daily	Leave Daily	Leave Daily
			12 10 AM			5 45 PM	6 58 <sup>34</sup> AM
			12 22			5 55	7 09
			12 35			6 05	7 18
			12 44			6 13	7 25
			12 49			6 17 <sup>16</sup>	7 29
			12 54			6 21	7 32
			1 04			6 29	7 43
			1 16			6 38	7 54
			1 24			6 44	8 00
	4 45 PM	4 45 <sup>AM</sup> 40	1 29		x 9 32 PM	6 47	8 06
	5 00	5 01 <sup>34</sup>	1 43		9 41	6 56	8 21 <sup>6</sup>
	5 15 <sup>16</sup>	5 09	1 51		9 46	7 01	8 27
	5 30	5 22	2 04		9 54	7 09	8 36
	5 45	5 37	2 20		10 04	7 25	8 50
	5 50	5 40	2 23		10 06	7 27	8 52
	6 05	5 55	2 38		10 15	7 37	9 09 <sup>2</sup>
	6 13	6 03	2 46		10 20	7 42	9 16
	6 25	6 17	2 58		10 29	7 52	9 27
	6 32	6 24	3 09 <sup>40</sup>		10 34	7 57	9 32
	6 38	6 30	3 15		10 38	8 08	9 44
	6 47	6 40	3 24 <sup>34</sup>		10 44	8 14	9 51
	6 56	6 49	3 33		10 49	8 20	9 57
	7 05	7 06 <sup>6</sup>	3 42		10 54	8 25	10 03
	7 14	7 15	3 51		10 59	8 31	10 12
	7 23	7 24	4 00		11 05	8 37	10 19
	7 32	7 33	4 09		11 11	8 43	10 26
	7 41	7 41	4 18		11 17	8 49	10 34
	7 49	7 55 <sup>2</sup>	4 26		11 22	8 55	10 41
	7 55	8 01	4 32		11 26	8 59	10 47
	8 05	8 09	4 40		11 33	9 05	10 55
	8 16	8 19	4 50		11 39	9 12	11 03 <sup>42</sup>
	8 26	8 28	5 00		11 45	9 18	11 14 <sup>36</sup>
	8 38	8 38	5 12		11 51	9 25	11 26
	8 43	8 43	5 17		11 54	9 28	11 30
	9 15 PM	9 00 AM	6 00 <sup>6</sup> AM		12 02 AM	9 45 PM	11 45 AM
	Arrive Daily	Arrive Daily	Arrive Daily		Arrive Daily	Arrive Daily	Arrive Daily
	4.30 23.9	4.15 25.3	5.50 25.3		2.30 43.1	4.00 36.9	4.47 30.9

Stn	Name	Miles from Denver	Capacity of Sidings
hd	MINTURN *BWCNT†	302.0	Yar
	5.9		
an	AVON D	307.9	10'
	6.4		
	WILMOR W	314.3	10'
	4.8		
ku	WOLCOTT D	319.1	10'
	2.2		
	KENT	321.3	24'
	2.3		
	ORTEGA	323.6	101'
	5.4		
ox	EAGLE WDN	329.0	88'
	6.8		
op	GYPSUM D	335.8	100'
	4.1		
	LUKE	339.9	90'
	2.0		
dy	DOTSERO JYDN	341.9	150'
	5.8		
	ALLEN	347.7	90'
	2.8		
	SHOSHONE W	350.5	86'
	4.7		
	GRIZZLY	355.2	111'
	4.9		
gn	GLENWOOD JB†NW	360.1	40'
	0.7		
	FUNSTON *WTC†	360.8	Yarc
	7.4		
	CHACRA	368.2	100'
	4.5		
no	NEWCASTLE DW	372.7	89'
	6.8		
sl	SILT D	379.5	90'
	3.9		
	IVES	383.4	62'
	3.2		
rl	RIFLE YWN	386.6	90'
	4.8		
	LACY	391.4	90'
	3.9		
	MORRIS	395.3	76'
	4.2		
	DCS	399.5	90'
	4.5		
gv	GRAND VALLEY WD	404.0	90'
	4.8		
	UNA	408.8	90'
	4.2		
	NIGER	413.0	40'
	3.6		
de	DE BROUE D	416.6	95'
	4.1		
	GRAVEL	420.7	83'
	2.9		
	AKIN	423.6	71'
	4.1		
	TUNNEL	427.7	103'
	4.9		
	CAMEO	432.6	96'
	4.4		
rd	PALISADE WD	437.0	90'
	5.5		
fn	CLIFTON D	442.5	90'
	2.8		
	FRUITVALE	445.3	
	4.3		
jd	GRAND JCT.†*BWCNT††	449.6	Yard

AUTOMATIC BLOCK SIGNALS

(147.6)

Schedule Time  
Average Speed per Hour

See Special Time-Table Rule 35, page 14, covering signals, spring switches and operations at Dotsero.

213

# MAIN LINE

# EASTWARD

Miles from Grand Junction	Sub-Division 4		FIRST CLASS				SECOND CLASS			
	STATIONS		6	2	16		40	34	42	36
	TIME-TABLE No. 110		The Panoramic	Scenic Limited	Passenger		Fast Freight	Fast Freight	Fast Freight	Fast Freight
	JUNE 16, 1935		Arrive Daily	Arrive Daily	Arrive Daily		Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily
147.6	nd	MINTURN 5.9 *BWOCTN†		11 10 AM	7 15 PM					
141.7	an	AVON 6.4 D		10 53	6 56		6 58 <sup>15</sup> AM		4 15 PM	
135.3		WILMOR 4.8 W		10 40	6 38		6 38		3 58	
130.5	su	WOLCOTT 2.2 D		10 31	6 25		6 22		3 42	
128.3		KENT 2.3		10 27	6 17 1		6 10		3 30	
126.0		ORTEGA 5.4		10 23	6 09		6 05		3 25	
120.6	ox	EAGLE 6.8 WDN		10 15	5 59		6 00		3 20	
118.8	gp	GYPSUM 4.1 D		10 04	5 44		5 48		3 08	
109.7		LUKE 2.0		9 58	5 34		5 28		2 48	
107.7	dy	DOTSERO 6.8 JYDN	x 8 30 AM	9 55	5 31		5 20		2 40	
101.9		ALLEN 2.8	8 21 15	9 46	5 21		4 45 <sup>75</sup> AM	5 15	2 15 PM	
99.1		SHOSHONE 4.7 W	8 16	9 41	5 15 77		4 31	5 01 75	2 01	
94.4		GRIZZLY 4.0	8 08	9 33	5 07		4 23	4 53	1 53	
89.5	on	GLENWOOD 0.7 JB†NW	8 7 59	9 24	4 58		4 10	4 40	1 40	
88.8		FUNSTON 7.4 *WTCY	7 55	9 19	4 47		3 55	4 25	1 25	
81.4		CHACRA 4.5	7 46	9 09 15	4 35		3 53	4 23	1 23	
76.9	no	NEWCASTLE 6.8 DW	7 41	9 04	4 28		3 36	4 06	1 06	
70.1	sl	SILT 3.9 D	7 32	8 55	4 15		3 28	3 58	12 58	
66.2		IVES 3.2	7 27	8 50	4 07		3 16	3 46	12 46	
63.0	nf	RIFLE 4.8 YWN	x 7 23	8 45	4 02		3 09 61	3 39	12 39	
58.2		LACY 3.9	7 16	8 36	3 51		3 03	3 33	12 33	
54.3		MORRIS 4.2	7 11	8 31	3 44		2 54	3 24 61	12 24	
50.1		DOS 4.5	7 06 75	8 26	3 38		2 45	3 15	12 15	
45.6	gv	GRAND VALLEY 4.8 WD	7 01	8 21	3 32		2 37	3 07	12 07 PM	
40.8		UNA 4.2	6 55	8 15	3 21		2 29	2 59	11 59	
36.6		NIGER 3.6	6 49	8 08	3 13		2 20	2 50	11 50	
33.0	de	DE BEQUE 4.1 D	6 43	8 02	3 06		2 12	2 42	11 42	
28.9		GRAVEL 2.9	6 38	7 55 75	2 57		2 05	2 35	11 35	
26.0		AKIN 4.1	6 34	7 50	2 51		1 57	2 27	11 27	
21.9		TUNNEL 4.9	6 28	7 44	2 43		1 51	2 21	11 21	
17.0		CAMEO 4.4	6 21	7 37	2 35		1 43	2 13	11 13	
12.6	rd	PALISADE 5.5 WD	6 15	7 31	2 27		1 33	2 03	11 03 15	
7.1	fn	CLIFTON 2.8 D	6 09	7 25	2 15		1 24	1 54	10 49	
4.3		FRUITVALE 4.3	6 06	7 22	2 07		1 13	1 43	10 38	
	jn	GRAND JCT. *BWOCTN†	6 00 61 AM	7 15 AM	2 00 PM		1 08	1 38	10 33	
		(147.6)	Leave Daily	Leave Daily	Leave Daily		1 00 AM	1 30 AM	10 25 AM	
		Schedule Time	2.30	3.55	5.15		Leave Daily	Leave Daily	Leave Daily	
		Average Speed per Hour	43.1	37.7	28.1		3.45 28.7	5.28 27.0	3.50 28.1	
							5.30 26.8			

See Special Time-Table Rule 35, page 14, covering signals, spring switches and operations at Dotsero.

# WESTWARD

# MAIN LINE

## SECOND CLASS

## FIRST CLASS

	77	75	61				1	5
	California Fast Freight	California Fast Freight	California Fast Freight				Scenic Limited	The Panorama
	Leave Daily	Leave Daily	Leave Daily				Leave Daily	Leave Daily
	10 00 PM	9 30 AM	6 30 AM				9 55 PM	12 10 AM
	10 05	9 35	6 35				f 9 59	12 13
	10 10	9 39	6 39				f 10 02	12 16
	10 15	9 43	6 50 <sup>2</sup>				f 10 05	12 19
	10 21	9 49	6 56				s 10 12	12 23
	10 30	9 56	7 04				s 10 20	12 28
	10 36	10 01	7 09				s 10 27	12 32
	10 43	10 08	7 16				f 10 33	12 37
	10 51	10 15	7 23				f 10 39	12 43
	11 02	10 23	7 31				10 46	12 49
	11 12	10 31	7 38				s 10 54	12 55
	11 30	10 44	7 51 <sup>34</sup>				f 11 03	1 03 <sup>38</sup>
	11 42	10 52	8 01				f 11 10	1 10
	11 55	11 00	8 11				f 11 19	1 17
	12 21 <sup>AM 38</sup>	11 17	8 35				f 11 30	1 26
	12 32	11 26	8 45				f 11 35	1 31
	12 45	11 38	9 00				f 11 41	1 36
	1 05	11 52	9 20				f 11 48	1 43
	1 15	12 01 PM	9 30				s 11 56 <sup>38</sup>	1 47
	1 26	12 11	9 42				f 12 03 AM	1 54
	1 37	12 22	9 56				f 12 11	2 02
	1 47	12 32	10 10				f 12 18	2 09
	1 55	12 40	10 20				12 23	2 14
	2 26 <sup>5</sup>	1 00	10 50				s 12 36	2 26 <sup>77</sup>
	2 50	1 14	11 10				f 12 45	2 35
	3 18 <sup>6</sup>	1 26	11 25				f 12 55	2 44
	3 40	1 45 <sup>36</sup>	11 45				f 1 05	2 53
	3 59 <sup>2</sup>	1 54	11 59				f 1 13	3 03 <sup>6</sup>
	4 27 <sup>34</sup>	2 08	12 18 PM				f 1 23	3 11
	4 45	2 28	12 42				f 1 34	3 20
	4 56	2 43	1 03 <sup>36</sup>				f 1 41	3 27
	5 06	2 55	1 15				f 1 48	3 32 <sup>2</sup>
	5 14	3 06	1 28				f 1 55	3 39
	5 22	3 15	1 40				f 2 02	3 45 <sup>34</sup>
	5 31	3 26	1 53				s 2 16 <sup>6</sup>	3 52
	5 37	3 32	1 59				2 23	3 55
	6 00 AM	4 00 PM	2 30 PM				2 40 <sup>AM 2</sup>	4 05 AM
	Arrive Daily	Arrive Daily	Arrive Daily				Arrive Daily	Arrive Daily
	8.00 22.1	6.30 27.2	8.00 22.1				4.45 37.2	3.55 45.2

## Sub-Division 5

## STATIONS

### TIME-TABLE No. 110

JUNE 16, 1935

		Miles from Denver	Capacity of Siding
JA	GRAND JCT. J*nb cwt y	449.6	Yar.
	2.4		
	DURHAM	452.0	54
	2.5		
	RACEY	454.5	69
	2.4		
	RHONE	456.9	90
	3.6		
R	FRUITA	460.5	81
	5.1		
	LOMA	465.6	71
	3.3		
MO	MACK	468.9	100
	4.2		
	RUBY	473.1	169
	4.9		
	SHALE	478.0	102
	5.4		
	UTALINE	483.4	108
	5.0		
	WESTWATER	488.4	116
	4.8		
	COTTONWOOD	493.2	51
	5.7		
	AGATE	498.9	77
	5.5		
CS	CISCO	504.4	90
	7.6		
	WHITE HOUSE	512.0	90
	3.9		
	ELBA	516.9	54
	4.2		
	SAGERS	520.1	81
	5.2		
	VISTA	525.3	77
	2.8		
HN	THOMPSON	528.1	90
	6.1		
	BRENDEL	534.2	100
	6.7		
	FLOY	540.9	78
	6.0		
	SOLITUDE	546.9	100
	4.5		
	DALY	551.4	100
	3.8		
GR	GREEN RIVER	555.2	Yar.
	6.1		
	SPHINX	561.3	101
	6.7		
	DESERT	568.0	90
	6.7		
	CLIFF	574.7	101
	5.9		
WD	WOODSIDE	580.6	91
	6.3		
	GRASSY	586.9	101
	6.6		
	CEDAR	593.5	87
	5.9		
	VERDE	599.4	101
	3.8		
MU	MOUNDS	603.2	91
	5.5		
	FARNHAM	608.7	88
	4.8		
	WELLINGTON	613.5	111
	5.6		
OV	PRICE	619.1	70
	2.7		
	MAXWELL	621.8	84
	4.7		
BA	HELPER	626.5	Yar.
	*nb cwt y		

AUTOMATIC BLOCK SIGNALS

(176.9)

Schedule Time  
Average Speed per Hour

# MAIN LINE

# EASTWARD

Miles from Elmer	Sub-Division 5		FIRST CLASS				SECOND CLASS		
	STATIONS		6	2			34	36	38
	TIME-TABLE No. 110		The Panoramic	Boemie Limited			Fast Freight	Fast Freight	Fast Freight
JUNE 16, 1935		Arrive Daily	Arrive Daily			Arrive Daily	Arrive Daily	Arrive Daily	
176.9	JN	GRAND JCT. *NS OWT	5 52 AM	7 05 AM			9 00 AM	6 00 PM	2 10 AM
174.5		DURHAM 2.4	5 45	f 6 56			8 52	5 52	2 04
172.0		RACEY 2.5	5 42	f 6 53			8 48	5 48	2 00
169.6		RHONE 2.4	5 39	f 6 50 61			8 44	5 44	1 56
166.0	R	FRUITA 2.6 DW	5 35	s 6 45			8 39	5 39	1 51
160.9		LOMA 2.1	5 29	s 6 37			8 32	5 32	1 44
157.6	Mc	MACK 2.3 DN	5 25	s 6 31			8 27	5 27	1 39
153.4		RUBY 4.2	5 20	f 6 24			8 21	5 21	1 33
148.8		SHALE 4.9	5 14	f 6 18			8 14	5 14	1 26
143.1		UTALINE 5.4	5 08	6 12			8 06	5 06	1 18
138.1		WESTWATER 5.0 W	5 02	s 6 06			7 59	4 59	1 11
133.3		COTTONWOOD 4.8	4 55	f 5 58			7 51 61	4 51	1 03 5
127.6		AGATE 5.7	4 48	f 5 50			7 39	4 39	12 42
122.1	CS	CISCO 5.5 DNWT	4 41	f 5 43			7 31	4 31	12 32
114.5		WHITE HOUSE 7.8	4 32	f 5 33			7 20	4 20	12 21 77
110.6		ELBA 3.9	4 27	f 5 28			7 14	4 14	12 15
106.4		SAGERS 4.2	4 22	f 5 23			7 08	4 08	12 09
101.2		VISTA 5.2	4 16	f 5 17			7 00	4 00	12 01 AM
98.4	HR	THOMPSON 2.8 JDNWT	4 12	s 5 13			6 55	3 55	11 56 1
92.3		BRENDEL 6.1	4 05	f 5 03			6 34	3 34	11 34
85.6		FLOY 6.7	3 57	f 4 55			6 16	3 16	11 16
79.6		SOLITUDE 6.0	3 50	f 4 47			6 00	3 00	11 00
75.1		DALY 4.5	3 45	4 41			5 47	2 47	10 47
71.3	GR	GREEN RIVER 3.8 *NICWY	3 40	s 4 36			5 35	2 35	10 35
65.2		SPHINX 6.1	3 26	f 4 23			5 06	2 03	10 03
58.5		DESERT 6.7	3 18 77	f 4 15			4 57	1 54	9 54
51.8		CLIFF 6.7	3 10	f 4 07			4 48	1 45 75	9 45
45.9	WD	WOODSIDE 5.9 DNY	3 03 5	f 3 59 77			4 36	1 33	9 33
39.6		GRASSY 6.3	2 56	f 3 52			4 27 77	1 24	9 24
33.0		CEDAR 6.6	2 48	f 3 44			4 16	1 13	9 13
27.1		VERDE 5.9	2 41	f 3 37			4 06	1 03 61	9 03
23.3	MU	MOUNDS 3.8 JDNY	2 36	f 3 32 5			4 00	12 57	8 57
17.8		FARNHAM 5.5	2 29	f 3 21			3 52	12 49	8 49
13.0		WELLINGTON 4.8	2 23	f 3 14			3 45 5	12 42	8 42
7.4	CV	PRICE 5.6 DNWT	x 2 16 1	s 3 05			3 32	12 34	8 34
4.7		MAXWELL 2.7	2 12	2 47			3 27	12 29	8 29
	RA	HELPER 4.7 *NS OWY	2 05 AM	2 40 AM 1			3 18 AM	12 20 PM	8 20 PM
		(176.9)	Leave Daily	Leave Daily			Leave Daily	Leave Daily	Leave Daily
		Schedule Time	3.47	4.25			5.42	5.40	5.50
		Average Speed per Hour	46.3	40.1			31.0	31.2	30.3

# WESTWARD

# MAIN LINE

# EASTWARD

SECOND CLASS		FIRST CLASS		Miles from Denver	Sub-Division 4-A STATIONS		Miles from Dotsero	Capacity of Siding	FIRST CLASS		SECOND CLASS	
77 California Fast Freight	75 California Fast Freight		5 The Panoramio		TIME-TABLE No. 110				6 The Panoramio	40 Fast Freight	42 Fast Freight	
Leave Daily	Leave Daily		Leave Daily		JUNE 16, 1935				Arrive Daily	Arrive Daily	Arrive Daily	
2 25 PM	2 55 AM		8 30 PM	128.7	OD	ORESTOD	38.1		9 32 AM	6 20 AM	3 50 PM	
2 30	3 00		8 32	129.3		BOND	37.5	Yard	9 30	6 15	3 45	
3 00	3 15		8 37			5.6			9 25	6 01	3 31	
3 20 42	3 27		8 45	134.9		GLEN	31.9	105	9 16	5 50	3 20 77	
3 37	3 43		8 56	142.1		7.2			9 05	5 36	3 06	
3 44	3 49		9 00	144.6		DELL	24.7	110	9 01	5 30	3 00	
3 52	3 57		9 06	148.8		2.5			8 55	5 21	2 51	
4 06	4 11		9 15	155.3		BURNS	22.2	Spur 19	8 46	5 07	2 37	
4 12	4 16		9 18	157.7		4.2			8 43	5 03	2 33	
4 27	4 28		9 26	163.2		SYLVAN	18.0	105	8 35	4 52	2 22	
4 45 PM	4 45 AM 40		9 32 PM	166.8	dy	RANGE	11.5	105	x 8 30 AM	4 45 AM 75	2 15 PM	
						2.4						
						SWEETWATER	9.1	110				
						5.5						
						NICHE	3.6	96				
						3.6						
						DOTSERO		150				
Arrive Daily	Arrive Daily		Arrive Daily						Leave Daily	Leave Daily	Leave Daily	
2.20	1.50		1.02			Schedule Time			1.02	1.35	1.35	
20.8	24.1		40.1			Average Speed per Hour			40.1	28.2	28.2	

Schedule time and train orders of all trains at Orestod will apply at D. & S. L. connection switch.  
 Schedule time and train orders, westward trains from sub-division 4-A will apply at Dotsero depot.  
 All trains except first class will operate between Orestod and Bond under Rule 93.  
 Pueblo Division westward trains will leave Orestod and Pueblo Division eastward trains will leave Bond without clearance card.  
 See Special Time-Table Rule 35, Page 14, covering signals, spring switches and operations at Dotsero.

## WESTWARD ASPEN BRANCH EASTWARD

SECOND CLASS	Miles from Denver	Sub-Division 4-B STATIONS		Miles from Aspen	Capacity of Siding	SECOND CLASS
229 Mixed		TIME-TABLE No. 110				230 Mixed
Leave Daily Ex. Sunday		JUNE 16, 1935				Arrive Daily Ex. Sunday
9 00 AM	360.1	gn	GLENWOOD	41.2	Yard	3 25 PM
f 9 24	367.9		7.8 CATTLE CREEK	33.4	20	f 2 55
s 9 59	373.0	ce	5.1 CARBONDALE	28.3	38	s 2 35
f 10 19	379.4		6.4 LEON	21.9	23	f 2 01
s 10 39	382.0		2.6 EMMA	19.3	17	s 1 50
f 11 19	392.9		10.9 WOODY CREEK	8.4	13	f 1 16
11 59 AM	401.3	ns	8.4 ASPEN		Yard	12 45 PM
Arrive Daily Ex. Sunday			(41.2)			Leave Daily Ex. Sunday
2.50			Schedule Time			2.40
13.9			Average Speed per Hour			15.4

NO. 229 IS SUPERIOR TO NO. 230

## WESTWARD IBEX BRANCH EASTWARD

Miles from Denver	Sub-Division 3-B STATIONS		Miles from Ibea	Capacity of Siding
	TIME-TABLE No. 110			
JUNE 16, 1935				
275.8	a	LEADVILLE	7.0	Yard
276.3		0.5 C. & S. CROSSING NO. 12	6.5	
276.3		0.0 CHRYSOLITE JCT.	6.5	
278.2		1.9 GRAHAM PARK JCT.	4.6	
279.4		1.2 ROY	3.4	24
280.2		0.8 WATER TANK	2.6	
280.4		0.2 EVANS	2.4	5
280.8		0.4 PENN JCT.	2.0	
281.8		1.0 ALPS JCT.	1.0	
282.8		1.0 IBEX		Yard
		(7.0)		



# WESTWARD

# MAIN LINE

# EASTWARD

EST CLASS	Miles from Denver	Sub-Division 16		Miles from Grand Junction	Capacity of Siding	FIRST CLASS
		STATIONS				316
TIME-TABLE No. 110						
JUNE 16, 1935						
5						Passenger
Daily						Arrive Daily
5 PM	351.5	MA	MONTROSE* 5.9	72.7	Yard	2 55 PM
37	357.4		MENOKEN 4.8	66.8	26	f 2 42
17	362.2	HO	OLATHE 5.3	62.0	30	s 2 32
17	367.5		CHIPETA 5.8	56.7	27	f 2 20
3	372.8	DT	DELTA 4.7	51.4	Yard	s 2 10
12	377.5		ROUBIDEAU 2.8	46.7	66	f 1 51
7	380.1		STRATTER 4.8	44.1	35	f 1 46
17	384.9		ESCALANTE 6.0	39.3	26	f 1 38
8	390.9		DOMINGUEZ 6.8	33.3	43	f 1 28
0	397.7		BRIDGEPORT 5.1	26.5	100	f 1 16
9	402.8		DEER RUN 5.2	21.4	61	f 1 07
8	408.0		KAHNAH 5.3	16.2	11	f 12 58
6	411.8		WHITEWATER 5.3	12.4	48	f 12 50
6	417.3		UNAWEEP 5.9	6.9	26	f 12 40
3 PM	424.2	JN	GRAND JCT.* 5.9		Yard	12 20 PM
Daily			(72.7)			Leave Daily
			Schedule Time			2.35
			Average Speed per Hour			28.1

# WESTWARD

# NORTH FORK BRANCH

# EASTWARD

Miles from Denver	Sub-Division 16-A		Miles from Delta	Capacity of Siding
	STATIONS			
TIME-TABLE No. 110				
JUNE 16, 1935				
415.3		SOMERSET 4.4	42.8	Yard
410.9		BOWIE 5.0	38.1	3
405.9	SW	PAONIA 2.3	33.1	30
403.6		COBURN 5.9	30.8	13
397.7	HK	HOTCHKISS 4.5	24.9	27
393.2		LAZEAR 0.6	20.4	10
392.6		ROGERS MESA 7.1	19.8	34
386.5		PAYNE 4.7	12.7	33
380.8	AX	AUSTIN 1.0	8.0	17
379.8		SAXTON 7.0	7.0	39
372.8	DT	DELTA (42.5)		Yard

# WESTWARD SUNNYSIDE BRANCH EASTWARD

Miles from Sunnyside	Sub-Division 5-A		Miles from Monrovia	Capacity of Siding
	STATIONS			
TIME-TABLE No. 110				
JUNE 16, 1935				
		SUNNYSIDE 4.1	17.2	Yard
4.1		COLUMBIA JCT. 3.4	18.1	
7.5		WHITE'S 9.7	9.7	40
17.3	MU	WOUNDS (17.2)		Yard

## Special Time-Table Rules

RESIDING GENERAL RULES AND REGULATIONS WHICH ARE INCONSISTENT THEREWITH

EASTWARD TRAINS ARE SUPERIOR TO WESTWARD TRAINS OF THE SAME CLASS, EXCEPT:

- No. 229 is superior to No. 230.
- Schedule time and train orders, eastward trains, will apply at end double helper.
- Schedule time and train orders of all trains at Orestod will apply at L. connection switch.
- Schedule time and train orders westward trains from Sub-Division 4-A apply at Dotsero Depot.
- No. 15 will leave Malta without clearance when no operator is on duty.
- No. 16 will leave Leadville Jct. without clearance.
- There is no train order signal at Leadville, Tennessee Pass or Delta. No ill leave these stations without clearance except all trains will leave Leadville Delta without clearance when no operator is on duty.
- Trains to or from Sub-Division 4-A will leave Dotsero without clearance of operator on duty.
- Trains will leave Aspen without clearance.
- Train register books are located at:
  - Dotsero
  - Bond (passenger trains only)
  - Orestod
  - Glenwood (Branch trains only)
  - Aspen
  - Grand Junction
- Delta
- Somerset
- Montrose
- Helper
- Mounds (Branch trains only)
- Sunnyside

Register stations are shown in body of the time-table in FULL FACED TYPE.

- 3-A. Conductors must register the number of their helper engines with their trains.
- 3-B. Conductors on Nos. 15 and 16 will register both arriving and departing time, in registers at Malta and Leadville Jct., for the information and guidance of crews on inferior trains between these points on Sub-Division 3.
- 3-C. Eastward passenger trains will register at Tennessee Pass with registering ticket.
  - If register check at Tennessee Pass shows No. 15 as having arrived at Tennessee Pass, this is sufficient authority that No. 15, of the same date, has arrived at Malta.
- 3-D. If No. 16 is registered at Salida or is met between Salida and Malta this is sufficient authority that No. 16 of the same date has arrived at Leadville Junction.
  - Nos. 15 and 16 must not be authorized to display signals on Sub-divisions 3 or 3-A.
- 3-E. Trains will register at Dotsero with registering ticket when Operator is on duty.
- 4. YARD LIMIT STATIONS
  - Salida
  - Buena Vista
  - Kobe
  - Malta—Leadville
  - Tennessee Pass
  - Pando
  - Minturn
  - Dotsero
  - Bond
  - Glenwood
  - Funston
  - Aspen
  - Carbondale
  - Emma
  - Woody Creek
  - Palisade
  - Grand Junction
  - Mack
  - Thompson
  - Green River
  - Sunnyside Branch
  - Price
  - Helper
  - Delta
  - Olathe
  - Montrose
  - Austin
  - Between Rogers
  - Mesa and Lazear
  - Hotchkiss
  - Between Paonia and Somerset

4-A. Yard Limits, Sub-Division 2-A, will extend from Malta to Leadville inclusive, and on Sub-Division 2-B will extend from Leadville to Ibox inclusive.

Second and inferior class and extra trains and yard engines will move within these yard limits in compliance with rule 93 of the rules and regulations of the Operating Department.

4-B. Rule 93 is modified as applied to first class trains on Sub-Division 16 between Passenger Station and east end of Colorado River Bridge, Grand Junction Yard, and within yard limits, Delta.

First class trains must move within these limits prepared to stop unless the main track is seen or known to be clear. In case of collision responsibility rests entirely with the approaching train or engine.

5. First class trains moving against the current of traffic on double track must move within yard limits prepared to stop, unless the main track is seen or known to be clear. In case of collision responsibility rests entirely with the approaching train or engine.

6. In applying retainers, commence at the head end of train; alternating retainers every ten miles, and in changing position of retainers, speed of train will be reduced to twelve (12) miles per hour while change is being made. In operating retainers, if any individual car is found to have wheels overheating, retainers must be turned to release position until wheels have had sufficient time to cool.

6-A. TENNESSEE PASS TO SALIDA. The use of retainers will be left to the judgment of Conductors and Enginemen.

6-B. TENNESSEE PASS TO MINTURN. Trains consisting of empty cars; retainers will be alternated. Trains consisting of loaded cars; all retainers must be used in light holding position, and in case retaining power is noticed to be insufficient to hold train while auxiliary reservoirs are being charged, a number of retainers on head end of train may be turned to heavy holding position on heavily loaded cars.

6-C. MINTURN TO WILMOR: The use of retainers will be left to the judgment of Conductors and Enginemen.

6-D. BALLARD AND THOMPSON BRANCH. All retainers must be used on descending grades.

6-E. SUNNYSIDE BRANCH: All retainers must be used on descending grades.

6-F. In handling of freight trains Tennessee Pass westward not more than one (1) car having non-air or inoperative air brakes will be permitted to descend in solid coal, ore or steel trains, not more than two (2) cars having non-air or inoperative air brakes in freight or mixed trains.

6-G. Trainmen must try hand brakes on all cars, and know condition of the same before trains descend heavy grades in the Leadville District. During a test of air and while the air is applied trainmen must turn up all retaining valves to ascertain their condition. After brakes have been released, and before starting down heavy grades retainers must be turned up and trainmen must assist in holding the train with hand brakes, using sufficient hand brakes to insure safety.

6-H. All trains except eastward passenger trains will stop at Tennessee Pass for inspection of train and brakes.

Eastward passenger trains at Tennessee Pass will make running test in accordance with Rule No. 15 of the Air Brake Instruction Book.

Westward freight trains will stop at Pando and eastward freight trains will stop at Kobe to cool wheels and inspect train.

6-I. The members of train crews must assist inspectors in inspecting the air brake equipment as well as the general condition of the train, before leaving Tennessee Pass, and put same in safe operating condition before descending the grade. After brakes have been released on passenger cars, and before trains start from this station, retainers must be turned up.

6-J. At least one member of the train crew must be on the rear end of the train on both ascending and descending grades, and a close observance of train made for sliding wheels.

6-K. Where locomotives are equipped with Water Brakes, be sure that these are in good working order.

7. Trains approaching the following crossings at grade, which are not protected by signals or derails, must stop at a point designated by stop board and not proceed until sure that track is clear. (See general Rule 98.)

Sub-Division	M. P. Location	Crossings
3-B	276.3	C. & S. R. R.

7-A. Switch lights in A. B. S. territory are maintained only on switches where required for yard operation and to protect facing point switches in reverse direction movement on double track not signalled for reverse movement.

In A. B. S. territory trains moving against the current of traffic on double track not signalled for reverse direction movement, must approach all facing point switches prepared to stop unless the switch is seen or known to be properly set for the main track; facing point spring switches must be inspected on the ground. Unless otherwise provided Automatic Block Signals govern trains moving only with the current of traffic.

In the event several automatic block signals are damaged or destroyed, become inoperative, such signals will be taken out of service by train order the following form:

"Effective \_\_\_\_\_ (time) \_\_\_\_\_ (date) \_\_\_\_\_ A. B. S. Nos. \_\_\_\_\_ between \_\_\_\_\_ (station) \_\_\_\_\_ and \_\_\_\_\_ (station) \_\_\_\_\_ will be taken out of service."

Under this order, trains will operate just the same as they do in non-A. B. territory. When such signals are taken out of service, all lights will be put out and the signal heads turned at right angle to the track.

7-B. Rule 505-A is revised as follows:  
"Automatic Block Signals are designated by number plate located on track just below the signal. Positive automatic block signals have an additional red light or glass reflecting marker indicating the letter 'P', placed above or below the signal. Trains passing a Positive Automatic Block Signal automatically set to STOP all block signals governing train movements from the next opposing Positive Automatic Block Signal."

7-C. Rules 509, 509-A and 509-B are revised as follows:  
509. Trains stopped and proceeding by a "stop" signal, must not exceed speed of eight miles per hour to the next clear or approach A.B.S. expecting to find a train in the block, broken rail, obstruction or switch not properly lined. In all cases, a flagman must precede the train through an intervening tunnel. It must be known that all facing point switches are properly lined for the main track facing point spring switches must be inspected on the ground.

509-A. When a train is stopped by a "positive stop" signal, it may proceed when the signal is cleared, or when it is authorized to proceed. In case of failure of means of communication, it may proceed when preceded by a flagman.

If it is possible for an opposing train to be in the block, the Dispatcher must authorize the train to proceed by issuing the following train order:

"Proceed under flag protection and according to Rule 509."

When it is known to the Dispatcher positively there is no opposing train between the two communicating points, the following train order should be issued:

"Proceed according to Rule 509."

In case of a work train in the block, the following train order may be issued:

"Proceed according to Rule 509 looking out for Work Extra \_\_\_\_\_ in the block."

509-B. When a train is stopped by a "stop and proceed" signal, it may proceed when the signal is cleared, or if not immediately cleared, at once under Rule 509 except when proceeding under Rule 509-A under flag protection, the flagman must precede the train to the next clear or approach signal.

7-D. Rule 517 of "Automatic Block Signal Rules, 1927" is revised as follows:  
"A train which is to take siding may pass stop and proceed signal at 'Stop' to enter siding at restricted speed, provided the switch is known to be lined for the siding and the track to the switch is known to be clear."

7-E. Rule 510 of "Automatic Block Signal Rules, 1927," is revised as follows:  
"A Grade Signal is a 'STOP AND PROCEED' signal with an additional indication mounted below and to the right of the signal, and when illuminated will show the letter 'G' to modify the automatic block signal restriction. In the absence of the illuminated 'G' which indication will appear only under certain conditions, the train will be governed by 'STOP AND PROCEED' signal. When the 'G' is illuminated, freight trains may pass the 'STOP AND PROCEED' signal and proceed at a speed not to exceed eight miles per hour to the next A. B. S., expecting to find a train in the block, a broken rail, obstruction, or switch not properly set. Passenger trains must STOP even though the 'G' be illuminated, and be governed by the 'STOP AND PROCEED' signal, except between Minturn and Tennessee Pass, and between Helper and Thistle, passenger trains may pass 'STOP AND PROCEED' signal when the 'G' is illuminated in the same manner as freight trains."

7-F. Westward signal No. 6255, located at end of double track Helper, has two signals on mast, top signal governing westward movements on main track and lower signal governing westward movements to the eastward track when the cross-over located at end of double track is reversed.

7-G. Between Vista and Thompson there is no intermediate A.B.S. Train occupying main track at Vista between A. B. S. 5258 and the signal overlap sign will hold A.B.S. 5258 and positive A.B.S. 5272 at east end Thompson in stop position.

7-H. Between Luke and Dotsero there is no intermediate A. B. S. Train occupying main track at Luke between A. B. S. 3404 and the signal overlap sign will hold A.B.S. 3404 and positive A.B.S. 3414 at east end Dotsero in stop position.

7-I. In all instances where it is necessary to use tracks or crossovers which converge with a main track immediately in advance of an A. B. S., the indication of the A. B. S. given prior to the operation of any switches must be observed when using that main track.

A. B. S. 3420 does not govern the movement of an eastward train moving through passing track at Dotsero onto Sub-Division 4-A.

8. Persons accompanying live stock or other freight will be carried on any freight trains handling such live stock or freight, when holding proper transportation, and when permission to accompany same is covered by contract. Passengers on freight trains should be informed that cabooses will not be pulled up to platform to receive or deliver passengers or baggage. Employees holding passes will be carried on any freight trains to and from points at which trains stop when passes are stamped: "Good on Freight Trains."

8-A. Passengers may be carried on freight trains between Delta and Somerset.

8-B. Extra freight trains are ordinarily operated as follows:

Between Grand Junction and Minturn  
 Eastward, Mondays, Wednesdays and Fridays. Departing about 6:30 A. M.  
 Westward, Tuesdays, Thursdays and Saturdays. Departing about 6:00 A. M.

Between Helper and Sunnyside  
 Eastward, Mondays, Wednesdays and Fridays. Departing about 7:30 A. M.  
 Westward, Tuesdays, Thursdays and Saturdays. Departing about 6:00 A. M.

9. Cars placarded "Explosives" must not be cut off while in motion, and other cars must not be dropped against them.

Trainmen must not uncouple cars on grades without first testing hand brakes and knowing they will work.

10. All employes are hereby notified of close clearance of structures, etc., located on the main track and on sidings, as follows:

Sub-Division	Miles	Description	Side or Overhead
13	215.1	Salida Yard—Bridge 215.14	Side and overhead
3		Salida Yard tracks L-131-132 class engines	Side
3	225.1	West Brown Canon—rock cut	Side
3	225.2	West Brown Canon—Bridge 225.27	Side
3	225.8	West Brown Canon—rock cut	Side
3	240.2	Buena Vista—Bridge 240.21	Side
3	246.4	West Americus Bridge 246.43	Side
3	252.0	Princeton Siding—Stock Chute	Side
3	254.0	West Princeton—Bridge 254.01	Side
3	266.9	Snowden—Old C. M. Abutment	Side
3	271.0	Malta—Water Column	Side
3	271.0	Malta—Train Order Signal	Side
3	271.0	Malta—Coal chute	Side
3	281.5	Tennessee Pass Tunnel	Side and overhead
3	282.1	East Mitchell—A. B. S. 2822 W	Side
3	284.5	West Mitchell—A. B. S. 2845-E	Side
3	286.7	Deen Tunnel	Side and overhead
3	286.9	Deen—A. B. S. 2870-W	Side
3	288.4	Pando—Water Column E. B. Track	Side
3	288.6	Pando—Water Column E. B. & passing track	Side
3	291.3	West Pando—Bridge 291.34 E. & W.	Side
3	294.3	West Red Cliff—Bridge 294.25 E. & W.	Side
3	294.3	West Red Cliff—Bridge 294.27 E. & W.	Side
3	296.1	Belden Tunnels—Eastward track	Side and overhead
3	296.4	West Belden—Bridge 296.45-E	Side
3	297.6	Rock Creek Tunnel—Eastward track	Side and overhead
3	301.6	Minturn—A. B. S. 3016	Side
3-B	275.8	Ibex Branch—Snow Sheds	Side and overhead
4	303.4	Minturn—Bridge 303.40	Side and overhead
4	321.2	West Wolcott—Bridge 321.23	Side
4	350.0	Shoshone Tunnel No. 1	Overhead
4	351.0	Shoshone Tunnel No. 2	Overhead
4	359.0	Glenwood Tunnel	Overhead
4	360.1	Glenwood—Water Column Main and passing tracks	Side
4	360.2	Glenwood—Viaduct	Overhead
4	360.3	Colorado River Bridge 360.30	Side and overhead
4	360.7	Funston Coal chute, main and E. B. passing	Side
4	372.7	New Castle siding—stock chute	Side
4	372.8	New Castle—Bridge 372.82	Side
4	372.8	New Castle siding—Bridge 372.82-S	Side
4	386.6	Rifle—Water Column, main line and siding	Side
4	444.2	West Clifton—Bridge 444.25	Side
4-B	371.7	Carbondale—Bridge 371.72	Side and overhead
4-B	373.0	Carbondale Siding—Stock chute	Side
4-B	382.0	Emma Siding—Stock chute	Side
4-B	387.3	Bates Siding—Stock chute	Side
4-B	392.9	Woody Creek Siding—Stock chute	Side
5	460.5	Fruita Siding—Stock chute	Side
5	471.2	West of Mack—Bridge 471.23	Side
5	471.9	Ruby Tunnel	Overhead
5	487.7	East Switch Westwater—Bridge 487.71	Side
5	580.6	East Switch Woodside—Bridge 580.58	Side
5	580.6	Woodside Siding—Stock chute	Side
5	595.8	West Cedar—Bridge 595.78	Side
5	609.5	West Switch Farnham—Bridge 609.51	Side
5	612.0	West Farnham—Bridge 612.02	Side
5	619.7	West Switch Price—Bridge 619.67	Side

Sub-Division	Miles	Description	Side or Overhead
16	332.2	Olathe Siding—Stock chute	Side
16	373.2	West Switch Delta—Bridge 373.22	Side
16	378.4	West of Roubideau—Bridge 378.38	Side
16	378.9	West of Roubideau—Bridge 378.91	Side
16	400.1	Bridgeport Tunnel	Side and overhead
16	423.5	East End Grand Jct. Yard—Bridge 423.52	Side and overhead
16-A	380.2	West of Austin—Bridge 380.19	Side and overhead
16-A	380.8	Austin Siding—Stock chute	Side
16-A	398.6	East of Hotchkiss—Bridge 398.66	Side and overhead

All employes are also hereby notified that there are coal chutes, buildings, platforms and other structures located on tracks other than the main track and sidings, that will not clear a man riding on the side or on the top of a car; and all employes must protect themselves from injury in passing such structures.

11. The following signs indicate:

- s—Regular stop.
- f—Flag stop to receive or discharge passengers or freight.
- x—Conditional stop under Rule 14.
- l—Meals or lunch.
- N—Day and night telegraph office.
- NO—Night (only) telegraph office.
- D—Day (only) telegraph office.
- DN—Part day and part night telegraph office.
- Tg—Telephones station.
- C—Coal station.
- W—Water station.
- Y—Wye.
- T—Turntable.
- J—Junction Point.
- f—Scale.
- B—General Orders and Bulletin.
- †—Standard clock.
- Sand.

12. The speed of trains should be so restricted that absolute safety will be assured, and the maximum speed will ordinarily be that necessary to make the schedule. Except in territory specified below, enginemen and conductors may moderately increase the speed above that required by the schedules when the necessity arises, if in their judgment it be safe and prudent, bearing in mind that safety in operation is to be given first consideration, and always giving due consideration to track and surrounding conditions. At no time, however, should a speed exceeding sixty miles per hour be made with passenger trains, or a speed exceeding forty-five miles per hour be made with freight trains on the main line.

12-A. Slow boards painted yellow, with the required numerals in black, are located 1,400 feet in advance of certain locations where the speed of trains is permanently restricted. The upper numerals denote the maximum speed in miles per hour allowable for passenger trains, and the lower for freight trains, but in no wise abrogate nor modify special rules, train orders nor instructions further restricting the speed of any or all trains. Where two or more restricted areas are close together, but one pair of slow boards is used. Enginemen should restrict the speed of train until, in their judgment, the entire train has passed the restricted territory, when normal speed may be resumed. The reverse side of slow board is painted green and indicates a point 1,400 feet beyond the restricted territory, and will serve as a guide to enginemen, in resuming normal speed.

Speed restrictions governing freight trains will govern the speed of light engines unless otherwise provided in Rule 12-B.

12-B. The specific restrictions shown below cover certain territories where conditions make a specific limited speed necessary, and these restrictions, also any other special speed restrictions, must be complied with:

Sub-Division	Passenger MPH	Freight MPH
Sub-Division 3:		
Between Salida and Tennessee Pass.....		40
Mallet Engines.....	35	35
Tennessee Pass to Rex.....	22	15
Rex to Minturn.....	30	20
Sub-Division 3-A:.....	25	15
Sub-Division 4:		
Between Minturn and Palisade.....	55	
1400 Class Engines.....	35	35
Mallet Engines.....	35	35
On curve east end of bridge 360.30, Glenwood.....	25	25
Sub-Division 4-A:.....	50	35
Mallet Engines.....	35	35
Sub-Division 4-B:.....	20	20

Sub-Division 5:	Passenger MPH	Freight MPH
Between Helper and Mack.....	55	
1400 Class Engines.....	40	40
Mallet Engines.....	35	35
Ballard and Thompson Branch.....	6	6
Sub-Division 5-A:.....		12
Sub-Division 16:		
Between Grand Junction and M. P. 356.....	40	20
Between M. P. 356 and Montrose.....	35	20
Sub-Division 16-A:.....	30	15
Slow boards at Shale cut near M. P. 402 and slow boards between M. P. 413 and 414.....	12	8
Between M. P. 390¾ and 391.....	10	10
Between M. P. 396 and 1000 feet east.....	10	10

**All Sub-Divisions, except where specific restrictions in certain territories require lower speed:**

Over all spring switches, except when lower speed is specified by timetable or slow board.....	25	25
Through turn-out all spring switches Salida.....	8	8
Through turn-outs ends of double track East Mitchell, West Mitchell and Deen.....	22	15
In or out of other turn-outs.....	15	15
Approaching and thru Interlockers.....	25	20
Over Railroad Crossings not Interlocked.....	25	20
Engines backing up.....	15	15
Trains hauling dead engines with side rods up.....		25
Trains hauling dead engines with side rods all down.....		15
Trains hauling dead engines with one pair wheels swinging.....		10
Steam Derricks, Shovels, Clam Shells, Short Scale Test Cars, Ditchers and Pile Drivers moving on own wheels also K. & J. and Western Air dumps and loaded system coke racks.....		25

**12-C. City ordinances speed limits as follows:**

	Miles per Hour
Buena Vista.....	25
Grand Valley.....	30
Palisade.....	15
Grand Junction.....	25
Montrose.....	15
Price.....	20

**12-D. Engines must not be moved on spur track at Pando.**

In using wye at Woodside examine highway crossing on both legs of wye before using to insure flangeway being clear of gravel.

M-64, M-67, M-75, F-81, L-131 and L-132 class engines must not be moved on wye at Price.

L-131 and L-132 class engines must not be moved west of road crossing on high line track at Silt nor placed on Nada Spur, M. P. 385.7.

On Sub-Division 4-B, C-41 class engines must not be doubleheaded with any power larger than T-31 class and C-48 class engines must not be doubleheaded with any class of power.

Engines heavier than C-48 class will not be permitted to cross Bridge 215.14 on narrow gauge main line Salida Yard.

**13. Company Surgeons are located as follows:**

J. F. ROE, Chief Surgeon, Denver	
Geo. H. Curfman.....	Salida.
G. W. Larimer.....	Salida.
C. R. Fuller.....	Salida.
L. E. Thompson; Eye, Ear, Nose & Throat.....	Salida.
V. B. Ayers.....	Buena Vista.
J. C. Strong.....	Leadville.
I. S. Egan.....	Minturn.
W. W. Crook.....	Glenwood.
R. B. Porter.....	Glenwood.
W. R. Tubbs.....	Carbondale.
W. H. Twining.....	Aspen.
O. F. Claggett.....	Rifle.
F. H. Weidlein.....	Palisade.
K. Hanson.....	Grand Junction.
A. G. Taylor.....	Grand Junction.
H. M. Tupper.....	Grand Junction.
G. C. Cary (Eye).....	Grand Junction.
L. A. Hick.....	Delta.
Lawrence Hick, Jr.....	Delta.
J. A. Spring.....	Montrose.
C. G. Brethouwer.....	Montrose.
A. H. Gould.....	Paonia.
J. E. McConnell.....	Somerset.
Jas. S. Orr.....	Fruita.
E. H. Walker.....	Thompson.
F. R. King.....	Green River.
M. T. Johnson.....	Sunnyside.
Chas. Ruggeri.....	Price.
A. R. Demman.....	Helper.

**13-A. Hospitals are located as follows: D. & R. G. W. Salida; St. Mary's, Grand Junction.**

**13-B. PROMPT REPORT MUST BE MADE OF ALL ACCIDENTS**  
When a personal injury occurs on a train, a message must be sent to the Superintendent and Claim Department showing the kind of transportation injured person holds, giving number of ticket or pass, destination of party, and if injury party is stopping over enroute, state where stop-over will be made, and address at point of stop-over. Message should show whether or not injured party coach or pullman passenger, and if pullman passenger, name of pullman should be given. Telegraph Accident Report (Form 3884) must be made at once as per instructions thereon. Mail reports of all accidents and casualties must be promptly made, using the following forms, according to the instructions thereon and in Book of Rules:

- Personal Injury Report (Form 3922 or 8407, as appropriate).
- Names of Passengers (Form 4009)
- Names of Witnesses (Form 4000).
- Ejectment (Form 3926).
- Inspection (Form 4012).
- Fire Report (Form 4119).
- Stock Report (Enginemen—Form 3511).
- Stock Report (Sectionmen—Form 4117).

**13-C. SURGICAL ATTENTION.** (Passengers and employes.) Whenever passengers or employes are injured, everything must be done to care for them proper either calling the Company's nearest Surgeon to treat them (and if seriously injured, calling the nearest competent Surgeon to be had, until the Company's Surgeon can get to the place of accident), or if they are able to be moved, taking them to the nearest place at which the Company has a Surgeon and turning them over him for care and treatment. If other than a Company Surgeon is called, he is advised that he is called for first attention only, beyond which the Company assumes no responsibility for his bill.

(Others.) When persons not employes or passengers (for example, persons injured at crossings, trespassers, outsiders at work around depot or industrial etc.) are injured, if they are unable to care for themselves, and if no friends or others are at hand to care for them, the nearest Company Surgeon should be called or if he cannot be reached, the nearest other competent Surgeon, which Surgeon must be advised that he is called for emergency attention only and that the Company does not assume responsibility for his bill. If trespassers are not taken charge of by friends or others, they should be turned over to the public authorities as soon as possible, and no expense incurred in behalf of the Company except for emergency attention above noted.

**13-D.** Parties calling Surgeons should explain fully as possible the nature of injuries so that the Surgeon may know what equipment to bring with him.

**13-E.** When any accident, collision of trains, or any collision of trains with vehicles or pedestrians, resulting in loss of life or injury to persons in Colorado the superior officer, agent or employe on the ground at time of such accident should immediately notify the Public Utilities Commission, Capitol Building, Denver, Colorado, by telegram, the details of such accident, stating the immediate location and the nature of the accident and the number of persons killed or injured.

Information covering such accidents must be sent by Western Union Telegraph Company wires, and all Agents will accept and so transmit same, assessing charges therefor against the Railroad Account.

**14.** Nos. 1, 2, 5 and 6 will stop at any station to discharge pay passengers ticketed through from foreign lines, or to pick up pay passengers ticketed through to points on foreign lines.

**14-A.** No. 1 will stop at any station east of Grand Junction to pick up pay passengers for stations west of Grand Junction.

**14-B.** No. 2 will stop at any station east of Grand Junction to discharge pay passengers from west or south of Grand Junction.

**14-C.** No. 5 will stop at Dotsero, Rifle and Price to discharge pay passengers from Denver or beyond. No. 6 will stop at Price, Rifle and Dotsero to pick up pay passengers for Denver or beyond.

**14-D.** No. 6 will stop at Rifle and Dotsero to pick up mail.

**14-E.** No. 1 will stop at Palisade to discharge pay passengers originating at Denver, Colorado Springs and Pueblo.

No. 2 will stop at Palisade to pick up pay passengers destined Salida at points east where train is scheduled to stop.

**14-F.** Nos. 15 and 16 will stop on flag at Mile Post 283.7, Edwards, Allers Ranch, Antlers and Rulison.

**15. Spring switches are designated by "Spring Switch" signs.**

The normal position of these switches is as shown below.

Trains stopping on spring switches, while trailing through, must not make back-up movement or take slack until switch has been thrown by hand.

Running switches or dropping cars will not be permitted over spring switches.

When necessary to throw a spring switch by hand, the switch should be operated slowly, keeping a steady pressure on the handle of the switch stand, and the employe handling the switch must remain adjacent to same until he locks it in normal position.

Miles from Denver	Location Spring Switches	Normal Position
213.8	Barrel	Westward main track
215.6	Salida	Eastward main track
216.3	West Switch Salida Yard	Main track
282.0	East Mitchell	Westward main track
284.6	West Mitchell	Eastward main track
286.8	Deen	Westward main track
288.5	East Switch Pando	Eastward main track
289.6	West Switch Pando	Westward main track
802.2	Minturn	Eastward main track
303.6	Minturn	Main track
166.8	Dotsero—Sub-Division 4-A	Main Track Sub-Division 4-A
166.8	Dotsero—Sub-Division 4-A	Passing Track
342.0	Dotsero Jct. Sub-Division 4-A	Main track Sub-Division 4
448.4	East Switch—Grand Junction	Main Track
625.6	Helper	Westward Main Track
625.7	Helper	Independent Lead

15-A. Eastward freight trains entering Minturn Yard must line derail in derailing position before caboose is uncoupled from train.

15-B. Location of Crossovers on double track:

Miles from Denver	Points
214.9	Facing
215.0	Trailing
215.1	Facing
282.9	Trailing
283.0	Facing
294.0	Facing
294.4	Trailing
296.3	Facing
296.4	Trailing
297.9	Trailing
298.0	Facing
301.5	Trailing
301.6	Facing
302.0	Trailing

16. Water Tanks or Cranes between Stations:  
Sub-Division 3, located M. P. 249.5.

17. The following are Auxiliary lines (Rules 14 T, 14-U):

Salida	Sub-Division 13
Malta	Sub-Division 3A
Leadville	Sub-Division 3B
Dotsero	Sub-Division 4-A
Orestod	Sub-Division 4-A
Glenwood	Sub-Division 4B
Grand Junction	Sub-Division 16
Mounds	Sub-Division 5A
Delta	Sub-Division 16A

The following special instructions, Rules 18 to 28, inclusive, in connection with the Rules and Regulations of the Operating Department, 1924, supersede all previous rules and instructions inconsistent therewith:

18. Rule 11 is revised as follows:

"A train finding a fusee burning red on or near its track must stop, and wait until it has burned out before proceeding, at restricted speed for a distance of at least one-half mile, or in Automatic Block Signal territory, to the next Automatic Block Signal.

"A red fusee should be used when safety requires a train be stopped.

"A yellow fusee is a signal to run at restricted speed for a distance of at least one-half mile, or in Automatic Block Signal territory, to the next Automatic Block Signal.

"A yellow fusee should be used where safety will permit."

19. Rule 86 is revised as follows:

"Unless otherwise provided, an inferior train must clear the time of a superior train in the same direction not less than 5 minutes but must be clear at the time a first class train in the same direction is due to leave the next station in the rear where time is shown.

"Where automatic block is continuous between stations, inferior trains must clear superior trains in the same direction sufficiently to give clear signal indication in the rear.

"In narrow gauge territory an inferior train must clear the time of a superior train, in the same direction not less than five minutes."

20. Rule 92 is revised as follows:

"A train must not leave a station in advance of its schedule leaving time."

21. Add to Rule 99 as follows:

"In Automatic Block Signal territory, when a train is stopped by a 'Stop and Proceed' signal, under conditions of momentary duration, the train may proceed in accordance with A. B. S. Rule 509-B, after the engineman has sounded whistle signal 14 (b), has received a proceed signal from train crew, and acknowledged same as provided by Rule 14 (g). The flagman must be on the ground at the rear, prepared to protect if train does not immediately proceed. When conditions require, fusees must be used to protect the train.

"Except as herein provided, all provisions of Rule 99 must be complied with."

22. Second paragraph of Rule 104-E is revised as follows:

"A train taking a siding must not be stopped for a trainman to close the switch, nor may the switch be closed, until the train is entirely clear of main track."

23. Rule 109 is revised as follows:

"Enginemen must exercise good judgment in making stops for fuel and water, cutting engine off when necessary to avoid rough handling or damage to equipment. Where grade conditions warrant, hand brakes must be set."

24. Add Rule 220-B as follows:

"220-B Train orders and MB's relating to track conditions, unless annulled, must be respected by conductors and enginemen on all trips made during the tour of duty on which such orders are received."

25. First paragraph of Rule 221 is amended to read:

"Except at stations where all trains are required to obtain a clearance card, a fixed signal must be used at each train order office, which shall indicate 'stop' when there is an operator on duty, except when changed to indicate 'proceed' to allow a train to pass when there are no train orders for any train in the same direction. Where other than two-position or three-position semaphore is used, the signal must not be changed to indicate 'proceed' when there is a train order for a train in either direction. A train must not pass the signal while 'stop' is indicated, without a clearance card. The signal must be returned to indicate 'stop' as soon as a train has passed. It must be fastened at 'proceed' only when no operator is on duty."

26. Add to instructions following Example 3 of Form G:

"Work extras, whether required to protect or not protect against extra trains, must clear the time of the extra five minutes."

27. Add to instructions following Form K:

"It will be necessary to obtain the annulment of a schedule or section but one, provided conductor and enginemen have a copy in their possession on each trip."

28. Add to instructions Form T:

"Trains receiving this order will register by registering ticket at station named and operator will record same in train register."

29. When spreaders are handled in trains other than work extras, they must be headed in working direction.

Where wreckers, clam shells or other derricks are moved the boom should be trained in trailing direction.

30. Not more than two men will be permitted on the leading footboard of a switch engine at the same time, one on each side of the drawbar.

31. Track No. 1 at Malta is westward passing track.

Track No. 1 at Funston is westward passing track.

First track north of coal chute at Funston is eastward passing track.

Depot track No. 2 at Grand Junction is passing track for passenger trains.

Track No. 3 at Green River is westward passing track for freight trains.

Track No. 4 at Green River is eastward passing track for freight trains.

31-A. Switch leading to spur track from west leg of wye at Pando must be left lined for the spur track.

31-B. Crossover switch on crossover leading from westward main track to house track at Minturn must be left lined for the house track.

22. Rule 208-A is modified to the extent that it will not be necessary for operators at Glenwood to place torpedoes on the rail when there is a "21" order to be delivered.

23. Trains arriving Salida on Sub-Division 13 must check register in Telegraph Office against first class trains on Sub-Divisions 2 and 3 before occupying standard gauge main tracks.

When signalled by Yardmaster in Salida Yard to do so, No. 316 may occupy eastward main track in front of Assistant Superintendent's office without checking register against eastward first class trains on Sub-Division 3.

23-A. Narrow gauge trains departing from Salida yard via eastward main track to switch in front of assistant superintendent's office must clear time of eastward first class trains at Bellevue or protect in accordance with Rule 99.

34. A. B. S. AND OPERATION BY SIGNAL INDICATION, TENNESSEE PASS—DEEN.

The limits of operation by signal indication are designated by signs.

Within these limits trains will be operated by indication of Automatic Block Signals and signals controlled from Tennessee Pass Tower, and the superiority of trains will be void, except when a section of double track is used as single track under Train Order Form 8. Except as otherwise provided herein, A. B. S. rules govern.

When a train or engine is stopped by a positive Stop signal, it may proceed when the signal is cleared, or when it is authorized to proceed by the signalman. The authority must be written and repeated by the conductor or engineman and record made by signalman.

A train must not make a reverse movement without the proper positive signal indication, except under flag protection when authorized by the signalman.

If head end of train passes a signal at end of siding or double track and then reverse movement is made so that it is again in the rear of the signal, the signalman must be notified at once.

24-A. Between Tennessee Pass and Deen, Rules 97, 97-B and 97-C of "Rules and Regulations of the Operating Department, 1924," are modified to permit the movement of extra trains and work extras by clearance card, except when a section of double track is used as single track under Train Order Form 8, proper train orders must be issued.

Classification and marker signals will not be removed through these limits.

Operation by signal indication does not dispense with the use or observance of other signals whenever or wherever they may be required.

Trains or engines having work to perform, must inform the signalman at Tennessee Pass the amount of time necessary and secure signalman's permission before entering the block in which the work is to be performed. If, for any reason, a train or engine is unduly delayed, the signalman at Tennessee Pass must be communicated with at once.

The signalman at Tennessee Pass controls the signals at east end Tennessee Pass, west end Tennessee Pass, East Mitchell, West Mitchell and end of double track at Deen.

When a mast has two signals, the top signal governs normal movements on the main track and the lower signal governs movements to siding.

Trains moving from siding to main track and from double track, when moving against the current of traffic, to single track, will be governed by signal, over or to the right of the track.

Movements on sidings are not protected by Automatic Block Signals between clearance points.

A green flag by day and a green light by night displayed in the west window of Tennessee Pass Tower will be authority for eastward trains to cut out helper engines, using crossover between main track and No. 1 track for that purpose.

A green flag by day and a green light by night displayed in the east window of Tennessee Pass Tower will be authority for helper engines to move from wye to No. 1 track.

Eastward trains having more cars than will clear between the middle crossover and the signal bridge at west end Tennessee Pass, will be authorized by signalman sounding four blasts of audible signal to make back up movement to cut out rear helper engine.

No westward freight train with more than twenty cars will leave Tennessee Pass until the westward signal on bridge at west end Tennessee Pass governing its movement displays a green or clear indication.

24-B. Audible annunciator is located three thousand feet west of the double track switch at Deen, and eastward trains will, commencing at the "Audible Annunciator" sign give the following whistle signals, using care to so space the whistle sounds as to be distinct, and so the signal will be completed by the time the engine reaches the annunciator:

Passenger trains.....One long blast.

Fruit and Stock Trains.....Two short blasts (counting three between each blast for space).

Other freight trains.....Three short blasts (count two for space).

34-C. REMOTE CONTROL AND HAND-THROW SWITCHES.

East switches to passing tracks Nos. 1 and 2 at Tennessee Pass are remotely controlled and operated by signalman at Tennessee Pass.

To operate a remote control switch by hand, permission with time limit must be secured from signalman. When time limit has expired, or when work is completed, the selector lever restored to the switch machine position, and the selector and hand-throw lever locked, the signalman must be so notified.

Written instructions governing the operation of remotely controlled switches are posted in adjacent telephone booth.

Enginemen must not accept hand signals as against fixed signals in making movements over a remote control switch, unless the selector, yellow lever, has been placed in the hand-throw position.

Switches at west end of Tennessee Pass are operated by carmen or trainmen under direction of the signalman, the following audible signals governing:

1 long blast—line switch No. 4 to passing track No. 2.

2 long blasts—line switch No. 5 to passing track No. 1.

3 long blasts—line switches for main track.

To operate main track hand-throw switches, or crossover switches leading to main track, permission must be secured from signalman.

The switches of the crossovers located at Mile Post 283.0 are manually operated and must be used only when authorized by the signalman at Tennessee Pass, or in emergency under flag protection in both directions.

25. Sub-Division 4-A (Dotsero Cutoff) begins at the switch at Mile Post 342.0, connecting with Sub-Division 4 at Dotsero. Sixty-five feet of the main track of Sub-Division 4-A (in front of Dotsero depot) will also be used as part of Dotsero siding. Trains using this track as siding must clear first class trains on Sub-Division 4-A.

During open hours of telegraph office at Dotsero, when trains have time-table authority or train orders which will permit them to proceed, operator will handle spring switches in front of the depot, when necessary, to avoid stopping train, carefully inspecting switch points to see that they fit closely when facing movements are to be made.

Eastward positive A. B. S. No. 3420 located at junction switch Dotsero has two signals on mast; top signal governs eastward movements on main track Sub-Division 4; lower signal governs eastward movements on main track to "End of Block" sign, Sub-Division 4-A when spring switch at Mile Post 342.0 is lined for Sub-Division 4-A.

Westward positive A. B. S. No. 1667, Sub-Division 4-A, has two signals on mast; top signal governs westward movements from Sub-Division 4-A to Sub-Division 4 when spring switch at Mile post 166.8 is lined for main track movement to Sub-Division 4; lower signal governs westward movements on main track to connection with siding; thence on siding to "End of Block" sign.

Westward trains Sub-Division 4-A entering Sub-Division 4 main track must remain in the rear of A. B. S. 1667 unless upper signal 1667 is in clear or approach position.

In making movements at Dotsero from either Sub-Division to siding, or from siding to either Sub-Division, facing point spring switches must be inspected on the ground.

26. Audible annunciator is located 500 feet west of west switch, Niche, and westward trains will when directly opposite "Audible Annunciator" sign, give the following whistle signals:

Passenger trains.....1 long blast.

Freight trains.....2 short blasts.

## Tracks not shown as Stations in Time-Table

JB-DIVISION	NAME	Mile	Car Capacity	Switch Connection
3	Tie Plant	216.8	881	East End
3	Mitchell	283.5	8	East End
3	Bonner	287.1	4	East End
3	Knight	295.1	5	East End
3	Black Iron Spur	295.2	8	West End
4	Dowda	303.4	5	West End
4	Edwards	312.1	15	East End
4	Sherman	325.5	3	West End
4	Bain	331.8	4	East End
4	Higby	353.4	7	West End
4	Deveraux	363.0	2	West End
4	South Canon	365.2	3	East End
4	Doll	376.3	6	East End
4	Antlers	382.3	16	Both Ends
4	Nada	385.7	13	East End
4	Rulison	396.9	7	West End
4	Midwest	435.8	47	West End
4	Savoy	436.7	40	West End
4	Bridges	440.2	21	Both Ends
4-B	Flour Mill	362.8	4	East End
4-B	Red Canon	364.1	3	East End
4-B	Kiggin	370.6	5	East End
4-B	Adnaw	376.1	6	Both Ends
4-B	Hooks	380.4	5	East End
4-B	Saco	384.3	9	East End
4-B	Wingo	385.1	9	West End
4-B	Rose	386.8	5	East End
4-B	Bates	387.3	6	Both Ends
4-B	Mellor	395.7	4	Both Ends
16	Roe	357.0	20	Both Ends
16	Frost	359.4	8	Both Ends
16	Casner	364.7	8	West End
16	Sage	370.5	10	West End
16	Campbell	375.8	6	West End
16-A	Beet Track	374.0	20	Both Ends
16-A	Saunders	377.3	7	Both Ends
16-A	Read	379.1	12	Both Ends
16-A	Bell Creek	400.5	12	West End
16-A	Elberta	401.4	15	West End
16-A	Hadley	404.5	12	Both Ends
16-A	Roberts	407.1	8	Both Ends
16-A	Underwood	408.0	4	West End
16-A	Morgan	409.1	8	Disconnected
16-A	Juanita Jct.	412.0	50	East End
16-A	Blackburn	412.1	20	Disconnected
16-A	Coal Mines	416.1	173	East End

## OPEN HOURS OF TELEGRAPH OFFICES

Station	Week Day Hours	Sunday and Holiday Hours
Salida	Continuous	Continuous
Buena Vista	9:00 AM to 1:00 AM	9:00 AM to 1:00 AM
Malta	5:30 AM to 1:30 PM	5:30 AM to 1:30 PM
	3:30 PM to 11:30 PM	3:30 PM to 11:30 PM
Leadville	4:30 AM to 1:30 PM	4:30 AM to 6:30 AM
Tennessee Pass	Continuous	Continuous
Red Cliff	5:50 AM to 2:50 PM	Closed
Minturn	Continuous	Continuous
Avon	7:00 AM to 4:00 PM	Closed
Wolcott	6:00 AM to 3:00 PM	Closed
Eagle	7:30 AM to 3:30 PM	7:30 AM to 3:30 PM
	5:00 PM to 1:00 AM	5:00 PM to 1:00 AM
Gypsum	7:45 AM to 4:45 PM	Closed
Dotsero	7:00 AM to 11:00 PM	7:00 AM to 11:00 PM
Orestod	Continuous	Continuous
Glenwood	Continuous	Continuous
New Castle	8:00 AM to 5:00 PM	Continuous
Silt	8:00 AM to 5:00 PM	Closed
Rifle	Continuous	Closed
Grand Valley	8:00 AM to 5:00 PM	Continuous
DeBeque	6:30 AM to 3:30 PM	9:45 AM to 11:45 AM
Palisade	8:00 AM to 5:00 PM	6:30 AM to 3:30 PM
Clifton	8:00 AM to 5:00 PM	11:00 AM to 2:30 PM
Grand Junction	Continuous	Closed
Fruita	8:00 AM to 5:00 PM	Continuous
Mack	8:30 AM to 4:30 PM	Closed
	10:15 PM to 6:15 AM	8:30 AM to 4:30 PM
Cisco	11:00 PM to 3:00 PM	10:15 PM to 6:15 AM
Thompson	11:30 PM to 3:30 PM	11:00 PM to 3:00 PM
Green River	Continuous	11:30 PM to 3:30 PM
Woodside	1:00 AM to 10:00 AM	Continuous
Mounds	1:30 AM to 10:30 AM	1:00 AM to 10:00 AM
Price	12:01 AM to 4:00 PM	1:30 AM to 10:30 AM
Helper	Continuous	12:01 AM to 4:00 PM
Carbondale	9:00 AM to 6:00 PM	Continuous
Aspen	8:00 AM to 5:00 PM	Closed
Delta	8:30 AM to 5:30 PM	Closed
Olathe	9:00 AM to 6:00 PM	1:45 PM to 4:45 PM
Montrose	9:00 AM to 6:00 PM	2:20 PM to 4:20 PM
Austin	9:00 AM to 6:00 PM	1:30 PM to 4:30 PM
Hotchkiss	8:00 AM to 5:00 PM	Closed
Paonia	8:15 AM to 5:15 PM	Closed

### LOCAL WATCH INSPECTORS

D. J. Kramer	Salida
F. J. Mund	Leadville
A. C. Parsons	Grand Junction
T. E. Dever	Glenwood Springs
C. D. Allen & Son	Delta
G. J. De Vinny	Montrose
Elite Jewelry Co.	Helper