COMPANY SURGEONS

*Dr.	Roscoe C. Webb, Chief Surg	eonMinneapolis, Minn.
*Dr.	Ernest R. Anderson, Asst. Chief Surgeon	Minneapolis, Minn.
*Dr.	Arthur M. Compton	Klamath Falls, Ore.
Dr.	C. J. Rademacher	Bend, Ore.
Dr.	J. C. Vandevert	Bend, Ore.
Dr.	L. C. Mosher	Bieber, Calif.

OPHTHALMIC SURGEON

*Designates also Examining Surgeon.

F. R. Cochran, Chief Dispatcher.

R. S. Olson, Asst. Trainmaster.

GREAT NORTHERN RAILWAY COMPANY

KLAMATH DIVISION

TIME TABLE 10

EFFECTIVE 12:01 A. M.

PACIFIC TIME

Sunday, January 1, 1950.

R. H. HEMMESCH, Superintendent.

I. E. MANION, General Manager.

J. B. SMITH, General Superintendent Transportation.

2 V	VES	STV	VARD					FIRST SUBDIVISION						EASTV	VARD
15		Car pacity		SECONI	CLASS	387	from	Time Table No. 10	Calls	ce from Klamath		386	SECONI	CLASS	
Station Numbers	Siding	Other Tracks				Time Freight Daily	Distance Bend	STATIONS	Telegraph	Distance South Kl	SIGNS	Time Freight			
вк о	Yard					L 7.00Am		BEND	ND	144.74	BDNKO PRVW XYZ	A 8.15Pm			
BETWEEN BEND DEPOT AND THIRD STREET, TRAINS WILL BE GOVERNED BY OREGON TRUNK RAILWAY, TIME TABLE AND RULES.															
вк з	Yard	358				7.15Am	2.79	BEND YARD	A	141.95	WXY	8.05Pm			
BK 13	91	14				7.50	13.01			131.73	P	7.45			
BK 24	102					8.15	24.30	STEARNS		120.44	P	7.25			
BK 32		15				8.35	31.62	LA PINE	NE	113.12	DPW	7.10			
		340				8.37	31.96	LA FINE WYE		112.78	PY	7.01	• • • • • • • • • • • • • • • • • • • •		
BK 39	107	. 24	•••••			8.55	38.63	BEAL		106.11	PW	6.45			
					•••••	9.08	44.24	SUMMIT JCT		100.50	PJVY	6.37	•••••		
BK 45		14			•••••	9.10	45.11	FREMONT		99.63	•••••	6.35	•••••		
BK 52	120					9.30	51.71	CRESCENT		93.03	P	6.25	• • • • • • • • • • • • • • • • • • • •		
BK 68		12				A 10.15Am	68.34	CHEMULT	MU	76.40	DNJKP RVXY	L 6.00Pm			
BETWE	EN	CHE	MULT A	AND BIE	BER LIN	E JCT., T	RAIN	S WILL BE GOVERNED BY SO	UTH	ERN P	ACIFI	C RY. TI	ME TAB	LE AND	RULE
BK144	Yard	468					144.46	KLAMATH FALLS	DS	2.72	DNK WX				
						1.45Pm	144.05	BIEBER LINE JCT		0.69	J BKOP RVWX	2.20Pm			
BK145	Yard	585				A 2.00Pm	144.74	SOUTH KLAMATH	·sk		YZ	L 2.15Pm			
						7.00 20.7		Time Over Subdivision Average Speed Per Hour				6.00 24.1			•

Westward trains are superior to eastward trains of the same class.

SEE ADDITIONAL SPECIAL INSTRUCTIONS PAGES 4 THROUGH 7.

WESTWARD SECOND SUBDIVISION EASTWARD 3															
, and I	Car Capacity		Car SECOND CLASS		math	Time Table No. 10	Calls	8	REIVI	BAUR	SECON	D CLASS			
n	_					387	Distance from South Klamath	Effective January 1, 1950		Distance from Bieber	SIGNS	386		30121	9.4
Station	Siding	Other	2 71			Daily	Dista	STATIONS	Telegraph	Distar		Daily			41
BK145 BK149	Yard	585 26				3.45Pm 3.55	3.85	SOUTH KLAMATH	sk	88.80 84.95	PRVWX YZ				
BK152		24				4.00	6.95	DEHLINGER.		81.85	P	5.48			
BK159	69	68				4.16	14.37	MERRILL	MR	74.43	DP	5.34			
3K161		27				4.20	16.26	STONEBRIDGE		72.54		5.30			
K164		46				4.27	19.74	ADAMS POINT		69.06	P	5.24			
3K169	100	130				4.45	23.79		MA	65.01	DPWX	5.17			
3K173		40				4.55	28.71	DALTON		60.09		5.07			
• • • • • • •							30.48	SOUTHERN PACIFIC RY, CROSSING		58.32	I				
BK176	69	43				5.00	30.89	STRONGHOLD	HD	57.91	DP	5.02			
BK181		42				5.11	36.11			52.69	P	4.54			
3K188	100	12				5.27	43.61	MAMMOTH		45.19	P	4.41			
3K191		270				5.37	47.33	AINSHEA BUTTE		41.47	PY	4.34			
K194		40		•••••		5.42	49.71	TIONESTA		39.09	P	4.30			
K199	69	14				5.52	53.80	KEPHART		35.00	P	4.21			
K210	100	0				6.10	65.44	SCARFACE		23.35	P	4.01			
3K222	69	94				6.35	77.56	LOOKOUT	ко	11.24	DPW BDNKOP	3.30			
3K234	Yard	319				4 6.55Pm	88.80	BIEBER	BR		RVWXYZ	L 3.00Am			
	L.					3.10 28.1		Time Over Subdivision Average Speed Per Hour			-1111	3.00 29.6		Lang Inc	

Westward trains are superior to eastward trains of the same class.

SEE ADDITIONAL SPECIAL INSTRUCTIONS PAGES 4 THROUGH 7.

SPECIAL INSTRUCTIONS

ALL SUBDIVISIONS

1. Omitted.

2. SPEED RESTRICTIONS GENERAL.

(a) Maximum permissible speed of passenger and freight trains, except Streamliners, will be designated by distinctive reflectorized roadway signs set in an upward angle of 45 degrees. Except as directly affected by speed restrictions prescribed below and other speed restrictions covered by Item No. 2 under individual Subdivisions, the 45 degree signs prescribe the speed territories and the numerals thereon indicate in miles per hour the maximum permissible speed which will govern until the next territory is reached.

When the movement is from a higher to a lower speed territory the 45 degree sign is located approximately one mile from the point where the lower speed becomes effective. When the movement is from a lower to a higher speed territory, the 45 degree sign is located at the point where speed may be increased. When operating against the current of traffic in double track territory, trains must not exceed the maximum permissible speed prescribed by the 45 degree sign with the current of traffic. This does not modify Rule 93.

When the 45 degree sign has two sets of figures, the numerals preceded with letter "P" apply to passenger trains, except Streamliners, and letter "F" to freight trains.

- (b) When passenger trains are handled by freight engines or when freight cars, except cars equipped with passenger trucks and steel wheels, are handled in passenger trains, the train will not exceed maximum permissible speed for freight trains in the territory operated.
- (c) Speed shown on Speed Limit Plate on engines must not be exceeded.

(d) Steam engines backing up	20	MPH
caboose only	35	MPH
Diesel and Electric engines light or with caboose only	50	MPH
Trains handling steam derricks, pile drivers, ditchers,	-	
cranes, steam shovels, dozers, etc. on Main Lines	25	MPH
except on 6 degree curves or sharper, and on Branch		
Lines	15	MPH
Trains handling ore cars or air dump cars loaded with		
ore or gravel and scale test car, on Main Lines	30	MPH
except on 6 degree curves or sharper and on Branch		
Lines	20	MPH
Trains handling carload poles or piling on open cars		
when operating on double track, siding or other		
adjacent track must stop meeting or being passed		
by Passenger Trains, for other trains reduce		
speed to	10	MPH
speed to		
trains or engines moving against the current of		
traffic on double track through interlockings	15	MPH
Trains or engines moving on main routes actuating		
points of spring switches	35	MPH
Trains or engines moving in facing point direction at		
spring switches without facing point lock	25	MPH
Trains or engines through No. 20 turnouts		MPH
(None on division)		
Trains or engines through No. 15 turnouts	25	MPH
(None on division)	-	
Trains or engines through all other turnouts	15	MPH

3. MOVEMENT OF ENGINES DEAD IN TRAINS.

Class O and larger engines will be placed not to exceed 15 cars behind road engine. In electrified zone only class R engine will be handled on head end, all others near rear. Class F-8 and smaller engines will be placed next ahead of caboose

Diesel and Gas-Electric engines 2300-2341 must be handled on rear of train.

Not less than five cars will be placed between all engines. Trains handling steam engines dead in train with side rods on both sides will not exceed 40 MPH; and without side rods will not exceed 10 MPH.

Trains handling Electric, Diesel and Gas Electric engines in tow dead in train will not exceed following speeds:

50	35 MPH
75 to 170	45 MPH
175 to 231 and 271	60 MPH
252 to 259-262 to 265-300 to 306-400 to 456	
260-261-266 to 270	
350 to 376-500 to 512	75 MPH
2300 to 2324	50 MPH
2325 to 2341	
5000 to 5008B	
5010 to 5019	

- Under Rule 2, watches that have been examined and certified to by a designated inspector must be used by train dispatchers and yardmen.
- Brakemen with less than one year of experience should not be used as flagmen except in emergency, and then Superintendent will be notified by wire.
- 6. When operating snow machines in non-block signal territory, no train should be permitted to follow closer than a station apart, when that cannot be done they will be blocked not less than thirty minutes apart.
- 7. After severe blizzard or dirt storm, employes on first train over road must exercise care to avoid accident caused by striking drift without first having drifts faced with hand shovels, cutting in far enough to get beyond the hard snow and giving a perpendicular wall to strike against instead of slope or wedge-like shape. When operating snow dozer, Conductor in charge will ride in the dozer.

On snow and dirt dozers every precaution must be taken to see that cage, flangers and wings clear all obstacles when in service and are properly secured when in through trains, and dozers properly turned. Hand screws must be tightened to raise flanger on dozers as high as possible before making a back-up movement, and must not be released until the dozing work is actually to start. Hand screws holding the cage on dozers must be tightened or chains otherwise fastened except when dozer has air in cylinders and is attended by an employe.

- 8. Loaded dump cars should not be handled on double track after dark, but if necessary to do so, close watch must be kept by trainmen and if a car dumps its load, train must be stopped and protection afforded on the opposite track.
- Baggage cars returned deadhead when moved in storage mail service in opposite direction will be accompanied by waybill carrying notation "Deadhead mail car, no material of any character other than U. S. Mail or mail sacks to be loaded in it." Conductors will be held responsible for compliance of waybill instructions.
- 10. Omitted.
- 11. Unless otherwise provided, when passenger trains are operated against current of traffic on double track or through sidings, Conductors shall notify Railway Postal Clerks, train shall stop at points where U. S. Mail is usually picked up and conductors are responsible for delivery of mail to Postal car.
- 12. Conductors will report by wire all flat spots on wheels of passenger cars. Any cars having flat spots on wheels of more than two and one-half inches long must be set out.
- 13. Due to limited overhead clearance at tunnels and structures, employes are warned to keep off top of cars of extreme height and width when handled in trains and yards, also such standing cars in electrified zone, except in emergency. In absence of previous advice on such cars, wire proper officer for instructions.
- 14. The Railway Company is responsible for proper handling of perishable freight on road and at points where Western Fruit Express Company do not maintain representatives. Conductors on trains handling perishable freight will ascertain from waybills class of service required and light or extinguish heaters and manipulate vents in accordance with current instructions provided for handling perishable freight issued by the National Perishable Freight Committee.

15. Placarded loaded tank cars moving in through freight trains must be placed not less than 6th car from engine or caboose; cars placarded "Explosives", "Inflammable", or "Corrosive Liquids", not less than 16th car from road engine, one car from helper engine and 11 cars from caboose. These cars may be handled second car from engine or caboose in local trains. These cars must not be placed in trains next to each other, next to refrigerators equipped with gas burning heaters, stoves or lanterns, or flat cars loaded with logs, poles, lumber, pipe, rails, iron, steel, and gondola cars with such lading higher than ends, or cars of similar lading that is liable to shift.

Carload express shipments of explosives, sealed and placarded, may be handled on passenger trains; LCL shipments may be made in so-called peddler car with messenger in charge when such car is assigned to the handling of express and baggage exclusively, provided shipments are accompanied by authorized representative of United States Government while on trains. Terminals or pick-up points enroute must furnish conductor and engineer Form 250 showing consecutively location in train of all cars placarded "Explosives". At points other than terminals where crews change notice will be transferred from crew to crew. Further details governing handling of Explosives, Inflammable and Corrosive Liquids may be found in I.C.C. Regulations.

- Gas-Electric engines must not be fueled while occupied by passengers, or coupled to cars occupied by passengers.
- 17. The normal position of a spring switch with facing point lock is identified by a color light type signal displaying a "lunar white" light for train or engine movements in a trailing point direction and for movements in facing point direction when conditions require.

The normal position of a spring switch without facing point lock is identified by a triangular yellow target on switch stand with letter "S" in black, and "lunar white" light in switch lamp in place of green light displayed in both directions through or over the switch.

Trains departing from stations, either from siding or main track, in trailing point movement actuating points of spring switches, a member of crew must observe indication of governing signal in opposite direction after rear end of train has passed through switch to ascertain if switch points return to normal position. If this signal indicates Stop and no immediate train movement or other cause is evident report the fact to Superintendent from first available point of communication.

During and immediately following snow storms or violent wind storms, spring switches must be operated by hand and relined to normal position before heading out through switch in trailing point movement, actuating switch points, to insure switch is in proper operating condition.

INDICATORS AT SPRING SWITCHES.

A Switch Indicator, consisting of a single yellow light unit (normally dark) and a switch-key-controller mounted on an iron mast located at clearance point of a siding, must be operated by a member of the crew who, together with engineer, must observe and be governed by its indication before fouling main track or making movement from siding to main track through a spring switch in automatic signal territory, unless the movement is made immediately after an opposing train has passed the switch, and Automatic Signal at leaving end of siding indicates "Proceed".

If Indicator displays a yellow light when switch-key-controller is operated, train or engine movement to main track may be made immediately in accordance with train rights and operating rules. Display of yellow light must continue until leading wheels have passed clearance point.

If Indicator does not display a yellow light when switch-keycontroller is operated, train or engine movement to main track may be made in accordance with train rights and operating rules, after operating spring switch by hand; waiting three minutes and taking every precaution to provide proper protection.

To operate Switch Indicator, insert switch key in controller and turn clockwise toward "R", hold a few seconds, and remove key. If yellow light is displayed and intended movement is not made, insert switch key in controller and turn counter-clockwise toward "N" to restore signal system to normal condition to avoid delays to trains on main track.

Switch-key-controller must never be operated toward "N" after having been operated toward "R" if intended movement to main track is to be made.

- 18. DRAGGING EQUIPMENT DETECTOR INDICATOR consists of a single white light unit (normally dark) with circular background mounted on signal or other mast. When white light is displayed, train must be stopped and inspected for dragging equipment. Notify Superintendent from first available point of communication.
- 19. Facing point locks on hand operated switches are indicated by a six-inch yellow stripe painted on target staff. Be positive locking device is restored to normal position after using. A running switch must not be made through this type switch.
- 20. Under Rule 24, engine number only will be displayed in indicators on engines so equipped. This will also apply when our engines are operating over Northern Pacific tracks. Between Klamath Falls and Chemult, Oregon, Southern Pacific Rules will govern.
- 21. Rule 204(A) prescribes that copies of train orders will be furnished the rear trainman, such orders will only be furnished on trains designated Nos. 1, 2, 3, 4, 7, 8, 9, 10, 28, 29, 30, 355, 358, 359, 360, and sections thereof; also extra passenger train, whether operated as section of regular train or as a passenger extra.
- Air hose on Diesel and Electric engines must be hooked up in hose fastener when not in use.
- 23. Before leaving any engine terminal enginemen will make proper tests and inspections of water glasses, gauge cocks, water column and injectors, and will not leave the terminal unless all these are in proper working order.

 Should enginemen on steam engines find that the water is not in sight in water glasses, and if water cannot be raised to bottom.

Should enginemen on steam engines find that the water is not in sight in water glasses, and if water cannot be raised to bottom gauge cock or water glass by opening throttle, on oil burning engines the fire must be extinguished immediately and on coal burning engines the fire must be knocked out or smothered to the extent there will be no damage done to the crown sheet. If water can be raised to the bottom gauge cock or water glass the water level should be built up by use of the pump, or injector, or both.

Should the low water alarm whistle blow, on any engine so equipped, enginemen will immediately ascertain where the water level is in the boiler by blowing out water glasses and water column, and being sure that water glass mounting valves are open and if water cannot be raised to the bottom gauge cock or water glass by opening throttle, enginemen will be governed by instructions in the preceding paragraph.

24. ON ENGINES, PASSENGER, FREIGHT AND ORE CARS EQUIPPED WITH ROLLER BEARINGS, EMPLOYES WILL BE GOVERNED AS FOLLOWS:

Roller bearing failures on cars or engines equipped with roller bearings in the journal boxes may be due to lack of oil. If the box is not blazing, the oil plug in the cover should be removed and engine or valve oil added. Oil must never be added to a box that is blazing. After the oil has been added and plug replaced, the train should proceed at reduced speed and care exercised until it is apparent that the box will run cool. If fire develops in roller bearing box on any equipment, it must be closely watched, train moved slowly, and Superintendent notified from first available point of communication, who will prescribe for the movement.

Some engines and cars equipped with roller bearings have heat indicators or stench bombs inserted in the housing of boxes which release a strong pungent odor in the event of excessive journal box temperatures. When this odor is detected train must be stopped at once and box located. Compare the temperature of this box with the other boxes on the same engine or car, check the oil level, and if there is no evidence of overheating, train may proceed, but if the box is overheating proceed only as instructed in the preceding paragraph.

Ore cars equipped with roller bearings have box cover painted orange, four inch white stripe full length of car beneath stencilled name, "GREAT NORTHERN," and "TIMKEN ROLLER BEARINGS" stencilled in black across center of white stripe. Cars or engines equipped with roller bearings must not be allowed to stand alone, even on level track, without brakes adequately applied.

25. OSCILLATING EMERGENCY RED HEADLIGHT will be immediately displayed by day or night when a train is disabled or stopped suddenly by an emergency application of air brakes or when engineer and conductor find it necessary to stop train due to some defect which might cause accident, over-running clearance point at meeting and waiting points, end of double track or junction.

Engineer of an approaching train observing display of emergency red headlight must stop before passing and be governed by conditions existing. If operating on adjacent track, ascertain and if safe for passage, then proceed at restricted speed until train is passed.

OSCILLATING EMERGENCY RED REAR END LIGHT is of two types—Automatic Control—Portable Manual Control—and except as otherwise provided, must be displayed by day or night each time train stops or is running at speed less than 18 MPH. Automatic Control type automatically functions in this manner. However, when train running at speed above 18 MPH and moving under circumstances in which it might be overtaken by another train or engine and during foggy and stormy weather, light may be operated manually with emergency switch and employes to afford other protection prescribed by rule.

THE USE OF EMERGENCY RED HEADLIGHT AND REAR END LIGHT DOES NOT IN ANY WAY RELIEVE ENGINEMEN AND TRAINMEN FROM RESPONSIBILITY OF COMPLYING WITH RULES 99 AND 102.

Emergency red rear end light must be extinguished; when standing at origin and terminus stations of train run; when switching being performed from rear; when on siding to be passed by another train; and, when another train operating on adjacent track is approaching from rear, but not until it is known such train is not on same track.

Portable light must be removed before coupling to rear of such car.

Oscillating white light on engines will be displayed in addition to standard headlight governed by Rules 17 and 17(B). In case of headlight failure it can be used as emergency headlight or as a focus light by push button control if desired.

Enginemen and trainmen on trains and engines equipped with oscillating emergency red lights must familiarize themselves with the operation of the lights.

26. Omitted.

27. Trains handling flat or skeleton cars loaded with logs must stop at appropriate locations immediately before passing over through-truss bridges or through tunnels and make thorough inspection of all cars of logs in their train, making certain train and lading are in safe condition before proceeding. Extra stops enroute will be made for this purpose when in the judgment of the conductor it is necessary.

Trainmen must maintain watch behind their trains for logs that may have rolled off cars and if main track is fouled take prompt action to protect trains.

On double track, conductors must notify train dispatcher when logs are to be handled and the log train must be at stop when being passed by other trains, except that when two trains handling logs are passing, either one should stop until the other train has pulled by whether on siding or double track.

On single track, trains handling logs must be at stop when meeting or being passed by passenger and freight trains, except when there are more cars than siding will hold, it is permissible for log train to pull by such trains at restricted speed.

Unless conditions require further speed restrictions, trains handling logs must not exceed 25 MPH.

FIRST SUBDIVISION

(Main Line)

1.	MAXIMUM PERMISSIBLE SPEED FOR T	TRAINS.	
	Between	Passenger	Freight
	Bend and Chemult	50 MPH	40 MPH

2. SPEED RESTRICTIONS.

3. RESTRICTED CLEARANCES.

Log car stake deflectors located just west of bridge 4.8 between Bend yard and Lava and on north side of track just west of Third Street crossing bridge, Oregon Trunk Ry, Bend, will not clear man on side of car.

 Water at Beal must not be used only in case of emergency. Westward trains take full tank of water at LaPine.

SECOND SUBDIVISION

(Main Line)

1.	MAXIMUM PERMISSIBLE SPEED FOR	TRAINS.	
	Between	Passenger	Freight
	South Klamath and Bieber	. 50 MPH	40 MPH

2. SPEED RESTRICTIONS.

TI DED MEDITIONS.		
	5 MPH	
Bieber, engines on wye tracks	5 MPH	
Between Home Signals of Interlocking at:	30 MPH	
Stronghold.		•

3. RESTRICTED CLEARANCES.

Bieber, Finney Spur, log jammers midway of tracks and only sufficient clearance to permit empty flats to pass under.

4. AUTOMATIC INTERLOCKINGS.

KLAMATH FALLS TERMINAL

1. RESTRICTED CLEARANCES.

Klamath Falls, following structures will not clear man on side of car:

Freight house, automobile platform. Lorenz warehouse, South Sixth Street.

Platform on Copco Spur.

Browskids on Klamath Basin Pine Mills and Kalpine log dumps. Draw span over Lake Ewauna.

Klamath Basin Pine Mills, Crane Shed track.

- Klamath Falls, tracks serving Weyerhaeuser Timber Company have rail braces applied between rails at certain locations which are protected by signs. These braces will not clear flangers of snow dozers.
- 3. Klamath Falls, draw bridge over Lake Ewauna.

 Trains and engines must stop before crossing draw span and be governed by indication of the color light type signal. Yellow light indicates that draw span is in safe position for rail traffic. Red light indicates that draw span is not in safe position for rail traffic. If the red light is displayed or in the absence of a light when draw span appears to be in proper position for rail traffic, movement may be made at restricted speed when preceded by a flagman across drawbridge.

SPEED TABLE

Time Min.	Per Mile Sec.	Miles Per Hour	Time Min.	Per Mile Sec.	Miles Per Hour
	40	90.0	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	12	50.0
	41	87.8	1	14	48.6
	42	87.8 85.7 83.7 81.8 80.0 78.3 76.6 75.0	1	16 18 20 22 24 26	47.4 46.1 45.0
	43	83.7	1	18	46.1
	44	81.8	1	20	45.0
	45	80.0	1	22	43.9
	46	78.3	1	24	42.9
	47 48	76.6	1	26	41.9
	48	75.0	1	28	40.9
	49	73.5	1	30	40.0
	50 51 52	72.0	1	33	38.7
	51	70.6	1	36	37.5
	52	69.2	1	39	36.4
	53 54	67.9	1	42	35.3
	54	66.6	1	45	212
	55	65.4	1	50	32.7
	56	64.2	1	50 55	31.3
	57	63.1	2	_	31.3 31.3 30.0 27.7 25.7 24.0 22.5
	58	62.0	2	10 20	27.7
	59	61.0	2	20	25.7
1	0	60.0	2	30	24.0
1	1	59.0 58.0 57.1 56.2 55.3	2	30 40	22.5
1	2	58.0	3		20.0
1	3	57.1	3	30	17.1
1	4	56.2	4		15.0
1	5	55.3	5		12.0
1	6	54.5	6	_	10.0
1 1 1 1 1 1 1 1	7	53.7	7	30	8.5
1	8	52.9	8		7.5
1	9	52.1	9	_	6.7
1	1 2 3 4 5 6 7 8 9	51.4	10		6.0

WATCH INSPECTORS

BUSINESS TRACKS NOT SHOWN AS STATIONS ON TIME TABLE.

Name	Location	Capacity Cars	Switch Opens	
First Subdivision. Prater Lumber Co. Spur Silica Brick and Tile	2.95 Miles west Lava 1.90 Miles east Chemult	4 3	East West	
Second Subdivision. Airport McKendree Kalina Suty Liskey Klamath Concrete Pipe Co. Hollenbeck Bieber Stockyards Finney Logging Co. Spur Caldwell Lumber Co.	1.70 Miles west South Klamath 2.42 Miles west Dehlinger 1.00 Miles west Malin 2.15 Miles west Stronghold 4.00 Miles west Stronghold 0.90 Miles west Stronghold 0.90 Miles east Scarface 2.22 Miles east Sieber 1.85 Miles east Bieber 1.54 Miles east Bieber	6 14 10 20 11 3 46 24 90 12	E & W E & W West E & W West East E & W E & W East West	

