

# COLLING DISTRICT

MP	STATION	STA.NO.
86.2	VASSAR	091
86.6	CARO JCT	
2.6	BANKSAND	203
9.4	WAHJAMEGA	209
13.5	CARO	214
22.1	COLLING	222

## SPECIAL INSTRUCTIONS COLLING DISTRICT

### RULE 93 — YARD LIMITS

VASSAR — MP 0.6

### RULE 98(A) — SWITCHES

Junction switch Caro Jct lined for Denmark District.

### SPEED LIMITS

	Lite	Fr't
District	50	40
Except		
MP0.6—0.8	10	10
Curves MP10—MP11.4	40	40
MP12.7—14.5	20	20

Maximum Gross Weight — 263,000 lbs—car

The Direction from Vassar to Colling is northward.

## SPECIAL INSTRUCTIONS — ALL DISTRICTS

### RULE 83 — REGISTER

Movements on all districts governed by train register located at Vassar.

Bulletin book located at Vassar

AIR BRAKE TRAINLINE PRESSURE 90 pounds

## EMERGENCY TELEPHONE NUMBERS

### Sheriff

Bay County 893-5505  
Saginaw Cty 771-2911  
Tuscola Cty 673-8161

### Office

Vassar 823-7661  
Vassar 823-8331  
Vassar (800) 292-1139

# TUSCOLA & SAGINAW TSB RAILWAY

## RAILWAY COMPANY

## TIMETABLE

## NO.

# 3

EFFECTIVE  
12:01 a.m. EST  
MARCH 1, 1981

FOR THE GOVERNMENT OF  
EMPLOYEES ONLY, WHO  
MUST ALSO BE GOVERNED  
BY CURRENT BOOK OF  
RULES.



## MILLINGTON DISTRICT

MP	STATION	STA.NO.
79.6	MILLINGTON	080
86.0	C&O CROSSING (Auto. Interlocking)	
86.2	VASSAR	086

### SPECIAL INSTRUCTIONS MILLINGTON DISTRICT

#### RULE 93 — YARD LIMITS

MP 85.5 to Vassar

#### RULE 329 — C&O CROSSING

If signals governing movements will not clear and no conflicting movements are evident, member of crew must go to box on relay shed and be governed by instructions posted in box.

Maximum Gross Weight — 263,000 lbs—car

SPEED LIMITS	Lite	Frt
District	50	40
Except		
MP 78.2—80.0	20	20
MP 85.5—86.0	Restricted	

The Direction from Millington to Vassar is northward.

## DENMARK DISTRICT

MP	STATION	STA.NO.
86.2	VASSAR	086
86.6	CARO JUNCTION	
91.0	DENMARK JUNCTION	091

### SPECIAL INSTRUCTIONS DENMARK DISTRICT

#### RULE 93 — YARD LIMITS

VASSAR — MP 86.7

#### RULE 98(A) — SWITCHES

Junction switches Caro Junction normally lined for Denmark District.

Junction switches Denmark Junction normally lined for Saginaw District.

#### RULE 103 — CROSSING SIGNALS

Crossing signals at M-46, MP 90.2, equipped with lunar flashing signal. If lunar marker fails to flash, stop and flag crossing.

Maximum Gross Weight — 263,000 lbs—car

SPEED LIMITS	Lite	Frt
District	50	40
Except		
MP 86.0—86.7	Restricted	

The Direction from Vassar to Denmark Junction is northward.

#### REGISTER REQUIREMENTS:

In addition to registering trains on Denmark District, trains must also register onto next district. Crew will be instructed as to whether they may register one way or round trip on Denmark District. If one way authority is granted, crew must register arrival at Denmark Jct by any available means of communication when clear of Denmark District and must not occupy Denmark District again without new registration.

**TUSCOLA &  
SAGINAW  
TSB AY**



## SAGINAW DISTRICT

MP	STATION	STA.NO.
91.0	DENMARK JUNCTION	091
4.6	HARGER	315

(9.4)

### SPECIAL INSTRUCTIONS SAGINAW DISTRICT

#### RULE 93 — YARD LIMITS

MP 5.2—MP 4.6

#### RULE 98(A) — SWITCHES

Junction switch Denmark Junction will be lined for Saginaw District.

Switches at Harger may be left lined as last used.

Maximum Gross Weight — 263,000 lbs—car

SPEED LIMIT	Lite	Frt
District	50	40

The Direction from Denmark Junction to Harger is northward.

#### USE OF TRACKS

GTW is authorized to operate over TSBY tracks within Harger yard limits, MP 5.2—MP 4.6

## MUNGER DISTRICT

MP	STATION	STA.NO.
91.0	DENMARK JUNCTION	091
94.5	REESE	094
94.6	C&O CROSSING	
100.6	MUNGER	101

### SPECIAL INSTRUCTIONS MUNGER DISTRICT

#### RULE 93 — YARD LIMITS

MP91.0—MP 91.5 and Munger—Saginaw Dist. connection.

#### RULE 98(A) — SWITCHES

Junction switch Denmark Junction will be lined for Saginaw District.

#### RULE 98 — CROSSING AT GRADE

At C&O Crossing, MP 94.6, be governed by target. TSBY trains and engines may cross C&O when target is vertical.

#### RULE 103 — CROSSING SIGNALS


At M-138 crossing, Munger, flashers have manual switch. Signals must be turned on 20 seconds before occupying crossing.

Maximum Gross Weight — 263,000 lbs—car

SPEED LIMITS	Lite	Frt
District	50	40
Except		
MP 91.0—91.5	Restricted	
MP 94.5—94.6	10	10

The Direction from Denmark Junction to Munger is northward.





**TUSCOLA & AGINAWAY**  
**TSB** AY