

SOUTHERN PACIFIC COMPANY

(PACIFIC LINES)

TIME TABLE

FOR THE

SACRAMENTO DIVISION

143

To Take Effect Sunday, May 31, 1931, at 12:01 A. M.

PACIFIC STANDARD TIME (120th MERIDIAN)

For the government and information of employes only.

F. L. BURCKHALTER,
General Manager

R. L. RUBY,
Superintendent of Transportation

L. U. MORRIS,
Assistant General Manager

W. L. HACK,
Superintendent



EASTWARD

Time Table No. 143

May 31, 1931

Capacity of sidings in car lengths	THIRD CLASS						FIRST CLASS						Distance from San Francisco
	280	276	270	308	306	262	22	28	20	534	24	10	
	Freight	Freight	Freight	Local Freight	Local Freight	Freight	Tahoe	San Francisco Overland Limited	Pacific Limited	Colfax MOTOR	Tonopah Express	Mail and Express	
Term. Yard BKTWOPY	Leave Daily	Leave Daily	Leave Daily	Lv. Mon. Wed. and Friday	Leave Daily Ex. Sunday	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	
	9.00PM	4.00PM	12.30PM		4.00AM	3.00AM	11.15PM	10.15PM	3.15PM	11.20AM		12.55AM	106.6
Yard P					4.15AM		f		f 3.25PM	s 11.30AM			110.6
65					See Page 3		11.32	10.31	See Page 3	See Page 3		1.11	115.5
84 WP	9.40	4.40	1.10		6.50AM	3.40	s 11.45	10.40	s 4.00PM	s 12.05PM		1.20	120.2
78 WP					7.50		s 11.57PM	10.48	s 4.10	s 12.20		1.29	124.2
68 P					8.20		12.08AM	10.57	4.20	f 12.35		1.38	129.1
P										f 12.42			131.4
78 PW					9.05		12.18	11.06	4.29	f 12.50		1.48	134.3
75 P					9.30		12.25	11.12	4.35	s 1.00		1.55	137.7
Yard YPWBK	10.30	5.50	2.00	7.00AM	9.55AM	4.30	s 12.50	11.25	s 4.50	s 1.10PM		2.10	141.7
80 P							1.04	11.37	5.04			2.23	146.0
125 PWOY	11.15PM	6.45	2.45	8.15		5.15	f 1.20	11.51PM	f 5.20			2.38	152.2
6 P Spur							s		s				154.1
4 P Spur							s		s				156.0
5 Spur PW				9.00			s 1.40	12.06AM	s 5.38			2.54	156.8
75 P				9.30			1.55	12.20	f 5.55			3.09	159.6
77 WP	12.33AM	9.00	5.00	10.00		7.30	2.10	12.33	6.10			3.24	164.8
Yard PTW				10.10			f		f				165.5
80 IPTW				11.50AM			f 2.30	12.50	f 6.30			3.42	166.6
82 PW	2.20	9.40	5.50	12.25PM		8.20	2.47	1.05	f 6.46			3.58	171.8
PWT				1.30			f 2.54		f 6.53				177.9
87 PW				2.05			3.10	1.22	7.05			4.17	180.3
P				2.30			f		f				185.5
79 PTWBI	3.00	11.00PM	7.00	3.05		9.30	s 3.30	1.37	s 7.20			4.34	190.4
PT				3.50									192.0
72 PW				4.05			3.50	1.57	7.40			4.54	196.3
Yard PWTYOBK	4.15	12.20AM	7.55	4.20PM		10.50AM	s 4.15	2.10	s 7.55		f 5.10		197.7
P							f 4.37	2.27	f 8.15			5.27	200.6
68 P							4.42	2.31	8.20			5.31	202.9
68 PW							f 4.52	2.39	f 8.30			5.39	208.0
No Siding WP													216.3
131 P	5.57	1.30	9.35			12.10PM	f 5.15	2.57	f 8.50			5.57	218.1
Yard P							s 5.40	3.20	s 9.10		8.25PM	s 6.20	222.4
Yard							6.00		9.25			6.30	228.5
Term. Yard OWTBK	7.15AM	2.35AM	10.45PM			1.05PM	s 6.10	3.35AM	s 9.35		s 8.35	s 6.45AM	232.4
	Arrive Daily	Arrive Daily	Arrive Daily	Ar. Mon. Wed. and Friday	Arrive Daily Ex. Sunday	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	234.9
	(10.15)	(10.35)	(10.15)	(9.20)	(5.55)	(10.05)	(7.00)	(5.20)	(6.25)	(1.50)	(0.15)	(5.50)	242.9
	13.38	12.95	13.38	7.12	5.93	13.60	19.59	25.70	21.37	19.15	13.20	23.50	245.5
													246.2

STATIONS

TO-R ROSEVILLE	4.0
TO ROOKLIN	4.9
LINCOLN AV., PENRYN	4.7
TO NEWCASTLE	4.0
AUBURN, NEVADA ST.	4.9
BOWMAN	2.3
CLIPPER GAP	2.9
EAST APPLGATE	3.4
N. E. MILLS	4.0
TO-R COLFAX	4.3
CAPE HORN	6.2
TO GOLD RUN	1.9
DUTCH FLAT	1.9
ALTA	0.8
TO TOWLE	2.8
AMERICAN	1.1
MIDAS	4.1
KNAPP	0.7
BLUE CANON	5.2
TO EMIGRANT GAP	6.1
CRYSTAL LAKE	2.4
TO CISCO	5.2
TROY	4.9
SODA SPRINGS	1.6
TO NORDEN	4.3
EDER	2.9
ANDOVER	2.3
STANFORD	5.1
TO-R TRUCKEE	8.3
BOCA	1.8
HINTON	4.3
TO FLORISTON	6.1
CALVADA	3.9
TO VERDI	10.5
RENO	2.6
SPARKS (PASS. STA.)	0.7
TO-R SPARKS (DSP. OFF.)	

Eastward inferior trains may run ahead of No. 24 Reno to Sparks.



ADDITIONAL FLAG STOPS TO RECEIVE OR DISCHARGE PASSENGERS

Train	At	Receive or Discharge	Passengers to (or beyond)	Passengers from (or beyond)
28	Any Station	Receive	Cheyenne	
20	Any Station	Receive	Ogden	
10	Any Station	Receive	Ogden	
22	Smart	Discharge		
22	Farad	Receive	Reno	
534	Union Mills	Receive		
	Roseville	Receive		
	High School	Receive		

ADDITIONAL FLAG STOPS TO RECEIVE OR DISCHARGE PASSENGERS

Train	At	Receive or Discharge	Passengers to (or beyond)	Passengers from (or beyond)
20	N. E. Mills			
	Magra, Forebay,			
	Yuba Pass,			
	Tamarack,			
	Union Mills,			
	Farad,			
	Fleish,			
	Lawton			

Additional Stations:

Lander, 139.0	Spruce, 187.8	Wickes, 221.5
Magra, 148.5	Polaris, 211.1	Farad, 224.7
Forebay, 163.0	Union Mills, 213.5	Fleish, 229.8
Smart, 173.3	Prosser Creek, 215.0	Mogul, 235.8
Yuba Pass, 176.1	Iceland, 220.9	Lawton, 237.1
Tamarack, 183.7		

Eastward trains using siding at Clipper Gap must back through crossover near east end.

.....Time over District
.....Average speed per hour

(137.1)

EASTWARD

Time Table No. 143

May 31, 1931

Capacity of sidings in car lengths.	THIRD CLASS						FIRST CLASS										Distance from San Francisco		
				230	224	222		18	54	16	22	28	20	534	42	44		10	8
				Local Freight	Local Freight	Freight		Cascade	Gerber Motor	West Coast	Tahoe	San Francisco Overland Limited	Pacific Limited	Colfax MOTOR	Tehama Motor	Dunsmuir Express		Mail and Express	Shasta
Term. Yard			Lv. Daily	Lv. Daily	Leave Daily		Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	
Yard IYP			Ex. Saturday	Ex. Sunday															
BKWOTYPI			6.45PM		8.40AM						10.35PM	9.35PM	2.35PM	10.40AM	10.35AM	1.20AM	12.15AM	88.8	
			7.00		8.55						10.42	9.42	2.42	f 10.48	10.42	1.27	12.22	91.8	
													f	f	f			93.5	
											10.48	9.47	2.47	f 10.55	10.47	1.32	12.27	94.9	
											10.59	9.58	2.58	s 11.07	s 10.58	1.43	12.38	102.8	
			7.30		10.00AM						s 11.08PM	s 10.07PM	s 3.07PM	s 11.20AM	s 11.08	s 1.55	s 12.47AM	106.6	
			9.10																
111 P															f 11.17	2.07		112.8	
134 PW			9.25												s 11.24	s 2.15		117.0	
38 P															f			121.0	
106 P			9.40													11.31	2.22	122.1	
32																s 11.35	f	124.8	
138 PW			10.10													s 11.40	s 2.35	128.1	
101 P			10.45PM													f 11.48AM	2.45	134.2	
																		139.8	
Yard BKIYOWP			12.10AM													s 12.01PM	s 2.55	140.8	
																		141.8	
112 WP																f 12.07	3.17	144.7	
43																f 12.12	3.22	147.7	
13																f		149.8	
54 IP			12.50													s 12.19	f 3.30	151.5	
108 P			1.10													s 12.30	s 3.40	158.0	
49 WP			1.30													s 12.37	s 3.50	161.4	
49 P			1.45													s 12.46	f 4.01	167.4	
97 P			2.00													f 12.52	f 4.09	171.5	
96 P			2.15													s 1.02	f 4.22	178.1	
Yard BKYWOP			2.30AM													s 1.15	s 4.35	184.2	
																4.55			
29 P																f 1.25	5.05	191.3	
122 P																f 1.34	5.09	193.6	
16																f 1.39		196.0	
130 WP																s 1.50	f 5.22	203.0	
15																f		204.6	
48 P																s 2.00	f 5.33	209.7	
120 PY				2.00AM				11.12PM	10.37PM	2.17PM						s 2.05PM	s 5.42	1.37AM	211.7
Term. Yard BKWOPY				2.10AM				s 11.19PM	s 10.45PM	s 2.25PM							s 5.50AM	s 1.45AM	213.8
			Ar. Daily	Ar. Daily	Arrive Daily		Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	
			Ex. Sunday	Ex. Sunday															

STATIONS

TO-R SACRAMENTO	3.0
ELVAS	1.7
SWANSTON	1.4
BENALI	7.9
ANTELOPE	3.8
TO-R ROSEVILLE	6.2
WHITNEY	4.2
TO LINCOLN	4.0
EWING	1.1
BROOK	2.7
SHERIDAN	3.3
TO WHEATLAND	6.1
OSTROM	5.6
DANTONI JOT.	1.0
TO-R MARYSVILLE	1.0
W. P. R. R. Crossing	2.9
BERG	3.0
LOMO	2.1
SUNSET	1.7
TO LIVE OAK	6.5
S. N. R. R. Crossing	6.5
TO GRIDLEY	3.4
BIGGS	6.0
TO RICHVALE	4.1
NELSON	6.6
TO DURHAM	6.1
S. N. R. R. Crossing	7.1
TO-R CHICO	7.1
NORD	2.3
ANITA	2.4
OANA	7.0
TO VINA	1.6
COPELAND	5.1
TO LOS MOLINOS	2.0
TO-R TEHAMA	2.1
TO-R GERBER	

A. B. S.

No. 3 Track

(7.45) (0.10) (1.20) (0.07) (0.08) (0.08) (0.33) (0.32) (0.32) (0.40) (3.30) (4.30) (0.32) (0.08) Time over District
 12.31 12.60 13.35 18.00 15.75 15.75 32.36 33.38 33.38 26.70 35.71 27.77 33.38 15.75 Average speed per hour

Schedule time and train orders will apply at the Junction Switch at Tehama.

Eastward trains, when taking siding at Marysville, will use crossover just west of west water column.

ADDITIONAL FLAG STOPS TO RECEIVE OR DISCHARGE PASSENGERS				
Train	At	Receive or Discharge	Passengers to (or beyond)	Passengers from (or beyond)
20 } 534 }	Walerga			
42	Gimbal			
16	Bohemia			
8	Any Station	Receive	Klamath Falls	
	Any Station	Receive	Black Butte	

Additional Stations:		
Walerga, 99.4	Sullivan, 146.4	Gimbal, 189.1
Clayton, 118.4	Fagan, 155.9	Soto, 198.3
Jester, 126.0	Riceton, 164.1	Ensign, 207.1
Rupert Spur, 138.9	Faulkner, 181.9	Bohemia, 208.0
Binney Junction Tower, 141.8		

Time Table No. 143

May 31, 1931

WESTWARD

FIRST CLASS

THIRD CLASS

STATIONS

TO-R SACRAMENTO	125.0
ELVAS	122.0
SWANSTON	120.3
BENALI	118.9
ANTELOPE	111.0
TO-R ROSEVILLE	107.2
WHITNEY	101.0
TO LINCOLN	96.8
EWING	92.8
BROCK	91.7
SHERIDAN	89.0
TO WHEATLAND	85.7
OSTROM	79.6
DANTONI JOT.	74.0
TO-R MARYSVILLE	73.0
W. P. R. R. Crossing	72.0
BERG	69.1
LOMO	66.1
SUNSET	64.0
TO LIVE OAK	62.3
TO GRIDLEY	55.8
TO BIGGS	52.4
TO RICHVALE	46.4
NELSON	42.3
TO DURHAM	35.7
TO-R OHICO	29.6
NORD	22.5
ANITA	20.2
CANA	17.8
TO VINA	10.8
COPELAND	9.2
TO LOS MOLINOS	4.1
TO-R TEHAMA	2.1
TO-R GERBER	0.0

Distance from Carbur

STATIONS	Distance from Carbur	FIRST CLASS										THIRD CLASS							
		21	9	27	7	53	535	19	15	17	43	237	239	231	241	229	243	319	
		Tahoe	Fast Mail	San Fran. Overland Limited	Shasta	Sacto Motor	Sacto MOTOR	Pacific Limited	West Coast	Cascade	Dunsmuir Express	Freight	Freight	Local Freight	Freight	Local Freight	Local Freight	Freight	
TO-R SACRAMENTO	125.0	4.00AM	4.35AM	5.20AM		8.55AM	1.20PM	5.15PM		1.50AM									
ELVAS	122.0	3.51	4.26	5.11		8.45	1.12	5.07		1.41							5.30PM		
SWANSTON	120.3																5.20		
BENALI	118.9	3.46	4.21	5.06		8.38	1.06	4.52		1.36									
ANTELOPE	111.0	3.35	4.10	4.55		8.26	12.55	4.41		1.25									
TO-R ROSEVILLE	107.2	3.25AM	4.00AM	4.45AM		8.15AM	12.45PM	4.30		1.15									
WHITNEY	101.0							4.18		1.03									
TO LINCOLN	96.8							4.10		12.55									
EWING	92.8																		
BROCK	91.7							4.01		12.42									
SHERIDAN	89.0							3.56											
TO WHEATLAND	85.7							3.50		12.32									
OSTROM	79.6							3.40		12.21									
DANTONI JOT.	74.0																		
TO-R MARYSVILLE	73.0							3.30		12.10AM									
W. P. R. R. Crossing	72.0																		
BERG	69.1							3.10		11.49PM									
LOMO	66.1							3.06		11.45									
SUNSET	64.0																		
TO LIVE OAK	62.3							3.00		11.40									
TO GRIDLEY	55.8							2.50		11.30									
TO BIGGS	52.4							2.40		11.20									
TO RICHVALE	46.4							2.30		11.13									
NELSON	42.3							2.23		11.07									
TO DURHAM	35.7							2.12		10.56									
TO-R OHICO	29.6							2.00		10.45									
NORD	22.5							1.39		10.25									
ANITA	20.2							1.34		10.20									
CANA	17.8							1.30		10.15									
TO VINA	10.8							1.20		10.04									
COPELAND	9.2																		
TO LOS MOLINOS	4.1							1.10		9.52									
TO-R TEHAMA	2.1				4.07AM	6.16AM		1.05	1.52PM	9.47									
TO-R GERBER	0.0				4.00AM	6.10AM		12.58PM	1.45PM	9.40PM									

Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Lv. Daily Ex. Sun.	Leave Daily	Lv. Daily Ex. Sun.	Leave Daily	Leave Daily
-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	--------------------	-------------	--------------------	-------------	-------------

Time over District	(0.35)	(0.35)	(0.35)	(0.07)	(0.06)	(0.40)	(0.35)	(4.17)	(0.07)	(4.10)	(5.45)	(5.40)	(0.10)	(6.00)	(6.30)	(6.00)	(0.50)
Average speed per hour	30.51	30.51	30.51	18.00	21.00	26.70	30.51	29.11	18.00	30.00	18.64	18.72	12.60	17.86	11.94	17.86	21.36

Schedule time and train orders will apply at the Junction Switch at Tehama.

Additional Stations:

Walerga, 99.4	Riceton, 164.1
Clayton, 118.4	Faulkner, 181.9
Jester, 126.0	Gimbal, 189.1
Rupert Spur, 138.9	Soto, 198.3
Binney Junction Tower, 141.8	Ensign, 207.1
Sullivan, 146.4	Bohemia, 208.0
Fagan, 155.9	

ADDITIONAL FLAG STOPS TO RECEIVE OR DISCHARGE PASSENGERS

Train	At	Receive or Discharge	Passengers to (or beyond)	Passengers from (or beyond)
43	Any Station	Discharge		Lincoln
15				
535				
7	Walerga	Discharge		Black Butte
17				

EASTWARD

Capacity of sidings in car lengths	THIRD CLASS				SECOND CLASS	FIRST CLASS				Distance from San Francisco
	224	232	252	128	8	18	54	16		
	Local Freight	Mixed	Local Freight	Colusa Branch Mixed	Shasta	Cascade	Gerber Motor	West Coast		
	Leave Daily Ex. Saturday	Leave Daily Ex. Sunday	Leave Daily Ex. Sunday	Leave Daily Ex. Sunday	Leave Daily	Leave Daily	Leave Daily	Leave Daily		
Terminal Yard IWYP	7.00 PM	4.00 AM	3.45 AM		11.00 PM	8.54 PM	7.20 PM	11.05 AM	75.6	
100 P	7.15				11.07	9.01	f 7.29	11.13	80.7	
17							f		88.2	
BKIPW Yard 107	7.35	4.20 AM	4.15		f 11.18	9.08	s 7.40	s 11.25	84.9	
26 P	7.50		5.10		11.25	9.14	s 7.50	11.33	89.9	
39 P					11.32	9.21	s 8.00	11.41	95.8	
17 P							f		98.0	
36 WP	8.30		5.59		11.40	9.29	s 8.12	11.50	103.2	
40 P							f 8.17		106.4	
118 119 YP					11.46	9.35	f	11.57 AM	108.3	
44 P	9.15		6.50		11.53	9.41	s 8.30	s 12.05 PM	118.5	
30 PW	9.30				11.58 PM	9.46	f 8.36	12.12	117.6	
11							f		118.5	
50 P			8.08		12.06 AM	9.53	s 8.48	s 12.23	124.2	
45 P	9.58		8.55		12.12	9.58	f 8.55	12.30	129.1	
59 WP					12.16	10.02	s 9.02	s 12.37	133.0	
39 P	10.20		9.20		12.22	10.08	f 9.09	12.44	138.3	
34					12.27	10.13	f 9.15	12.50	142.1	
31 P							f 9.19	12.54	144.3	
64 BKWOYP	11.00 PM		10.00 AM		f 12.40	10.25	s 9.35	s 1.10	149.9	
10							f		153.2	
44 P	12.01 AM				12.49	10.33	f 9.45	1.20	156.8	
50					12.53	10.37	f 9.50	1.25	160.7	
33 P							f		162.0	
41 KPW	12.50		4.40 AM		f 1.02	10.43	s 10.00	s 1.35	165.4	
39 PY			4.50 AM				f		167.0	
11							f		169.0	
26 P					1.14	10.52	f 10.11	1.47	173.4	
47 P	1.24				1.24	10.59	s 10.20	s 2.03	178.5	
44 P					1.29	11.04	f 10.27	2.09	181.6	
120 YP	2.00 AM				1.37 AM	11.12 PM	s 10.37 PM	s 2.17 PM	186.3	
	Arrive Daily Ex. Sunday	Arrive Daily Ex. Sunday	Arrive Daily Ex. Sunday	Arrive Daily Ex. Sunday	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily		

Time Table No. 143

May 31, 1931

STATIONS

TO-R DAVIS	5.1	110.7	s 6.45 AM	s 9.45 AM	s 4.15 PM	s 5.20 PM
MERRITT	2.5	105.6	6.35	f 9.35	4.08	f 5.11
MULLEN	1.7	103.1		f		f
TO-R WOODLAND	5.0	101.4	s 6.28	s 9.25	4.03	s 5.05
S. N. R. R. Crossing.						
TO YOLO	5.9	96.4	6.16	s 9.12	3.56	f 4.55
ZAMORA	2.2	90.5	6.08	s 9.01	3.49	f 4.48
BRETONA	5.2	88.8		f		f
TO DUNNIGAN	3.2	83.1	5.59	s 8.48	3.40	f 4.39
HERSHEY	1.9	79.9		f		f
HARRINGTON	5.2	78.0	5.53	s 8.36	3.34	f 4.31
TO ARBUCKLE	4.1	72.8	5.47	s 8.25	3.28	s 4.24
GENEVRA	0.9	68.7	5.41	f 8.17	3.23	f 4.16
MACY	5.7	67.8		f		f
TO WILLIAMS	4.9	62.1	5.33	s 8.08	3.15	s 4.07
COERTENA	3.6	57.2	5.27	f 7.58	3.09	f 3.57
TO MAXWELL	5.3	53.8	5.22	s 7.52	3.04	s 3.51
DELAVAN	3.8	48.0	5.15	f 7.42	2.57	f 3.42
NORMAN	2.2	44.2		f		f
LOGANDALE	5.6	42.0	5.07	f 7.33	2.49	f 3.33
TO-R WILLOWS	3.3	36.4	s 5.00	s 7.25	2.42	s 3.25
LYMAN	3.6	33.1		f		f
TO ARTOIS	3.9	29.5	4.49	s 7.09	2.33	f 3.11
GRAPIT	1.3	25.6	4.45	f 7.02	2.28	f 3.05
GREENWOOD	3.4	24.3		f		f
TO-R ORLAND	1.6	20.9	4.37	s 6.55	2.22	s 2.58
WYO	2.0	19.3	4.33	f 6.48	2.19	f
MALTON	4.4	17.3		f		f
KIRKWOOD	5.1	12.9	4.25	f 6.38	2.10	f 2.40
TO CORNING	3.1	7.8	4.19	s 6.30	2.03	s 2.32
RICHFIELD	4.7	4.7	4.14	s 6.23	1.58	f 2.25
TO-R TEHAMA		0.0	4.07 AM	6.16 AM	1.52 PM	2.17 PM

A. B. S.

(110.7)

FIRST CLASS

SECOND CLASS

THIRD CLASS

Distance from Tehama	7	53	17	41	131	233	251	231
	Shasta	Sacramento Passenger	Cascade	Sacramento Motor	Colusa Branch MIXED	Mixed	Local Freight	Local Freight
	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily Ex. Sunday	Arrive Daily Ex. Sunday	Arrive Daily Ex. Sunday	Arrive Daily Ex. Sunday
	s 6.45 AM	s 9.45 AM	s 4.15 PM	s 5.20 PM		12.10 PM	1.40 PM	5.00 PM
	6.35	f 9.35	4.08	f 5.11			1.25	4.45
		f		f				
	s 6.28	s 9.25	4.03	s 5.05		11.40 AM	1.10	4.30
	6.16	s 9.12	3.56	f 4.55			12.15 PM	4.10
	6.08	s 9.01	3.49	f 4.48			11.41 AM	3.49
		f		f				
	5.59	s 8.48	3.40	f 4.39				3.20
		f		f				
	5.53	s 8.36	3.34	f 4.31			10.10	
		s 8.25	3.28	s 4.24			9.50	2.50
	5.47	f 8.17	3.23	f 4.16				2.35
	5.41	f		f				
	5.33	s 8.08	3.15	s 4.07			9.20	2.20
	5.27	f 7.58	3.09	f 3.57			8.55	
	5.22	s 7.52	3.04	s 3.51			7.52	1.55
	5.15	f 7.42	2.57	f 3.42			7.15	
		f		f				
	5.07	f 7.33	2.49	f 3.33				
	s 5.00	s 7.25	2.42	s 3.25			6.40 AM	1.10 PM
		f		f				
	4.49	s 7.09	2.33	f 3.11				
	4.45	f 7.02	2.28	f 3.05				
		f		f				
	4.37	s 6.55	2.22	s 2.58				11.55 AM
	4.33	f 6.48	2.19	f				
		f		f				
	4.25	f 6.38	2.10	f 2.40				
	4.19	s 6.30	2.03	s 2.32				11.15
	4.14	s 6.23	1.58	f 2.25				
	4.07 AM	6.16 AM	1.52 PM	2.17 PM				10.40 AM
	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily Ex. Sunday	Leave Daily Ex. Sunday	Leave Daily Ex. Sunday	Leave Daily Ex. Sunday

(7.00) 15.81 (0.20) 27.90 (6.15) 11.89 (0.10) 9.60

(2.37) 42.30 (2.18) 48.85 (3.17) 33.72 (3.12) 34.60

Time over District (2.38) 42.04 (3.29) 31.78 (2.23) 46.45 (3.03) 36.29 (0.05) 19.20 (0.30) 19.24 (7.00) 10.61 (6.20) 17.48

Average speed per hour

Schedule time and train orders will apply at the Junction Switch at Tehama.
 At Woodland, the Woodland-Oroville main track originates at east switch of siding, located 150 feet east of cattle guard 85-A.
 Trains to and from Knights Landing must use Woodland siding.

West end of Harrington siding west of crossover is the westward siding and east end east of crossover is the eastward siding; Junction switch located at crossover.
 Track 2 of the two tracks paralleling the main track at Wyo is the siding.

Additional Stations: { Elvaton 89.2, Dufour 92.1, Ronda 93.7, Delphos 126.8, Riz 146.0.

ADDITIONAL FLAG STOPS TO RECEIVE OR DISCHARGE PASSENGERS				
Train	At	Receive or Discharge	Passengers to (or beyond)	Passengers from (or beyond)
16	Any Station	Receive	Klamath Falls	Davis or West
18	Harrington	Discharge	Klamath Falls, or beyond	Davis or West
	Any Station	Receive		
54	Elvaton	Receive or Discharge	{ Points train is scheduled to stop.	Black Butte
53	Dufour			
41	Ronda			
7	Orland			
7	Williams	Receive		
7	Any Station	Discharge	Black Butte	
8	Any Station	Receive		

EASTWARD

Capacity of sidings in car lengths.	THIRD CLASS	SECOND CLASS	FIRST CLASS	Distance from San Francisco
	232 Mixed	234 Oroville Mixed		
IBKPW Yard 107	Lv. Daily Ex. Sunday 4.20 AM	Leave Daily Ex. Sunday		84.9
16	f			87.2
23	f			87.7
19	f			90.1
26	P s 5.00			94.0
	P f			96.6
2	Spur f			97.4
65	f			105.2
20	f 5.35			107.5
18	W f			111.7
8	f			112.7
31	f			116.1
43	f			118.0
19	PI s 6.15			120.7
Yard				122.1
WPYOIBK	s 6.30 AM	7.30 AM		122.7
19		s		131.0
15	P	s 8.05		135.3
14		f		141.9
35	P	s 8.35		142.8
27		f		145.3
Yard WTPK		s 9.00 AM		148.2
	Arrive Daily Ex. Sunday	Arrive Daily Ex. Sunday		

Time Table No. 143

May 31, 1931

Knights Landing and Oroville Branches

STATIONS

TO-R	STATION	Distance from Oroville
TO-R	WOODLAND	63.3
	GARIO	61.0
	PEART	60.6
	CURTIS	58.1
TO	KNIGHTS LANDING	54.2
R	GRACE & P. Crossing	51.7
	BYPASS	50.8
	OHANDLER	43.0
	MARCOUSE	40.7
	TUDOR	36.5
	ABBOTT	35.5
	OSWALD	32.1
	BOGUE	30.2
	YUBA CITY & N. R. R. Crossing	27.5
	E STREET, MARYSVILLE	26.1
TO-R	MARYSVILLE	25.5
	RAMIREZ	17.2
	HONOUT	12.9
	HEARST	6.3
	PALERMO	5.4
	VILLA VERONA	2.9
TO-R	OROVILLE	0.0

WESTWARD

Capacity of Sidings in Car Lengths	FIRST CLASS	THIRD CLASS	Distance from San Francisco
		233 Mixed 235 Marysville Mixed	
WOTYPBK		Ar. Daily Ex. Sunday s 11.30 AM	88.8
		f	89.3
		f	89.6
		f	89.7
		f	90.2
		f	90.8
	Via Elvas	s 11.00	92.0
		f	92.3
89	WP	s 3.17	94.7
29		s 3.20	95.9
9		f	97.5
81		f 3.25	98.9
8		f	100.7
22		s 3.31	101.6
35		f 3.35	103.4
35	P	s 3.38	104.4
18		f 3.44	107.4
31		f	108.3
25		s 3.50	110.1
25	WY	s 3.55	111.1
9		f 4.13	118.0
15		f 4.34	126.1
6		f 4.50	131.4
27	W	s 5.05	136.9
32		s 5.23	142.7
23		s 5.31	145.0
Yard WTK		s 5.40 PM	148.7
	Arrive Mon., Wed., Fri.	Arrive Daily	
		Lv. Daily Ex. Sunday	
		Leave Daily Ex. Sunday	

EASTWARD

Capacity of Sidings in Car Lengths	THIRD CLASS	FIRST CLASS	Distance from San Francisco
	264 Local Freight	162 Placerville Motor	
WOTYPBK	Leave Mon., Wed., Fri. 5.30 AM	Leave Daily 3.00 PM	88.8
			89.3
			89.6
			89.7
			90.2
			90.8
	Via Elvas	Via Elvas	92.0
			92.3
89	WP	s 3.17	94.7
29		s 3.20	95.9
9		f	97.5
81		f 3.25	98.9
8		f	100.7
22		s 3.31	101.6
35		f 3.35	103.4
35	P	s 3.38	104.4
18		f 3.44	107.4
31		f	108.3
25		s 3.50	110.1
25	WY	s 3.55	111.1
9		f 4.13	118.0
15		f 4.34	126.1
6		f 4.50	131.4
27	W	s 5.05	136.9
32		s 5.23	142.7
23		s 5.31	145.0
Yard WTK		s 5.40 PM	148.7
	Arrive Mon., Wed., Fri.	Arrive Daily	

Time Table No. 143

May 31, 1931

Placerville Branch

STATIONS

TO-R	STATION	Distance from Placerville	FIRST CLASS 161 Sacramento Motor	THIRD CLASS 265 Local Freight
TO-R	SACRAMENTO	59.9	s 9.20 AM	12.15 PM
	S. N. R. R. Crossing	59.4		
	JCT. SWITCH, R STREET	59.1		
	S. N. R. R. Crossing	59.0		
	Western Pacific Crossing	58.5		
	Central California Traction Crossing	57.9		
	Western Pacific Crossing	56.7	Via Elvas	Via Elvas
	S. N. R. R. Crossing	56.4		
	HOMESTEAD	54.0	s 9.03	11.50 AM
R	BRIGHTON	52.8	s 9.01	11.40
	PERKINS	51.2	f	
	MANLOVE	49.8	f 8.54	11.25
	MAYHEW	48.0	f	
	ROUTIER	47.1	s 8.48	11.15
TO	MILLS	45.3	f 8.44	11.05
	MATHER	44.3	s 8.42	11.00
R	CITRUS	41.3	s 8.27	11.00
	NIMBUS	40.4	8.20	10.15
	ALDER CREEK	38.6	f 8.17	
	NATOMA	37.6	s 8.13	10.00
TO-R	FOLSOM	30.7	s 8.10	9.50
	WHITE ROCK	22.6	f 7.54	9.10
	LATROBE	17.3	f 7.36	8.35
	DUGAN	11.8	f 7.24	8.10
	SHINGLE SPRINGS	6.0	s 7.10	7.45
	EL DORADO	3.7	s 6.55	7.20
TO	DIAMOND SPRINGS	0.0	s 6.50	7.05
TO-R	PLACERVILLE		6.40 AM	6.50 AM

WESTWARD 7

(2.10) 17.45	(1.30) 17.00	Time over District	(2.00) 18.90	(1.31) 17.00
		Average Speed per hour		

At Woodland, the Woodland-Oroville main track ends at east switch to siding, located 150 feet east of cattle guard 85-A.

Trains to and from Woodland-Oroville line will use Woodland siding. Normal position of east switch is for Woodland-Oroville line.

Normal position of switch of the Woodland-Oroville main track at Marysville is for Yuba City.

EASTWARD

Capacity of Sidings in Car Lengths	THIRD CLASS	FIRST CLASS	Distance from San Francisco
		164 Fair Oaks Motor	
35	P	Leave Daily 8.28 AM	104.4
Yard	15 P	s 8.33 AM	106.3
		Arrive Daily	

Time Table No. 143

May 31, 1931

Fair Oaks Branch

STATIONS

TO-R	STATION	Distance from Fair Oaks	SECOND CLASS 165 Fair Oaks Motor	FOURTH CLASS
R	CITRUS	1.9	s 8.41 AM	
TO-R	FAIR OAKS	0.0	8.35 AM	

(0.06) 22.86	(0.06) 19.00	Time over District	(0.06) 19.00	
		Average speed per hour		

Additional Stations:—

- Laugenour, 89.4
- Saccarus, 89.7
- Coranco, 92.4
- Cunard, 96.1
- Vernon, 98.7
- Coulter, 101.8
- Lee, 102.7
- Wilson, 109.2
- Messick, 114.5
- Binney Junction Tower, 122.7
- Mello, 126.5
- Mission, 131.8
- Coxlane, 139.2
- Baggett, 146.5

Additional Flag Stops to Receive or Discharge Passengers:—

- Nos. 232, 233, 234, and 235
- Laugenour
- Saccarus
- Coranco
- Cunard
- Vernon
- Coulter
- Lee
- Wilson
- Messick
- Mello
- Mission
- Coxlane and Baggett.

Additional Stations:—

- Ramona, 95.5
- Brown, 97.0
- Alden, 98.0
- Bradshaw, 99.8
- Boyd, 100.3
- Soudan, 103.7
- Salsbury, 105.2
- Nagle, 111.3
- Prattrock, 111.4
- Malby, 119.4
- Harvey, 121.7
- Cothrin, 123.1
- Flonellis, 127.6
- Swift, 127.8
- Brela, 128.1
- Brandon, 129.8
- Bullard, 131.7
- Bennett, 134.0
- Cummings, 140.4
- Apex, 147.7

Additional Flag Stops to Receive or Discharge Passengers:—

- Nos. 161 and 162 Soudan
- Brown
- Malby
- Harvey
- Bradshaw
- Salsbury
- Alden
- Prattrock
- Ramona
- Cothrin
- Flonellis
- Brela
- Brandon
- Bullard
- Bennett
- Cummings and Apex.

SPECIAL INSTRUCTIONS



RULE 2. The following are designated Watch Inspectors:
 San Francisco.....S. A. Pope, Manager of Time Service, 65 Market St.
 Sacramento, H. T. Harger, 1022 "K" St. Marysville.....Frank G. Mooney
 Roseville.....H. T. Harger Chico.....J. R. Dupen
 Sparks.....Adams & Davidson Co. Willows.....Robt. E. Boyd
 Oroville.....O. W. Halstead Placerville.....Leo C. Burger

RULES 10 (G) and 10 (H). On double track between Sparks and east end of tunnel No. 41, signals, except fixed signals used by trackmen, will be placed on right of track in direction of movement.

RULE 14 (d). As specified below four long one short sounds of whistle will be indication that flagman may return from west as prescribed by Rule 99.
 Tehama on Davis-Tehama Line.

RULE 14 (e). As specified below six long sounds of whistle will be indication that flagman may return from east as prescribed by Rule 99.
 Roseville on Roseville-Gerber Line.
 Brighton on Sacramento-Placerville Line.
 Davis on Davis-Tehama Line.
 Oroville on Swayne Lumber Co. Logging Road.

RULE 19. Markers must be kept lighted on No. 2 track between Rocklin and Colfax and on Nos. 1 and 2 tracks Knapp and Truckee, at all hours.

RULE S-72. Westward trains are superior to trains of the same class in the opposite direction.

RULE D-71 and RULE 72. Trains between Elvas and Sacramento, and between Elvas and Brighton, and eastward trains via Elvas from Stockton Division to Roseville will move irrespective of time-table superiority when moving with the current of traffic.

RULE 83 (A). At the following stations, only the trains indicated will register.
 Chico } Trains originating and terminating.
 Willows }
 Harrington }

Sacramento, 12th St.—Trains originating and terminating and eastward freight trains from Western Division.

RULE 83 (B). At open train-order offices trains may register by ticket as follows:
 Nos. 7, 8, 16, 17 and 18 at Woodland, Orland and Tehama.
 Nos. 43, 44 and 15 at Tehama.
 First-class trains Sacramento 12th Street, Roseville Yard Office, Colfax and Truckee.

First-class trains on Roseville-Gerber line, register at Roseville Passenger Station.

Folsom.—Register at Junction Switch, Folsom. Trains that are required to go to Folsom or trains originating or terminating at Folsom will on return to the Junction register the same information as shown on register at station.

RULE 83 (D). Trains must obtain a clearance before leaving Marysville, Colfax, and Truckee, also at Folsom and Fair Oaks when such stations are open train-order offices. Extra trains not routed via Folsom or Fair Oaks will not go to or obtain a clearance at those stations.

RULE 93. YARD LIMITS.—Are defined by yard limit signs at the following stations:
 Truckee, Colfax, Willows, Chico, Oroville, Isleton.
 Blue Canon, Woodland, Orland, Folsom, Walnut Grove, Placerville.

SACRAMENTO YARD.—Between a point 1,000 feet east of Benali to a point ¼ mile west of west switch Mikon to a point 1,000 feet west of west switch at Brighton on Stockton Line via Elvas, to a point 1,000 feet east of east switch at Brighton on Placerville Line via Homestead, to a point ¾ miles east of Junction switch, R Street, on Walnut Grove Line.

ROSEVILLE YARD.—Between a point 4,000 feet west of west switch Antelope, to a point one mile east of junction switch on Roseville-Gerber Line, to a point 1,000 feet east of east switch at Rocklin, on No. 4 track and to a point 1,000 feet east of crossover on Nos. 1 and 2 tracks.

TAHOE YARD.—From a point 1,000 feet west of west switch Moss Hills.

MARYSVILLE YARD.—Between a point 1,000 feet west of Rupert Spur, and including Dantoni Branch, to a point 1,000 feet east of 143-D, to a point 4,100 feet east of Binney Jet. switch on Woodland-Oroville Line, to a point 1,000 feet west of west switch of cannery track at Yuba City. This includes E and A Street cut-off.

GERBER YARD (Shasta Div.).—Between a point 80 feet east of east switch of house track at Tehama and a point on Shasta Division east of Gerber.

SPARKS YARD (Salt Lake Div.).—Between a point one and one-half miles west of Reno to a point 2,700 feet east of east switch at Sparks.

RULE D 97 (A). On double track between Sacramento and Sparks, trains may run extra moving with the current of traffic without running orders, but must obtain clearance before commencement of trip, if an operator is on duty.

DRAWBRIDGES AND RAILROAD CROSSINGS NOT INTERLOCKED

RULE 98.
 Sacramento River at Knights Landing. Trains must not stop on drawbridge at Knights Landing.
 Sacramento River at Tehama.

Southern Pacific trains will approach Western Pacific R. R. crossing at Front and R Streets, Sacramento, with caution, expecting to find crossing occupied. Southern Pacific yard engines will stop and ascertain that crossing is clear before proceeding.

Southern Pacific and Western Pacific trains and yard engines must ascertain that all switch and industry track crossings in the vicinity of Front and R Streets are clear before using.

Trains will stop within two hundred feet of Sacramento Northern R. R. crossing Front and R Streets Sacramento before crossing.

Movement of trains, engines or cars in switching over crossing of the Southern Pacific tracks and the electric lines at Front and M Streets, Sacramento, will be governed as follows:

Southern Pacific trains moving on Front Street, Sacramento and Southern Pacific yard engines switching on Front Street will stop before reaching the crossing at Front and M Streets and will proceed on hand signals from flagmen on the ground in the center of the crossing, flagman using a green flag by day and a green light by night.

Sacramento Northern trains and San Francisco & Sacramento Railroad trains will stop before reaching the crossing and will proceed on signal from the flagman in the center of the crossing flagman using a yellow flag by day and a yellow light by night.

Trains and engines on "R" Street, Sacramento, will stop before crossing Sacramento Northern tracks at 31st and "R" Streets.

RULE D-152. Does not apply between 15th Street and Sacramento River Bridge, Sacramento, between Yosemite Street first road crossing east of Roseville passenger station and cut-off at Dry Creek west of Roseville.

TRAIN AND AIR INSPECTION.

On grades retaining valves will be used as follows:

Norden to Truckee
 One retaining valve for every 120 Ms in train.

Norden to Yuba Pass
 One retaining valve for every 140 Ms in train.

Yuba Pass to Loomis
 One retaining valve for every 100 Ms in train.

Stirling City to Mile Post 188
 One retaining valve for every 80 Ms in train.

Placerville Branch
 From MP-148 to MP-146 and from MP-145 to MP-138 one retaining valve for every 120 Ms in train.
 MP-136 to MP-130 and from MP-129 to MP-122, one retaining valve for every 140 Ms in train.

From MP-117 to MP-112, one retaining valve for every 150 Ms in train.

When passenger train has stopped, engineer will release air brakes and retainers must be turned down and engineer notified by one sound of air signal.

Where retainers are used the rate of speed of freight trains on any grade of over one per cent (1%) will not exceed 25 miles per hour, and on grades of this character, MORE THAN FIVE MILES LONG, FOR THE FIRST FIVE MILES THE TIME CONSUMED IN TRAVELING ANY ONE MILE SHALL NOT BE LESS THAN THREE MINUTES. This will not be authority to exceed specified speed restrictions.

Freight trains and light engines, not equipped with tire coolers, except Mallets, on descending grade will make a stop of ten minutes between switches at the following stations to permit wheels to cool, trainmen will make a careful inspection of all cars, and engineers inspect engine:

Andover: (During storms inspection will be made in shed at Andover.)	Colfax.
Truckee, Five minutes.	Flint (except westward freight trains that stop at Auburn, will inspect at Auburn instead of Flint.)
Summit. On No. 1 track.	Latrobe.
Norden. On No. 2 track.	Paradise.
Troy.	Doon.
Yuba Pass.	Crouch.
Midas.	
Gold Run.	

Passenger trains stop at Paradise five minutes to cool wheels.

Freight trains on descending grade, stop between switches at Knapp, five minutes to cool wheels.

Mallet engines running light on descending grades will make stop of sufficient length of time to inspect engine.

In valley open territory, freight trains will operate from one water stop to another without making stop for inspection, providing next stop is not greater than 50 miles apart.

Light engines descending grade that are equipped with tire coolers will stop at Emigrant Gap, Truckee, and Colfax for inspection.

At all points where freight trains stop for inspection between Roseville and Sparks, engineers will drain water from main reservoirs on engines.

Westward passenger trains on No. 1 Track will make running test just before entering tunnel No. 6.

Standing air brake tests must be made at:
 Summit.....Westward freight trains.
 Norden.....Eastward and westward freight trains.
 Stirling City.....All trains.
 Placerville.....All trains.

This test must be made immediately before departure from Norden and Summit and engineers and conductors are responsible for brake pipe pressure throughout the train.

Westward freight trains will make brake pipe test at Truckee and Summit.

The tonnage of freight trains between Stirling City and Chico must not exceed 80 M's per operative brake.

The tonnage of freight trains between Placerville and Folsom must not exceed 100 M's per operative brake.

The tonnage of freight trains between Summit and Loomis, must not exceed 100 M's per operative brake.

The tonnage of freight trains between Norden and Truckee must not exceed 120 M's per operative brake.

Emergency hose must be used on freight trains between Sparks and Roseville. Emergency hose will be handled by carmen at Sparks and Roseville, but must be applied and removed when necessary by trainmen at intermediate stations.

AUTOMATIC BLOCK SYSTEM

When signals 889, 890, 891, 892 and 893, in Sacramento yard, indicate "stop," train will not proceed until signal indicates "proceed" or hand signals are given by switch tender, green flag by day, green light by night. In foggy or stormy weather, flagman must precede train when signal indicates "stop."

Three-arm block signal on No. 2 track at Junction switch, Rocklin, governs the movement of eastward trains. The upper home and distant signals govern the use of No. 2 track. The lower home signal will clear only when No. 4 track is clear and switch lined for that track.

On No. 1 track between Newcastle and Loomis and on No. 4 track between Rocklin and Loomis, block signal rules governing trains on single track will apply.

Trains stopped by signal 2134 or 2141 Gerber yard, may then proceed with caution, not exceeding 12 miles an hour.

Signal arrangement west end Sparks yard will govern as follows: Signal 2452 on bridge governs main track movements on eastward main track. Dwarf signal 2452 on signal mast governs diverging route movements from eastward track across westward track into freight yard. Dwarf light signals 2453 and 2459 govern main track movements on westward main track. Light signal 2455 governs movement from engine lead to eastward main track.

SPECIAL SIGNALS

Light signals governing movement against current of traffic on No. 2 track from crossover Emigrant Gap to west limits Summit interlocking plant and from east limits Summit interlocking plant to Andover. On No. 1 track from Andover to east limits Summit interlocking plant and from west limits Summit interlocking plant to crossover Emigrant Gap, mile post 171.5.

When these signals indicate "stop," trains moving against current of traffic on No. 1 or No. 2 tracks will be governed by paragraphs A and E of Rule No. 509.

Lower light on signal No. 2015 at Andover governs movement through crossover against the current of traffic and to signal No. 1999.

Lower light on signal No. 2010 at Andover governs movement through crossover and to signal No. 2022.

Lower light on signal No. 2013 at Andover governs movement through crossover and to signal No. 2003.

Signal 1706 at Emigrant Gap. Indications as follows:

Rule 501, Fig. 6—Stop and proceed as per Rule 509.

Rule 504, A—Proceed.

Rule 502A, Fig. 3—Proceed prepared to stop at next home signal.

Rule 502, Fig. 3—Take siding.

Disc signals located at west switch Colfax, controlled by operators, will govern movement of trains as follows:

When showing yellow disc or yellow light; take siding.

When showing white disc or green light, proceed, if train orders or schedule permits.

Light signal on mast of signal 1427 east of Colfax, controlled by operators.—Indications are given by illuminated letters and figures as follows:

M—Hold main track.

X—Take cross over for roundhouse.

3—Take No. 3 siding at cross over east of road crossing.

4—Take No. 4 siding at east switch.

No light—Proceed, on time table or train order authority.

Light signal at switchman's cabin opposite yard office Roseville. This signal to be used by switchmen to give proceed signal to westward freight trains off Sparks-Roseville line to enter yard. Indications as follows:

No light—Stop and stay clear of Yosemite Street crossing.

Yellow light—Proceed into yard.

When proceed signal is given the yellow light will alternately flash off and on.

Junction switch at Tehama will be normally lined for movements via Chico. Light Signal 2119 will govern Gerber-Roseville line. Light dwarf signal located on top of signal case of Signal 2119 will govern Tehama-Davis line. Normal indication of Signal 2116 will be "STOP." Trains from Tehama-Davis line will not pass Signal 2116 until junction switch is lined for Tehama-Davis line. Rule 509 applies.

INTERLOCKING

SACRAMENTO RIVER DRAWBRIDGE.—Extends eastward on No. 1 track to westward home signal three hundred fifty feet east of Front Street crossing and eastward on westward freight track to westward home signal three hundred fifty feet east of crossing.

Interlocking home light signal governing westward movements on No. 1 track at east end of bridge, equipped with number plate SA-887.

Derails, operated by switchtender, in Front Street tracks and drill tracks seventy-five feet from crossing.

Trains, engines and cars approaching Front Street crossing or junction of freight tracks with No. 1 and No. 2 tracks, will be governed by hand signal from switchtender, using green flag by day and green light by night.

NINETEENTH STREET, SACRAMENTO.—At crossing of R Street track with Western Pacific R. R.

Limits extend from interlocking home signal 400 feet west of tower to dwarf signal 250 feet east of tower.

Yard engines wishing to use industry spurs will give following signal from push button located on home signal 400 feet west of crossing.

To Valley Grocery spur—one short, two long.

To Bekins spur—one long, one short, one long.

ELVAS.—Limits on Sacramento-Roseville line extend from interlocking home signal 1400 feet west of tower to automatic home signal 924.

On Elvas-Polk line extend to interlocking home light signal at west switch to siding at Polk and to home interlocking light signal 600 feet east of Junction switch to Placerville line.

Following switches and derails within interlocking limits are hand operated and must not be thrown until permission has been obtained from Signal Operator:

American Can Company spur switch and derail. Derail is electrically locked. Meister's spur switch and derail. Derail is electrically locked.

Permission must be obtained for each movement into or out of American Can Company and Meister spurs.

Crossover, center siding Elvas to westward track Elvas-Polk line. Movement governed by Signal 1355.

Crossover, center siding Elvas to eastward track Polk-Elvas line. Movement governed by Signal 1354.

West switch and derail center siding Elvas. Movement governed by Signal 1351.

Hopfen spur switch and derail. Movement governed by Signal 1345.

"R" Street connection, switch and derail. Movement governed by Signal 1331.

Switches and derails must be immediately returned to normal position after train has passed over them.

When giving hand signals as required by Rule 628, towerman may give them from the tower instead of from the ground.

To operate a dual control switch by hand, trainman must secure permission from the Signal Operator. When permission, including the time and working limits, is granted, he must first move selector lever to the "hand-throw" position and lock it in that position. When the time limit has expired or work is completed, the selector lever must be restored to the "switch machine" position, selector lever and hand-throw lever locked, and so reported to the Signal Operator; at the same time he must report the location of train or engine. If the main track is cleared and selector lever restored to "switch machine" position before expiration of the time limit new authorization must be obtained before again using the dual control.

The selector and hand-throw levers must never be forced. They will move easily when properly in mesh, although some manipulation of first one and then the other may be necessary to get them in proper mesh. If the switch was lined for siding when dual control use was started it must be again lined for siding before selector lever is restored to "switch machine" position.

When selector lever is placed in the "hand-throw" position, all signals immediately adjacent to the switch governed will indicate "stop." Under these conditions the train or engine authorized to use switch may pass these signals without stopping and make movements over the switch within the limits authorized as necessary during the time the selector lever is in the "hand-throw" position and locked. Trainman must notify engineer when the selector lever is in the "hand-throw" position, and also notify him when it is returned to the "switch-machine" position, so he may know when to be governed by the interlocking signals adjacent to the switch.

Whistle Signals governing routes as follows:

To Roseville, one long, four short.

To Sacramento, three long, one short.

To Polk, two long, three short.

To Elvas Siding, three short, two long.

To Third Track, two short, two long.

To American Can Spur, one long, one short, one long.

To Meister's Spur, one short, two long.

Eastward passenger trains will not be required to make running test approaching interlocking plant at Elvas, except when brake pipe has been separated.

EMIGRANT GAP.—Limits as follows:

On No. 1 Track from signal located 100 feet west of house track spur at Emigrant Gap, to signal 1711, 500 feet west of turntable.

On No. 2 Track from clearance of crossover to signal 60 feet east of east switch of crossover.

Electrically operated derail located 60 feet west of signal at house track spur switch on No. 1 Track.

East switch of crossover equipped with electric lock.

Derail located at clearance on east lead of turntable and equipped with electric lock.

Westward trains stopped at interlocking signal at house track spur switch, will call operator at Emigrant Gap on telephone and be governed by his instructions and when instructed by him to operate the derail by hand, be governed by the instructions on the sign at derail.

Trains moving through crossover from No. 2 track to No. 1 track will be governed by interlocking signal located 60 feet east of crossover switch. Signal will not clear for crossover movement until crossover switches have been lined.

Trains moving off east lead of turntable to No. 1 track will be governed by signal located 60 feet west of derail. Signal will not clear until derail and switch have been lined.

Trainmen or enginemen will not unlock or throw the west switch of crossover, when making crossover movement, until the east switch of crossover has been lined.

Trainmen or enginemen will not unlock or throw switch to east lead of turntable until derail has been closed.

Eastward signal, located opposite east switch of crossover on No. 1 track, governs movement against current of traffic through derail, and to signal 1736 at Smart.

Westward movement from west lead of turntable or from fire train crossover will not be made until permission is given by operator.

Rule 628 and 663 will not apply and the following will govern:

Telephones located at signals establishing communication with operator at Emigrant Gap. Trains stopped at signals will call operator for instructions and when such instructions have to do with an inoperative signal, trains will be preceded by flagman to next clear home or distant signal.

SUMMIT.—Limits as follows:

No. 1 track from interlocking home signal at west switch of siding Donner to Signal Bridge 775 feet west of Norden office.

No. 2 track from signal bridge 775 feet west of Norden office to westward interlocking home signal opposite signal 1975 west of cross-over Eder.

Fire Train Spur.—Switch and derail hand operated, derail electrically locked and must not be thrown until permission has been obtained from signal operator. Movement from spur governed by signal.

Run-around Tracks.—Engineers on helpers left on run-around track must obtain permission from signal operator before lining switch to siding.

Spur track switches must not be lined for movement to siding without first obtaining permission from signal operator.

Rules 628 and 663 will not apply and the following will govern. Telephones located at signals communicating with signal operator at Norden office, call signal operator by one long ring giving number of train, route desired, etc., movement will be governed by signal indication or instructions of signal operator and when such instructions have to do with an inoperative signal, trains will be preceded by a flagman to next home signal or clear distant signal.

When permission is given by signal operator to eastward trains to pass interlocking signals located on main track and on siding east end of Norden, will wait ten minutes and then be preceded by flagman according to rules and follow flagman 10 minutes to next home signal or clear distant signal.

Signal on No. 2 track 60 feet west of west switch to siding governing eastward movement on No. 2 track and to siding and turntable.

Signal on No. 1 track opposite clearance point on west lead to turntable governing westward movement on No. 1 track and through cross-overs.

GEORGIANA SLOUGH-DRAWBRIDGE.—Limits extend from interlocking home signal, 500 feet west of drawbridge, to interlocking home signal 500 feet east of drawbridge.

SNODGRASS SLOUGH-DRAWBRIDGE.—Limits extend from interlocking home signal 400 feet west of drawbridge to interlocking home signal 600 feet east of bridge.

NINTH STREET TOWER, MARYSVILLE.—Crossing Western Pacific R. R. and Woodland-Oroville line.

Limits extend from a point 450 feet west of tower to a point 450 feet east of tower.

BINNEY JUNCTION TOWER.—Junction with Woodland-Oroville line and crossing Western Pacific R. R.

Limits on Roseville-Gerber line extend from signal bridge 1300 feet west of tower to automatic home signal 1420. On Oroville line extend from signal bridge 1300 feet west of tower to interlocking home signal 950 feet east.

Woodland line from signal bridge 1300 feet west of tower to interlocking home dwarf signal on west leg of wye at clearance point to main track. Also from interlocking home signal 500 feet east of tower to interlocking home dwarf signal at spur switch on east leg of wye.

Whistle signals governing routes as follows:

Main track to or from Gerber, one long, four short.

Main track to or from Oroville, two short, two long.

Siding to or from Gerber, one short, three long.

Siding to or from Oroville, three long, one short.

Siding to or from west leg of wye, three short, two long.

Main track to or from west leg of wye, two long, three short.

Main track to or from east leg of wye, one short, one long.

To Spur, one short, two long.

Switches to east and west legs of wye hand thrown. Normal position of switch to west leg of wye.

LIVE OAK AUTOMATIC.—Crossing Sacramento Northern Railway one half mile east of Live Oak.

Interlocking limits on S. P. track extend from home light signal SA 1522, 517 feet west of crossing, to home light signal SA-1523, 523 feet east of crossing, and on S. N. Railway track between home light signals located 600 feet on both sides of crossing.

Speed of engines at crossing 20 miles per hour.

Normal indication of interlocking home signal is "STOP."

Home signal will change to PROCEED (or CAUTION) when train enters approach circuit to distant signal, provided there is no train in the block and no train within interlocking limits or approach thereto on Sacramento Northern Railway.

Eastward trains holding main track when meeting another train at Live Oak will stop west of overlap post located 100 feet west of station.

Trains having switching to perform at Live Oak should take siding, clearing main track as quickly as possible. East switch to house track and east switch to siding should be restored normally as quickly as possible after using same.

When train is stopped by interlocking home signal, a flagman must be sent in each direction on intersecting track unless the interlocking signals thereon are known to be in proper position to protect the movement.

Clockwork Time Release, located in door of Battery House at crossing.

This Clockwork Time Release must not be operated when trains or engines are between home signals or seen to be approaching on Sacramento Northern Railway tracks.

To operate Clockwork Time Release, turn knob to right to extreme position about one-quarter turn, release knob and when a red indicator light appears, this will indicate to flagman that signals on Sacramento Northern Railway are in proper position to protect the movement. Flagman may then proceed as prescribed by Rules 663 and 509. After four minutes, home signal should change from "Stop" to "Proceed with Caution" or a repeater red indicator light located on signal mast near base of home signal will light up and will indicate to engineer that home signals on Sacramento Northern Railway are in "Stop" position.

Train may then proceed through interlocking limits not exceeding 12 miles per hour.

WOODLAND.—Crossing Sacramento Northern R. R.

Limits on Davis-Tehama line extend from home signal 450 feet west of Sacramento-Northern R. R. crossing to home signal 500 feet east of crossing. On Woodland-Oroville line extend to dwarf signal 200 feet east of crossing.

Whistle signals governing routes as follows:

For Tehama to or from siding, one long, four short.

For Tehama to or from house track, three long, one short.

For Knights Landing to or from siding, one short, three long.

When giving hand signals as required by Rule 628, signal operator may give them from the tower instead of from the ground.

MISCELLANEOUS

On freight trains ascending and descending grade between Emigrant Gap and Andover member of train crew must observe track from rear of caboose, that train may be brought to stop promptly in event of derailment.

In Valley territory engines may take oil and water without cutting off train at all points, except Marysville.

On ascending grades between Roseville and Sparks, engines may take oil and water without cutting off train at all stations except Gold Run.

RULE 221.—Train Order Signals:

Emigrant Gap:

Westward signal located 2500 feet east of office and eastward signal 100 feet west of office.

Cisco:

Westward signal located 100 feet east of Tunnel No. 3, and Eastward signal 1000 feet west of office.

Norden:

Westward signal located 900 feet east of station, and Eastward signal 800 feet west of station.

Indication of these train order signals will be by lights only.

When a train reaches a point approximately 300 feet from signal, if no train orders, light will change from "Stop" to "Proceed."

If signal is first seen in "Proceed" indication clearance card must be obtained.

Tracks between Sacramento and Roseville numbered and will be used as follows:

No. 1 Track, by westward trains.

No. 2 Track, by eastward trains.

Westward trains via Brighton having cars to set out at Elvas will use east end of center siding, using switch at road crossing.

Eastward trains from Brighton having cars to set out at Elvas will use west end of center siding and set cars in at switch near road crossing.

5000 Class Engines will not clear umbrella sheds of Sacramento passenger station and must not be used on Tracks 2, 3, 4, 5, 6, and 7.

Trains and engines must not pass the switch tenders stations at east end Sacramento River Bridge, Sixth Street, Seventh Street and Fifteenth Street, Sacramento, without receiving a signal from switch tender to proceed, green flag by day and green light by night, and will move with caution between switch stations enumerated above.

Engineers leaving and arriving Sacramento passenger station will refrain from sounding whistle or ringing bell and keep cylinder cocks closed while passing hospital building.

Tracks between Roseville and Sparks numbered and will be used as follows:

No. 1 Track, via Auburn, by westward trains.

No. 2 Track, Eastward main track via Auburn, Nevada Street, by eastward trains.

No. 4 Track, between Rocklin and Loomis; diverges from No. 2 track at Rocklin and runs on south side of No. 1 track, one half mile east of Rocklin to Loomis, connecting with No. 1 track at Loomis.

Mallet, 2-10-2, 4-10-2, AC Mt., GS-I and Mikado engines, must not be operated over the following tracks:

Rocklin, siding and house track.

Loomis, east end fruit tracks.

Penryn, fruit spurs west of station.

Newcastle, tracks 3 and 4 (either from crossover leading from main track to No. 3 or from crossover from siding).

Flint, Standard Oil spur.

Auburn, high line.

Nev. St., Auburn, spurs.

Clipper Gap, team track east of road crossing.

W. New England Mills, spur, west of tool house.

W. Applegate, spur.

Colfax, material spur in west yard.

Magra, spur.

Towle, spur.

Blue Canon, dump spur, oil spur and Greek spur east of oil column.

Spur switch, Eder.

Lumber spur switch, Summit.

Spur switch, Spruce.

Outfit spur switch, Cisco.

Crystal Lake, spur on south side of No. 2 track.

Spur switches, Yuba Pass.

Andover, outfit spur, 3 car lengths back of frog.

Donner, 6 car lengths back of frog.

Campbell Spur, Cisco, east of corral chute.

5000 and 4100 class engines must not use following tracks in Colfax Yard:

Corral track west of corral,

Bunk track,

House track and house track lead east of freight house,

Trains picking up Colfax helpers for movement to Emigrant Gap or Norden, must cut same in ahead of the Roseville helper.

Eastward freight trains with helpers to cut at Norden will take siding. Westward freight trains with helpers to cut at Summit will take upper siding.

On account of storage tanks of Standard Oil Company near tracks at M. P. 107.9 between Roseville and Rocklin, flues of engines must not be sanded until after engine has passed this point.

Normal position west switch siding at Midas lined for lead to No. 1 track.

Three Indication Light Type Dwarf Signal 1603 and switch indicator (Rule 512-A), located at derail west end center siding, Midas, governing movement from center siding to No. 1 track.

Normal indication Signal 1603, DARK. RED indication will be displayed after derail has been closed; and with main line switch to No. 1 track lined for siding, GREEN indication will be displayed if block is unoccupied.

YELLOW indication if block is unoccupied and signal in advance is at stop.

Should Signal 1603 fail to change immediately from RED to GREEN or YELLOW after derail and switch are lined, wait four minutes for time element relay which will be effective when the approach to Signal 1601 is occupied.

Should Signal 1603 fail to change from RED to either GREEN or YELLOW, be governed by Rules 509 and 99.

Cars containing live poultry moving west from Sparks must be placed three cars ahead of caboose, Sparks to Truckee and three cars ahead of helper engine from Truckee to Summit.

5000 and 4100 class engines may operate on west end of team track Colfax to east end of freight house platform, but must not proceed beyond east end of platform.

When torpedoes are used between Blue Canon and Stanford, each torpedo placed, will be duplicated on opposite rail.

Crotch switch at east end of Verdi center siding, will be mechanically locked by the derail. Derail must be open before crotch switch can be operated.

When making up train or picking up enroute, scale repair and scale test cars should be placed in rear of freight train next ahead of caboose, or next ahead of occupied outfit cars, when latter cars are handled in freight train. Yard crews must not switch with scale repair or scale test cars, but will handle them in this respect as required to handle caboose, and when setting these cars in or out of train or shifting them from one track to another, rough switching must be avoided and equipment carefully handled.

When car is set out and scale inspector is working in car, he will display a blue signal, which must be respected as per Transportation Rule No. 26. Inspector must not display blue signal for any other purpose, that unnecessary delay in handling this equipment may be avoided.

Ordinarily freight trains from Sacramento Division will enter Sparks freight yard at crossover switch just west of Seventeenth Street and will approach this switch prepared to stop unless route lined and signals indicate proceed.

Minimum Clearances for Rotary Plows, Blue Canon East

Push cars in shed district must be placed between posts providing for proper clearance.

Tunnels 3 and 4 shed posts clear 8 to 10 inches.

Tunnel 5, 8 inches clearance.

East and west of mile post 195, stone walls clear 6 inches. Water trough east of tunnel 10 clears 5 inches.

East end of tunnel 11 clears 8 inches.

Rotary plow on an 8 or 10 degree curve will swing approximately 7 inches from center.

Crews handling plows through district where standard clearance is not provided must reduce speed to six miles per hour through tunnels and at rock walls.

Normal position turntables on Truckee District will be as follows:

Blue Canon West approach, on account of repair platform on west end.

Emigrant Gap East approach, with motor on east end.

Cisco East approach, with motor on east end.

Norden East approach to eastward track.

Trainmen and enginemen using these turntables must leave them lined as shown above.

OPERATION OF TURNTABLE AT NORDEN

Yellow light signals on leads to turntable at Norden. These signals will indicate route to be used from turntable. If no indication visible when engine is ready to leave turntable, telephone signal operator at Norden for instructions.

Remove rail locks before attempting to move table.

Properly line table and reset rail locks before moving engine on or off table.

Release brake before moving turntable and do not apply brake unless control handle is in the "off" position.

To Move Turntable: Turn controller handle around to the third or fourth point, allowing about one second on each point.

To Stop Turntable: Turn controller rapidly to "off" position.

Allow turntable to come to a stop before reversing motor.

In case of trouble notify operator at Norden office, who will call maintainer.

Turntable must be left lined and locked for east lead to eastward track.

Box No.	ALARM BOX LOCATIONS	Mile Post
3	300 feet east of east portal Tunnel No. 1.....	...
4	¼ mile east of Blue Canon.....	...
5	300 feet west of Signal 1687 (Gunter).....	...
7	Signal 1707, 500 feet east of west switch Emigrant Gap.....	...
8	Cross-over east of turntable house, Emigrant Gap.....	173
9	Between Smart and Emigrant Gap.....	174
12	Between Smart and Yuba Pass.....	175
13	Between Smart and Yuba Pass.....	175
14	In first shed west of Yuba Pass.....	...
15	East switch of Summer Siding, Yuba Pass.....	...
16	End of shed east of portal Tunnel No. 36.....	...
17	West end of center siding, Crystal Lake.....	178
18	West end Butte Canyon Bridge.....	179
19	200 feet west of west cross-over, Cisco.....	180
21	End of shed east portal Tunnel No. 39.....	181
22	1½ miles east of Cisco.....	182
23	½ mile west of cross-over, Tamarack.....	183
24	½ mile east of cross-over, Tamarack.....	184
25	Between Tamarack and Troy.....	185
26	½ mile west of west switch, Troy on No. 1 track.....	...
27	East switch, Troy.....	186
28	600 feet east of Lower Cascade Bridge.....	187
29	¼ mile east of Upper Cascade Bridge.....	188
31	Between Spruce and Soda Springs.....	189
32	In first shed west of Soda Springs.....	190
33	300 feet east of cross-overs, Soda Springs.....	...
34	Castle Creek Bridge (Culvert 190-0).....	...
35	East switch of west run-around track on No. 1 track, Summit.....	...
36	1000 feet west of west portal Tunnel No. 6.....	193
37	East portal Tunnel No. 6.....	194
38	Between Tunnels No. 9 and 10.....	195
39	West Switch, Donner.....	...
41	1 mile east of Donner.....	197
42	½ mile east of cross-overs, Eder.....	198
43	Between Eder and Andover.....	199
44	Between Eder and Andover.....	199½
45	300 feet west of west portal Tunnel No. 13.....	200
46	100 feet east of Andover Section House.....	...
47	At Andover Station.....	201
48	In turntable house, Summit.....	...
49	East switch of run-around on No. 2 track, Norden.....	...
51	East switch of siding on No. 2 track, Norden.....	...
52	West portal Tunnel No. 41.....	...
53	Center of Tunnel No. 41.....	...
54	East portal Tunnel No. 41.....	...

Code signals following box numbers are as follows: One—East. Two—West. Three—Broken rail. Four—Track men. Five—Slide. Six—Fire.

Trains using spur track serving the Stockton Fire Brick Co. across highway at Clayton will be governed by the following:

This spur must not be used by any class of engine larger than 2700 Class.

No engine, train or car shall be operated over highway crossing except between the hours of 7:30 P. M. and 7:30 A. M.

Trains, motors, engines and cars must be stopped before crossing the highway and must not proceed to cross highway until conductor or other trainman has gone upon the crossing to ascertain if it is safe to do so and until signal to proceed has been given.

Oil trains in valley district when consisting of mixed loads and empties, will be made up with ten steel frame empty cars immediately behind engine, loaded oil cars to follow.

Through trains between Roseville and Gerber will take water at Berg instead of Marysville whenever possible.

Sidings at Nord and Lomo and team track, mill spur and Earl Fruit spur Marysville must not be used by Mikados, Mallets, SP, AC, Mt, GS-I, or 2-10-2 type engines. Engines equipped with pilot plows must not use tracks on "E" Street, Marysville.

Where cars or engines are to be moved on old Cannery Track over 4th Street, Marysville, flagman must flag the crossing before movement is started over crossing. When using Wye track at Barber, by engine with or without cars, tangent track, continuation of the Wye, must be used and at no time use the Diamond Match Company's track.

Cars will not be handled ahead of engine at any point between Stirling City and Chico on westward trip.

Two engines must not be coupled on Stirling City line. Helper engines must be cut back in train.

At Chico, the Chico-Stirling City main track originates at switch on Chico-Stirling City line leading to engine house at Chico.

Trains to and from Stirling City line use yard tracks from passenger station Chico to Chico-Stirling City main track.

Track between station and Stirling City main track, must be kept clear of cars.

Flint hoppers and box cars must not be placed on spur serving El Dorado Lime & Mineral Company at Bullard to or beyond rock chute which does not clear this class of equipment.

Trains must stop and flagmen must precede train over Main Street when making movement on house track at Woodland.

Trains to and from Oroville on Woodland-Oroville line use Marysville siding. No engine larger than Consolidation engines with 225,000 pounds on the drivers should pass over Trestles 97-A and 97-E on Knights Landing Line.

No train, engine, motor or car shall be operated over county road known as Wilson road at Wilson unless said train, engine, motor or car shall be under control and unless traffic on the highway be protected by a member of the train crew or other competent employee acting as flagman.

Willows-Fruto main track originates at yard limit board located on Willows-Fruto line. Trains to and from Willows-Fruto line use yard tracks from passenger station to Willows-Fruto main track.

At Roseville, schedule time and train orders for eastward trains on Roseville-Gerber line, applies at west switch of crossover, leading from No. 2 to No. 1 tracks, 400 feet west of Lincoln Street crossing.

Westward trains receiving orders at, or east of Newcastle moving an eastward train from Loomis to Newcastle on No. 1 track, must not pass east crossover switch at Newcastle until opposing trains on No. 1 track have arrived.

A westward train must stop east of east crossover switch at Newcastle unless they receive a train-order signal permitting it to proceed.

Eastward trains authorized to use No. 1 track between Loomis and Newcastle, may proceed on No. 1 track to first crossover switch, located east of the station building at Newcastle.

Nos. 20, 534 and 306 will use No. 4 track Rocklin to Loomis.

Before using drill track across Victory Highway at Isleton Wharf, train must be under control and traffic on the highway must be protected by member of the crew acting as flagman.

SPEED TABLE

Miles per Hour	1 Mile in		Miles per Hour	1 Mile in		Miles per Hour	1 Mile in		Miles per Hour	1 Mile in	
	Min.	Sec.		Min.	Sec.		Min.	Sec.		Min.	Sec.
6	10	21	2	51	31	1	56	41	1	27
8	7	30	22	2	43	32	1	52	42	1	25
10	6	23	2	36	33	1	49	43	1	23
12	5	24	2	30	34	1	45	44	1	21
15	4	25	2	24	35	1	42	45	1	20
16	3	45	26	2	18	36	1	40	46	1	18
17	3	31	27	2	13	37	1	37	47	1	16
18	3	20	28	2	8	38	1	34	48	1	15
19	3	9	29	2	4	39	1	33	49	1	13
20	3	30	2	40	1	30	50	1	12

SPEED RESTRICTIONS

Wooden passenger cars, when used in main line service, must be equipped with steel center sills and steel platforms, except

(a) Wooden baggage, express and other head-end cars not so equipped may be used, when entire consist of train is composed of such equipment, or may be handled on head end of passenger trains, provided consist thereof does not exceed seven cars, and inspection indicates movement can be made with entire safety.

(b) Wooden passenger-carrying cars not so equipped may be used in local passenger trains and in local extras, operated account Holiday or excursion traffic, provided speed of such extras is restricted to forty miles per hour. When consist of local regular or extra trains contain both wooden and steel passenger-carrying cars, the wooden equipment must be kept together and on the rear.

Trains and engines must not exceed 12 miles per hour over Lincoln Street crossing, Roseville.

Speed of 60 miles per hour permitted train No. 9 between Roseville and Sacramento, where speed of other passenger trains is restricted to 50 miles per hour.

Passenger trains must not exceed 40 miles per hour and freight trains 30 miles per hour on No. 4 track between Rocklin and Loomis.

SPEED RESTRICTIONS—Continued.

Speed Restrictions in Miles Per Hour, Will Apply as Follows:

Pages	Between	PASSENGER				FREIGHT			Engines and Motors Backing	All Trains City Ordinance	LIGHT ENG. RUNNING FORWARD			
		Maximum	With SP-1, SP-2, SP-3, F-1, F-3, F-4, F-5, F-6, MM-2 and AM Engines	With GS-1, AC-1, 2, 3, 4, 5, 6, MC-2, 4, 6, MK-2, 4, 5, 6, 8, 9, C-2 to 10 inc., C-11, 12, 14, 15, 17 and TW Engines	With Other Type Engines	Freight and Mixed, Maximum	With MC-1, 2, 4, and 6 Engines	SP-1, SP-2, SP-3, F-1, F-3, F-4, F-5, F-6, MK-5, 6, 8 and 9			MT-1, 2, 3, 4, 5, E, M, T, A and P	Types C-2 to C-10 and C-18 to 23 inc.	C-11, 12, 14, 15, 17, TW, MC Class MK-2, 4 MM-2, AM, AC-1, 2, 2, 3, 4, 5, 6 and GS-1	
2	Colfax—Truckee..... No. 2 Track	35	35	35	35	20	20	15		30	30	25	30	
2	Truckee—Sparks..... No. 2 Track	40	40	40	40	30	25	15		35	35	30	30	
2, 3	Reno.....								15					
2, 4	Sacramento—Colfax..... No. 2 Track	50	45	40	50	35	25	20		35	40	35	30	
3	Sparks—Truckee..... No. 1 Track	40	40	40	40	30	20	20		35	35	30	30	
3	Truckee—Loomis..... No. 1 Track	35	35	35	35	20	20	15		30	30	25	30	
3	Truckee—Tahoe.....	40	25	25	40	30	20	15		20	30	30	30	
3, 5	Loomis—Sacramento..... No. 1 Track	50	45	40	50	35	25	20		35	40	35	30	
4, 5	Roseville—Gerber.....	50	45	40	50	35	25	20		35	40	35	30	
4, 5	Lincoln.....								35					
6	Davis—Tehama.....	60	45	40	60	40	25	20		35	40	35	30	
7	Woodland—Marysville.....	45		35	45	35		20			35	35	30	
7	Marysville—Oroville.....	25		25	25	25		15			20	25	25	
7	Brighton—Folsom.....	50		40	50	35		20			40	35	30	
7	Citrus—Fair Oaks.....	25		20	25	20		15			20	20	20	
7	Folsom—Placerville.....	30		20	30	15		12			25	15	15	
8	Harrington—Wyo via Colusa.....	30		25	30	25		20			25	25	20	
8	Willows—Fruto.....	20			20	15		10			15	15	15	
8	Sacramento—Isleton.....	30		20	30	20		15			25	20	20	
8	Grace—Josephine.....	30		20	30	20		15			25	20	20	
8	Marchant—Karnak.....	30		20	30	20		15			25	20	20	
8	Chico—M. P. 188 (Stirling City Branch).....	30		25	30	25		15			25	25	25	
8	M. P. 188—Stirling City.....	20		20	20	12		10			15	12	12	
.....	Through Crossovers, Turn-outs, and on Sidings.....				15		8							

Eastward passenger trains must not exceed 40 miles per hour and eastward freight trains must not exceed 30 miles per hour between east end of Roseville yard and Rocklin station.

Slow boards have been placed at west switch Truckee No. 1 track, east switch Loomis No. 1 track and west switch Colfax No. 2 track, with figures 35 on upper left side, 30 on lower left side, and 20 on right side.

Passenger trains must not exceed 35 miles per hour on tangent and 30 miles per hour on curves between Truckee and Loomis on No. 1 track and between Colfax and Truckee on No. 2 track.

Freight trains must not exceed 20 miles per hour between Truckee and Loomis on No. 1 track and between Colfax and Truckee on No. 2 track.

SP-1, SP-2, SP-3, F-3, F-4, F-5, F-6, AC-4, AC-5, AC-6, AM, GS-1, and MM-2 type engines must not exceed 25 miles per hour where slow boards restricting speed on curves, show 30 miles per hour between Truckee and Loomis on No. 1 track and between Colfax and Truckee on No. 2 track, and between Truckee and Sparks on Nos. 1 and 2 tracks where slow boards restricting speed on curves show 28 miles per hour.

Mt. 1, 2, 3, 4, 5 class engines must not exceed 28 miles per hour where slow boards restricting speed on curves show 30 miles per hour.

MC 2, 4, 6 and AC 1, 2 and 3 class engines must not exceed 20 miles per hour on curves.

Motors backing through yards and over highway crossings must not exceed 10 miles per hour.

Relief trains with steam derrick must not exceed 15 miles per hour over Colusa, Sutter Basin, River Farms, Stirling City, Walnut Grove, and Placerville lines.

Relief trains with steam derrick must not exceed 25 miles per hour and will be governed by other speed restrictions.

Fire trains and flangers operating between Lawton and Loomis must not exceed 30 miles per hour and be governed by other speed restrictions.

Speed of fire trains, with water cars full, must not exceed 25 miles per hour in forward direction.

Speed of fire trains, with water cars less than three quarters full, must not exceed 20 miles per hour in forward direction. Water cars must be kept full when possible.

Trains handling loaded Flint hoppers must not exceed 25 miles per hour.

At intermediate stations where mail is dispatched while trains are in motion speed must be reduced sufficiently to avoid injury to passengers or others who may be standing on station platforms.

Eastward first-class trains must not exceed 30 miles per hour from yard limit board located one thousand feet west of west switch at Antelope to signal 1046, from signal 1046 to mile post 108 on Roseville-Sparks line, 20 miles per hour.

Westward first-class trains from mile post 108 Roseville-Sparks line to signal 1049 20 miles per hour. From signal 1049 to Antelope station 30 miles per hour.

Freight trains on descending grades must not exceed 15 miles per hour while passing passenger trains.

When necessary for locomotive cranes to move in trains with flexible or swivel truck trailing, the speed of the train must not exceed 18 miles per hour.

Trains must not exceed 25 miles per hour entering or moving through controlled sidings, or when running against the current of traffic on double track under authority of dwarf signals.

Trains must not exceed 25 miles per hour from Yuba River bridge to Feather River bridge, Marysville, and from east yard limit board Chico to west switch Chico Siding.

Eastward trains using No. 2 track must not exceed 12 miles per hour from Signal Bridge just west of Passenger Station Sparks, to yard office at Sparks.

Engines must not exceed 8 miles per hour on balloon track at Lake Tahoe.

Trains must not exceed 25 miles per hour over Feather River bridge east of Binney Junction. This includes approaches as well as trestle on the curve just east of Feather River.

Trains must not exceed 15 miles per hour between the overhead bridge at Roseville, on the Roseville-Gerber line, and the passenger station at Roseville.

Trains must not exceed 12 miles per hour over Main and Court Street crossings Woodland.

Trains must not exceed 12 miles per hour over railroad crossing Bridge Street east of Yuba City station.

Trains must stop within 200 feet of S. N. R. R. crossing at Yuba City and at Knights Landing drawbridge before crossing.

Trains will pass over S. P. R. R. crossing at Grace with caution.

Consolidation engines must not exceed 30 miles per hour between Yuba City and Woodland.

Motor cars must not exceed 25 miles per hour between Mile Post 138 and Placerville.

Trains having cars loaded with ore or high loads of lumber must not exceed 12 miles per hour on curves 7 degrees or over on Placerville line.

Engines using Mather Field Spur must not exceed 10 miles per hour.

Trains must not exceed 15 miles per hour over trestle 112-A on Grace-Josephine line.

When necessary to operate 5000 class engines on Stirling City line to the Sacramento Northern transfer at Chico, speed must not exceed 10 miles per hour.

Trains will stop within two hundred feet of Sacramento Northern R. R. crossing on Chico-Stirling City line before crossing.

Trains must not exceed 20 miles per hour on Dantoni line between Dantoni Junction and Dantoni.

Freight trains must not exceed 12 miles per hour on curves between Kurand and Fruto.

Trains must not exceed 10 miles per hour between initial switch of spur to Hood Wharf and Hood Wharf.

Trains must pass over S. N. R. R. crossing 9th Street Chico with caution.

Trains must not exceed 40 miles per hour through city limits of Corning, Orland and Willows.

No. 8 stop at Orland for exchange of U. S. Mail.

Trains and engines must not exceed 20 miles per hour between west end Sacramento River Drawbridge and 15th Street, Sacramento.

Engines being hauled in trains or running under own steam must not exceed:

- When main rod only is removed..... 30 miles per hour
 - When side rods only are removed..... 30 miles per hour
 - When both main and side rods are removed..... 20 miles per hour
- S and SE class engines must not exceed 20 miles per hour.

SPECIAL INSTRUCTIONS

LOCATION OF STRETCHERS

Sacramento.....Hospital	Oroville.....Baggage Room	Rocklin.....Baggage Room	Norden.....Baggage Room
".....Baggage Room	Knights Landing.....Freight House	Loomis.....Baggage Room	Truckee (3)....."
Fair Oaks.....Freight House	Woodland.....Baggage Room	Penryn.....Baggage Room	Floriston....."
Hood....."	Williams....."	Newcastle....."	
Walnut Grove.....Baggage Room	Willows (2)....."	Auburn....."	
Lincoln....."	Roseville.....Power House	Colfax....."	
Wheatland....."	".....Car Dept.	Dutch Flat....."	
Marysville....."	".....Yard Office	Towle....."	
Gridley....."	".....Station	Blue Canon (2)....."	
Biggs....."	".....Hospital	Cisco.....Baggage Room	
Chico (2)....."	".....Store Dept.		

HOSPITALS

GENERAL.....	SAN FRANCISCO
EMERGENCY.....	SACRAMENTO
".....	ROSEVILLE
".....	GERBER
".....	SPARKS

LOCATION OF OVERHEAD AND SIDE STRUCTURES NOT STANDARD CLEARANCE

Mile Post	LOCATION	DESCRIPTION
SACRAMENTO YARD		
	Sacramento River Bridge	Side
	Shop Yard	Oil House West of Store No. 1.....Side
	Shop Yard	Sand spurs Nos. 1 and 2.....Overhead
	Shop Yard	Track No. 2, Car Shop No. 9.....Side
	Shop Yard	Track No. 3, Car Shop No. 9.....Side
	Shop Yard	Track No. 4, Car Shop No. 9.....Side
	Shop Yard	Track No. 5, Car Shop No. 9.....Side
	Shop Yard	Track No. 9, Car Shop No. 9.....Overhead & Side
	Shop Yard	Roundhouse spur.....Side
	Shop Yard	Track No. 2 Bone Yard Track.....Side
	Shop Yard	Track No. 3 Laundry.....Side
	Shop Yard	Track No. 2 Scrap Dock.....Side
	Shop Yard	Track No. 3 Scrap Dock.....Side
	6th and H Streets	Western Meat spur.....Side
	6th Street	New Foundry Track.....Side
	6th Street	Coke spur.....Side
	6th Street	Foundry Track 6th Street.....Side
	R between 11th & 12th	Lawrence Warehouse.....Side
	R between 21st & 22nd	Barley spur Buffalo Brewery.....Side
	R between 21st & 22nd	Buffalo Brewery spur.....Overhead & Side
	B between 11th & 12th	Phoenix Mill spur.....Side
	B between 8th & 9th	Consumers Ice Co. Track.....Side
	3rd to 6th Streets	Track No. 4 Rolling Mill.....Side
	6th Street	Water Tank.....Side
	15th & N. B. Streets	Unloading pit center of Track, Golden Gate Atlas spur.....Side
	13th & 14th on B St.	Unloading pit center of Track, Clark and Henry spur.....Side
	4th & R Streets	Sacramento Vegetable Growers Assn.....Side
	5th & R Streets	Viriden Packing Co. spur.....Overhead & Side
	Front St. between M & N	Sacramento Northern Guy Pole.....Side
	Walnut Grove Connection	2nd Street to Front St. Yard.....Overhead
	Front St. between H & I	Stulsaft spur.....Overhead
	Between tracks No. 1 and No. 2	South end of old freight shed.....Front St.
	Between tracks No. 2 and No. 3	South end of new freight shed.....Front St.
ROSEVILLE-SPARKS—EASTWARD		
106.6	American River Bridge	Side
	Roseville	Iceing track, PFE track No. 2 and New Iceing track, PFE Plant.....Side
	Roseville Yard	Track No. 3, Heavy Rip.....Side
	Roseville Yard	Track No. 4, Heavy Rip.....Side
	Roseville Yard	Track No. 5, Heavy Rip.....Side
	Roseville Yard	Track No. 6, Heavy Rip.....Side
	Roseville	P. F. E. Iceing Tracks Nos. 0-1-2-3.....Overhead
	Rocklin	Kesty Quarry spur.....Overhead
	Rocklin	Henderson Quarry spur.....Overhead & Side
	Rocklin	Pernu Quarry spur.....Overhead
	Rocklin	Elickson Quarry spur.....Overhead
110.6	Rocklin	Cal. Granite spur, Rocklin, Quarry.....Side
110.6	Rocklin	Stock Chute on Corral Track.....Side
	E. of Rocklin	Antelope Creek bridge.....Side
114.2	E. of Rocklin	Tunnel No. 15.....Overhead
114.8	E. of Rocklin	Tunnel No. 16.....Overhead
117.3	E. of Lincoln Ave., Penryn	Tunnel No. 17.....Overhead
120.5	E. of Newcastle	Tunnel No. 18.....Side & Overhead
122.7	E. of Newcastle	Tunnel No. 19.....Overhead
123.2	E. of Newcastle	Tunnel No. 20.....Overhead
124.7	E. of Nev. St., Auburn	Tunnel No. 21.....Overhead
131.2	E. of Bowman	Tunnel No. 22.....Overhead
132.7	E. of Clipper Gap	Tunnel No. 23.....Overhead
132.9	E. of Clipper Gap	Tunnel No. 24.....Overhead
133.1	E. of Clipper Gap	Tunnel No. 25.....Overhead

LOCATION OF OVERHEAD AND SIDE STRUCTURES NOT STANDARD CLEARANCE

Mile Post	LOCATION	DESCRIPTION
ROSEVILLE-SPARKS—EASTWARD—Continued		
133.3	E. of Clipper Gap	Tunnel No. 26.....Overhead
133.8	E. of Clipper Gap	Tunnel No. 27.....Overhead
134.8	E. of Applegate	Tunnel No. 28.....Overhead
136.0	E. of Applegate	Tunnel No. 29.....Overhead
138.7	E. of N. E. Mills	Tunnel No. 30.....Overhead
139.2	E. of Lander	Tunnel No. 31.....Overhead
139.4	E. of Lander	Tunnel No. 32.....Overhead
141.7	Colfax	Automatic Signal Nos. 1420, 1421 & 1425 Side
141.7	Colfax	Water Col. W. of Station W. B.....Side
141.7	Colfax	PFE Iceing Platform.....Side
144.5	E. of Colfax	Tunnel No. 33.....Side & Overhead
144.7	E. of Colfax	Tunnel No. 34.....Side & Overhead
152.2	Gold Run	Mail Crane.....Side
	Gold Run	Water Tank West end of Yard.....Side
152.4	E. of Gold Run	Oil & Water columns.....Side
165.5	Blue Canon	Water Columns.....Side
208.0	Truckee	Roundhouse portals.....Side
208.0	Truckee	Oil sump doorways.....Side
242.9	Reno	Transfer track.....Side
242.9	Reno	Buffalo Brewing Co. platform.....Side

COLFAX-ROCKLIN—WESTWARD

132.7	W. of Applegate	Tunnel No. 0.....Side & Overhead
124.5	Auburn	Ford & Son Warehouse, hill track.....Side
124.5	Auburn	Lowell Warehouse, hill track.....Side
124.5	Auburn	Fruit House Track, hill track.....Side
124.5	Auburn	Hse. Track, Auburn I. & C. siding.....Side
124.5	Auburn	Hse. Track, Ford & Son, Whse. siding.....Side
122	W. of Flint	Cut West of 122.....Side
	W. of Flint	Cut West of 122-G.....Side
	W. of Flint	Cut West of 122-H.....Side
	W. of Flint	Bloomer Cut.....Side
113.9	Loomis	No. 1 Hill track, Earl Fruit Co.....Side
113.9	Loomis	No. 1 Hill track, Law Bros., Fruit Hse. Side

SACRAMENTO-GERBER

94.9	Ben Ali	Cannon Phillips spur.....Overhead & Side
117.0	Lincoln	Diamond Match Co., Lumbershed.....Side
	Clayton	Stockton Fire Brick Co., Spur.....Overhead
140.8	Marysville	W. T. Ellis Warehouse.....Side
140.8	Marysville	Buckeye Mill platform.....Side
120.0	Marysville, E Street	Yuba Construction Co., platform.....Side
161.4	Biggs	Rice Mill Siding.....Side & Overhead

WOODLAND-TEHAMA

103.2	Dunnigan	Water Tank.....Side
117.6	Genevra	Water Tank.....Side
124.2	Williams	Bartlett Water Co., shed platform.....Side
124.2	Williams	Stoval-Wilcox Wholesale platform.....Side & Overhead
124.2	Williams	Williams Warehouse Co., platform.....Side
133.0	Maxwell	Water Tank.....Side

Mile Post	LOCATION	DESCRIPTION
WYO-HARRINGTON		
120.8	Grimes	Water Spout.....Overhead
145.9	Princeton	Water Spout.....Overhead
150.4	Codora	Warehouse.....Side
165.9	Rotavelle	Elevator.....Side
177.4	Hamilton	Boiler House of sugar factory.....Side
177.4	Hamilton	Shed over beet unloading track.....Overhead
DAVIS-OROVILLE		
111.4	Tudor	Water Tank.....Side
112.4	Abbott	Earl Fruit Co. bldg. siding.....Side
120.4	Yuba City	S. N. R.R. trolley wire, E. of depot.....Overhead
135.0	Honcut	Station platform.....Side
135.0	Honcut	Brown's Warehouse.....Side
147.9	Oroville	C. L. Bills cement warehouse.....Side
147.9	Oroville	Olive Produce Co. porch.....Side
147.9	Oroville	Ice House platform.....Side
SACRAMENTO-PLACERVILLE		
91.5	Sacramento, 23rd & R.	Contractors' spur, building.....Side
	Brighton	Unloading pit center of track A. Teichert Co. spur.....Side
95.9	Perkins	Perkins' Store.....Side
98.9	Mayhew	Humphrey Packing house platform.....Side
98.9	Mayhew	Earl Fruit Co. platform.....Side
122.3	Cothrin	Rock Cut.....Side
126.4	Latrobe	Rock Cut.....Side
126.5	E. of Latrobe	Rock Cut.....Side
128.6	E. of Latrobe	Rock Cut.....Side
148.7	Placerville	Water Tank.....Side
SACRAMENTO-ISLETON		
92-B	Charles	Bridge.....Side
93.0	Charles	Stock Chutes at 93-A.....Side
	Snodgrass Slough	Bridge.....Side
113.4	Walnut Grove	Pacific Fruit Bldg.....Side

LIST OF SURGEONS.

LOCATION	NAME	TITLE
San Francisco	Dr. W. B. Coffey	Chief Surgeon and Manager.
Sacramento	Dr. A. M. Henderson	Division Surgeon.
Sacramento	Dr. G. L. Stevenson and W. W. Cross	District Surgeons.
Sacramento	Dr. J. Roy Jones	Aurist.
Sacramento	Dr. E. C. Turner	Oculist.
Roseville	Dr. B. Woodbridge	District Surgeon.
Roseville	Dr. L. E. Jones	Asst. District Surgeon.
Roseville	Dr. E. E. Myers	Asst. District Surgeon.
Roseville	Dr. P. D. Barnes	District Surgeon.
Loomis	Dr. L. B. Barnes	District Surgeon.
Newcastle	Dr. G. H. Fay	District Surgeon.
Auburn	Dr. D. M. Kindopp	District Surgeon.
Colfax	Dr. C. J. Durand	District Surgeon.
Colfax	Dr. B. F. Howard	Emergency Surgeon.
Blue Canon	Dr. H. N. Miner	District Surgeon.
Truckee	Dr. J. H. Bernard	District Surgeon.
Reno	Dr. W. H. Hood	Consulting Surgeon.
Reno	Dr. Horace J. Brown	District Surgeon.
Reno	Dr. M. R. Walker	Assistant District Surgeon.
Reno	Dr. John A. Fuller	Oculist and Aurist.
Wheatland	Dr. F. W. Didier	District Surgeon.
Marysville	Dr. E. E. Gray	District Surgeon.
Marysville	Dr. Thos. E. Lerner	Oculist and Aurist.
Live Oak	Dr. I. W. Higgins	District Surgeon.
Gridley	Dr. W. S. Lavv	District Surgeon.
Biggs	Dr. P. Caldwell	Emergency Surgeon.
Durham	Dr. J. L. Doyle	District Surgeon.
Chico	Dr. N. T. Enloe	District Surgeon.
Chico	Dr. D. H. Moulton	Associate District Surgeon.
Chico	Dr. J. H. Belyea	District Surgeon.
Los Molinos	Dr. F. J. Bailey	District Surgeon.
Gerber	Dr. W. E. Bates	Emergency Surgeon.
Davis	Dr. Thomas E. Cooper	Emergency Surgeon.
Davis	Dr. H. D. Lawhead	Consulting Surgeon.
Woodland	Dr. Fred R. Fairchild	District Surgeon.
Woodland	Dr. H. S. Powis	District Surgeon.
Arbuckle	Dr. C. F. Keith	Acting District Surgeon.
Williams	Dr. C. O. Poage	District Surgeon.
Colusa	Dr. C. W. Lund	District Surgeon.
Willows	Dr. S. Iglick	District Surgeon.
Orland	Dr. A. L. Derbyshire	District Physician and Surgeon.
Stirling City	Dr. H. H. Beck	District Surgeon.
Corning	Dr. E. A. Kusel	District Surgeon.
Oroville	Dr. G. M. Kennedy	Emergency Surgeon.
Fair Oaks	Dr. L. H. Sanborn	Emergency Surgeon.
Folsom	Dr. W. A. Reckers	District Surgeon.
Placerville	Dr. Mary B. Poket	Emergency Surgeon.
Hamilton	Dr. Smith McMullen	District Surgeon.
Yuba City	Dr. John F. Drew	District Surgeon.
Walnut Grove		

NOTE.—Emergency Surgeons should only be summoned for temporary treatment when prompt attention is required and when patients cannot be sent to or await arrival of Division or District Surgeon.

RATING OF LOCOMOTIVES—SACRAMENTO DIVISION—In M's of 1000 lbs. back of Tender.

Revised to April 26, 1931

NOMINAL CLASS	OFFICIAL CLASS	ENGINE NUMBERS	Boiler Pressure	Sacramento and Gerber via Roseville	Roseville to Colfax via Eastward Track	Colfax to Sparks Roseville to Colfax via Westward Track	Sparks to Truckee	Truckee to Summit	Davis and Gerber Davis and Marysville	Placerville to Folsom	Folsom to Placerville	Folsom to Sacramento	Sacramento to Folsom	Chico to Stirling City	Stirling City to Chico
E-23	E-73 20/24 92	1433 to 1458	190	3310	720	450	1160	530	2780						
E-23	E-73 20/24 101 S.	1438 to 1458	190	3430	750	470	1200	550	2890	1060	560	2990	1880		
E-24	E-69 18/26 73	1459 to 1463	165	2580					2100			2260	1410		
E-24	E-69 18/26 74	1464 to 1467, 1469, 1471	165	2580					2100			2260	1410		
E-25	E-69 18/26 72	1470, 1472, 1477, 1478	160	2510					2050			2190	1380		
E-27	E-73 20/26 113 S.	1526 to 1540	210	4000					3100						
M-4	M-63 20/28 126														
M-4	M-63 20/28 128 S.	1615 to 1719	190	4280	1050	690	1630	800	3380	1240	780	3740	2300		
M-4	M-63 20/28 135 S.														
M-6	M-63 21/28 150 S.	1725 to 1769, 1780 to 1803	200	5260	1300	870	2020	1000	4160	1550	990	4610	2840	530	980
M-6	M-63 21/28 153 S.	1823 to 1825	200	5260	1300	870	2020	1000	4160	1550	990	4610	2840	530	980
M-9	M-63 21/28 150 S.	1804 to 1822	210	5540	1390	930	2140	1060	4390	1630	1050	4850	2990	570	1050
M-9	M-63 21/28 156 S.	1826, 1827	210	5540	1390	930	2140	1060	4390	1630	1050	4850	2990	570	1050
T-8	T-57 18/24 87	2174, 2176 to 2179, 2181, 2183	160	2780					2220			2430	1500	250	490
T-2	T-63 20/26 105	2221 to 2234	160	2830					2310			2470	1560	220	460
T-1	T-63 20/28 112	2235 to 2273	180	3840	900	590	1420	680	3920	1110	700	3360	2090	370	700
T-25	T-69 26/28 134	2275 to 2280	200	4220	980	630	1550	730	3430	1180	720	3690	2320	360	720
T-26	T-69 21/28 152 S.	2283 to 2300	200	4800	1150	750	1800	870	3900	1380	860	4230	2680	440	860
T-23	T-63 21/28 148 S.	2301 to 2310	210	5550	1380	920	2130	1060	4400	1650	1060	4860	3000	560	1040
T-28	T-63 22/28 162 S.	2311 to 2362	210	6060	1520	1020	2340	1160	4800	1800	1150	5310	3270	630	1150
T-32	T-69 23/28 174 S.	2363 to 2370	210	6170	1470	970	2300	1120	5040	1800	1140	5400	3440		
C-11	C-51 22/26 152	2502	180	5170					4050	1550	1000	4490	2770	550	1100
C-12	C-50 20/28 164	2503	190	4760					3720	1380	870	4160	2520	580	1080
C-9, 10	C-57 22/30 200 SF.	2513 to 2599, 2752 to 2860													
C-9, 10	C-57 22/30 194 S.														
C-8	C-57 22/30 192 S.	2698 to 2749, 2750, 2751	210	6660	1680	1130	2600	1290	5220	1980	1280	5790	3560		
C-5	C-57 22/30 187 S.	2624 to 2679													
C-5	C-57 22/30 185 S.	2680 to 2693													
C-5	C-57 22/30 180	2624 to 2679													
C-5	C-57 22/30 178	2680 to 2693	200	5930	1460	970	2280	1110	4640	1750	1110	5140	3150		
TW-1	TW-54 22/26 147	2900 to 2913	180	5070	1260	840	1960	960	3960	1490	950	4450	2690	500	950
TW-8	TW-54 21/32 161 S.	2914 to 2923	190	5660	1430	960	2220	1100	4430	1680	1080	4730	3020	600	1120
TW-8	TW-54 21/32 155	2914 to 2923	180	5020	1260	840	1960	960	3920	1470	930	4190	2660		
TW-4	TW-56 20/30 120	2928, 2930, 2931	160	3920	940	610	1480	710	3070	1160	740	3430	2090	400	740
Mk2	Mk57 23 1/30 206 S.	3200 to 3240	210	7830	2000	1350	3050	1540	6130	2340	1520	6800	4190		
Mk4	Mk57 23 1/30 206 S.														
Mk5, 6	Mk63 26/28 210 S.	3241 to 3277	210	8000	2100	1400	3250	1600	6700	2500	1600	7400	4550		
F-1	F-63 27 1/32 273 S.	3600 to 3652	200	8000	2420	1620	3650	1850							
F-4, 5	F-63 29 1/32 306/B-61 SF.	3668 to 3763	200	8000	2730	1820	4150	2090							
F-5	F-63 29 1/32 306/B-62 SF.	3764 to 3768													
MC-2	MC-57 2 1/2-40 394	4000 to 4016													
MC-4	MC-57 2 1/2-40 398	4017 to 4028													
MC-6	MC-57 2 1/2-40 401 S.	4029 to 4043	210	8000	3250	2200	4950	2500							
MC-6	MC-57 2 1/2-40 395 S.	4044 to 4048													
AC-1,2,3	AC-57 2 1/2-40 441 SF.	4000 to 4048													
AC-4	AC-63 2 1/2-40 475 SF.	4100 to 4109													
AC-5	AC-63 2 1/2-40 483 SF.	4110 to 4125	235	8000	4100	3000	6300	3450							
AC-6	AC-63 2 1/2-40 517 SF.	4126 to 4150	250	8000	4450	3250	6800	3700							
MM-2	MM-63 2 1/2-40 320 SF.	4200 to 4211	200	8000	2450	1630	3750	1870							
MT-1,3,4,5	MT-73 28/30 246/B-60 SF.	4300 to 4376	210	8000	2250	1450	3650	1700	7650						
SP-1	SP-63 2 1/2-40 316/B-60 SF.	5000 to 5015	225	8000	3150	2100	4800	2400							
SP-2	SP-63 2 1/2-40 317/B-61 SF.	5016 to 5048													
P-1,3,5	P-77 22/28 141 S.	2400 to 2452, 2459, 2460	210	4980	1140	730	1820	850	4080	1390	840	4350	2780		
P-1	P-77 22/28 152 SF.	2400 to 2427	210	5350	1180	760	1900	880	4400	1440	870	4700	3000		
P-1	P-77 22/28 160/B-54 S.	2400 to 2427													
P-1	P-77 23/28 163/B-54 SF.	2409, 2422	210	5850	1280	810	2050	950	4800	1560	930	5100	3200		
P-4	C-77 23/28 155/B-58 SF.	2400 to 2437	210	5850	1280	810	2050	950	4800	1560	930	5100	3200		
GS-1	GS-73 27/30 262/B-58 SF.	4400 to 4409	250	8000	2350	1550	3800	1800	8000						

AVERAGE TARE WEIGHTS OF PASSENGER TRAIN CARS

CLASS	All Steel	Steel Underframe	Wood
Baggage—60 ft.	93,070		
—66 ft.	127,610		
—70 ft.	122,620		
(Dynamo)	98,730	87,120	81,120
and Mail—60 ft.	103,620		
—69 ft.	124,760		
—70 ft.	129,140		
and Passenger	108,675	103,590	99,200
—CM&StP	125,000	112,640	76,320
Express Refr.—NP RR.		74,000	60,000
—GN RR.			70,000
—ARE No. 40-154		78,000	
—155-224		89,000	
—500-506		110,000	
—1101-1175		85,000	
—PFE 500-799		83,000	
Tea & Silk			48,180
Express, Horse	133,050		81,033
Postal	112,120		
Storage—40 ft.	74,530		
—60 ft.	105,120		
Club	145,210	122,300	
Official	170,700	155,370	109,370
—CM&StP	141,000		
Chair	100,620		84,740
Coaches—60 ft.	98,130		
—70 ft.	137,640		
—72 ft.	139,660		
—73 ft.	148,040		
—72 ft. Interurban	120,000		
—CM&StP	133,000		
All-Day Lunch—Chair	105,970		
—Coach	103,875		
Cafe-Coach			117,200
Diner—70 ft.		135,930	131,040
—72 ft.	155,330	146,930	134,530
—77 ft.	157,240	165,530	
—79 ft.	169,100		
Cafe-Observation	148,950		128,550
Observation		141,870	121,300
Pullman—Observation	163,600	153,000	
—Parlor	155,600	147,500	
—Standard Sleeper	164,600	144,000	
—Tourist	140,600	133,000	
CM&StP—Tourist Sleeper	141,000		
Rail Car—Gas & Electric	143,360		
—McKeen—55 ft.	64,140		
—70 ft.	71,530		
Observation (Open Top)			62,000

MILEAGE

Main Lines

End Western Division to Sacramento	S. P. R. R.	29
Sacramento to Lawton	C. P. Ry.	147.73
At Elvas	C. P. Ry.	.31
Brighton to Elvas	C. P. Ry.	4.13
Davis to Tehama	S. P. R. R.	109.71
Roseville to Gerber	C. P. Ry.	105.92
Total Main Lines		368.09

Branches

Colusa	S. P. R. R.	Harrington to Wyo.	71.66
Dantoni	C. P. Ry.	Dantoni Jet. to Dantoni	4.46
Fair Oaks	S. P. R. R.	Citrus to Fair Oaks	2.14
Fruto	S. P. R. R.	Willows to Fruto	17.20
Knights Landing	S. P. R. R.	Woodland to West of Cunard	9.71
	S. P. Co.	West of Cunard to Grace	1.20
	S. P. R. R.	Grace to Binney Junction	26.23
Lake Tahoe	S. P. Co.	Truckee to Lake Tahoe	14.73
Oroville	S. P. R. R.	Bin	

