

SOUTHERN PACIFIC LINES

TEXAS AND NEW ORLEANS RAILROAD COMPANY

TIME TABLE

FOR THE

SAN ANTONIO DIVISION

176

To Take Effect Sunday, December 6, 1942, at 12:01 A. M.

CENTRAL STANDARD TIME

For the government and information of employes only.

A. D. MIMS,
Vice President and General Manager

B. S. HOLLIMON,
Assistant General Manager

T. B. OLLIS,
Acting Superintendent of Transportation

INTERLOCKING WHISTLE CODES

TOWER 6, EL PASO

Main track movements in either direction with current of traffic
Main track movements in either direction against current of traffic

T. & N. O. Union Depot connection, from any direction
S. P. Co. main track East and West
S. P. Co. connection to and from Union Depot
(NOTE.—Top arm signal at switch leading to Union Depot governs route to Union Depot track. The lower arm governs the route to either the T. & N. O. or Pacific Lines Freight Yard.)

TOWER 47, EL PASO

Main track movements in either direction with current of traffic
Main track movements in either direction against current of traffic

North lead, Eastward
North lead, Westward
South lead, Eastward
South lead, Westward
To T. & P. main track
Westward to west yard
To East Yard
Eastward to West Yard
From Alamogordo Subdivision to T. & N. O. yard
From Alamogordo Subdivision to West Yard
From T. & N. O. yard to Alamogordo Subdivision
From west yard to Alamogordo Subdivision
S. P. Shop Lead Track Eastward from any point
S. P. Shop Lead Track Westward from any point
S. P. Enginehouse Lead Track Eastward
S. P. Enginehouse Lead Track Westward

TOWER No. 105, I-G. N. and S. A. B. & T. CROSSINGS, SAN ANTONIO

For westward main track with current of traffic from any point
Westward main track against current of traffic from any point
Eastward main track with current of traffic from any point
Eastward main track against current of traffic from any point
Union Stock Yard lead from any point

TOWER No. 112, S. A. B. & T. CROSSING, SAN ANTONIO

Westward main track with current of traffic from any point
Westward main track against current of traffic from any point
Eastward main track with current of traffic from any point
Eastward main track against current of traffic from any point
To Victoria Division from any point
To Kerrville Subdivision from any point

TOWER No. 109, S. A. B. & T. CROSSING (Kerrville Subdivision) SAN ANTONIO

Main track from any point
To S. A. B. & T.

TOWER No. 121, OLIVE STREET, SAN ANTONIO

Westward main track with current of traffic from any point
Eastward main track with current of traffic from any point
East Yard from any point
Enginehouse lead from any point
Industry Yard from any point

Note.—A buzzer located on corner of enginehouse will be used in lieu of engine whistle for all outbound engine movements from enginehouse, using above code.

Engines moving westward over Hackberry Street on auxiliary track must approach interlocking switch, located just west of Hackberry Street, expecting to find it lined for either route.

Yard engines moving through Interlocking plant from vicinity of Burleson Street, will first communicate with signal operator from Burleson Street crossing tower.

TOWER No. 3, T. & N. O. CROSSING, FLATONIA

Main track from any point
To south siding from any point
To north siding from any point
To Dallas and Austin Divisions from any point

TOWER No. 115, T. & N. O. and G. C. & S. F. CROSSINGS, EAGLE LAKE

Main track, Glidden Subdivision, eastward from any point
Main track, Glidden Subdivision, westward from any point
Main track, Bellaire Subdivision, from any point
Main track, Yoakum Subdivision, from any point
To Glidden Subdivision siding from any point
To Rice Mill Spur from any point

East end ice track switch and Alamo Lumber Co. Spur switch are electrically locked and cannot be hand operated until released by signal operator. Telephone located on pole just east of Rice Mill track.

TOWER No. 17, G. C. & S. F. CROSSING, ROSENBERG

Main Track from any point
To west siding from any point
To east siding from any point
Victoria Division from any point
G. C. & S. F. from any point

TOWER No. 114, S. L. Ry. CROSSING, SUGAR LAND

Main track
During the hours an operator is not on duty, plant will be operated as a cabin-interlocker. The normal position of signals and derails will be for San Antonio Division main track.

TOWER No. 13, EUREKA

Main track for movement with the current of traffic, from main track except San Antonio Division main track westward
San Antonio Division main track westward
Eastward main track eastward, from any other point
Westward main track westward, from any other point
Eastward main track westward, from any point
Westward main track eastward, from any point
To Wye track, from any point

TOWER No. 134, I-G. N. CROSSING, STELLA

(Cabin Interlocker)

All trains must be governed by signal indication. Normal position of signals for trains on T. & N. O. main track is "proceed." If signal is in stop position member of crew will operate plant in accordance with instructions located within cabin interlocker.

TOWER No. 30, T. & N. O. and G. H. & H. CROSSINGS, HARRISBURG

To Houston Division main track, from any point
Glidden Subdivision main track, from any point
To saw mill, from any point
To Cut Off between Harrisburg and Manchester
Eastward trains must approach Harrisburg WITH CAUTION and stop clear of east switch to siding unless home interlocking signal indicates proceed.

TOWER No. 81, G. C. & S. F. CROSSING, (Glidden Subdivision)

Glidden Subdivision main track eastward or westward
Transfer from any point

BETWEEN TOWER 86 AND HARRISBURG

Signal 45 on signal bridge west of Tower 86 governs movements from that point to Harrisburg.

Signal 70 at Harrisburg governs movements from that point to signal bridge west of Tower 86.

Yard engines may operate between Tower 86 and Harrisburg in accordance with rules governing yard movements and in accordance with positive block signal indications, but must not occupy main track when it is known a first-class train will thereby be delayed.

TOWER 86, H. B. & T. CROSSING

Main track for movement with the current of traffic from any point
Eastward main track eastward from any point
Westward main track eastward from any point
Bethlehem Supply Co. Spur from any point

TOWER 26, I-G-N, H. B. & T. and T. & N. O. CROSSINGS BETWEEN SEMMES JUNCTION, ENGLEWOOD, and NORTH YARD

Main track for movement with the current of traffic, from main track
Eastward main track eastward from any other point
Westward main track westward from any other point
Eastward main track westward, from any point
Westward main track eastward from any point
Cooperative Mill track, from any point
Shreveport Line Transfer, from any point
Shreveport Line connection, from any point
Freight house transfer, from any point
Old Head, from any point
H. B. & T. interchange, from any point
Icing Plant, from any point
I-G. N. interchange, from any point
Freight main track westward, from any point
Inbound Enginehouse Lead from any point
Outbound Enginehouse Lead from any point
New Lead from any point

TOWER 68, WEST END ENGLEWOOD

Main track for movement with the current of traffic, from main track
Eastward main track eastward from any other point
Westward main track westward, from any other point
Eastward main track westward from any point
Westward main track eastward from any point
West leg of wye, from any point
Polk Avenue lead, from any point
Creosote No. 1, from any point
Creosote No. 2, from any point
South Switching lead, from any point
Middle Switching lead, from any point
North Switching lead, from any point
Freight Main West from any point
Freight Main East from any point
Old Wye from any point
New Wye from any point
26 lead from any point
For ice house track
New lead from any point

AUTOMATIC INTERLOCKING PLANT

I-G. N. Crossing, MP 5.6 east of Harrisburg
Normal position of governing signals is STOP.

Signals governing route through plant should clear when train enters approach circuit if intersecting route is not occupied. When train enters approach circuit and signals do not clear, send member of crew to crossing to ascertain conditions. If a train on intersecting route is observed standing on approach circuit or moving away from interlocking plant, member of crew will unlock box marked "T. & N. O. RELEASE", turn knob on the release to the right as far as it will go, then permit it to run down, after which signal should assume PROCEED position.

If a train on intersecting route is observed approaching crossing, release must not be operated until such train has passed the crossing or has stopped.

If member of crew at crossing cannot see a train on intersecting route and home signal fails to assume PROCEED position, he should immediately operate release as described above and, if home signal then fails to clear, train must be governed by Paragraph (c), Rule 663.

INTERLOCKING PLANT No. 51, G. C. & S. F. CROSSING, WALLIS, PASSENGER STATION

Main track

COMPANY SURGEONS

Table with 3 columns: Location, Name, Title. Lists various locations and the names and titles of company surgeons at those locations.

General Hospital—

Southern Pacific Hospital, Thomas Street, between James and Paschal, Houston.

Emergency Hospital—

Hotel Dieu, El Paso. Medical & Surgical Clinic, Del Rio. Santa Rosa Infirmary, San Antonio.

EASTWARD

EL PASO SUBDIVISION

WESTWARD

Length of sidings in cars, location of bulletin, water and fuel stations, standard clocks, interlocking plants, turn tables, wyes and tele-phones.	SECOND CLASS					FIRST CLASS				Distance From El Paso	TIME TABLE No. 176 December 6, 1942 CENTRAL STANDARD TIME	Mile Post Location	FIRST CLASS				SECOND CLASS		Train Order Office Hours and Hours of Signal Operators at Interlocking Stations	
	566 T. & P. Freight	244 Freight	564 T. & P. Freight	242 Freight	246 Freight	6 Argonaut	512 T. & P. Sunshine Special	506 T. & P. Texas Ranger	2 Sunset Limited				511 T. & P. Sunshine Special	5 Argonaut	507 T. & P. Texas Ranger	1 Sunset Limited	245 Freight	241 Freight	Daily Ex. Sundays and Legal Holidays	Sundays and Legal Holidays Only
	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily				Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily		
BKP I						10.30PM	10.20PM	12.30PM	11.20AM	0.0	TOWER 6 R EL PASO (Union Depot)	829.3	8.30AM	10.40AM	7.00PM	8.10PM			Continuous Closed	Continuous Closed
YWPBK Yard		4.10PM		9.10AM	1.10AM	10.36	10.26	12.36	11.26	1.6	TO-R EL PASO (Cotton Ave)	827.7	8.22	10.32	6.52	8.02	5.35AM	9.20PM	Continuous	Continuous
I	6.15PM		10.01AM							1.8	(Tower 47 S. P. and T. & P. Conn.)	827.5							Continuous	Continuous
Yard P	6.27	4.25	10.13	9.25	1.25	10.46	10.36	12.47	11.37	6.5	ALFALFA	822.8	8.09	10.19	6.40	7.48	5.18	9.00		
51 P	6.39	4.37	10.25	9.37	1.37	10.55	10.43	12.57	11.46	12.6	TO YSLETA	816.7	7.59	10.09	6.30	7.38	5.08	8.48	Continuous	Continuous
P	6.42	4.40	10.28	9.40	1.40	10.57	10.45	12.59	11.48	14.1	BELEN	815.2	7.56	10.06	6.27	7.35	5.05	8.45		
79 P	6.55	4.53	10.41	9.53	1.53	11.07	10.55	1.14	11.58AM	22.0	OLINT	807.8	7.44	9.53	6.14	7.22	4.52	8.32		
E66 PW Will	7.12	5.05	10.53	10.05	2.05	11.17	11.03	1.25	12.07PM	29.2	TO FABENS	800.1	7.33	9.43	6.04	7.12	4.41	8.21	Continuous	Continuous
77 P	7.25	5.15	11.03	10.15	2.15	11.24	11.10	1.34	12.14	35.0	TORNILLO	794.8	7.25	9.35	5.53	7.04	4.32	8.10		
84 P	7.35	5.24	11.11	10.23	2.23	11.30	11.16	1.41	12.20	39.6	POLVO	789.7	7.19	9.29	5.46	6.58	4.24	8.01		
72 P	7.53	5.37	11.22	10.34	2.34	11.39	11.25	1.50	12.29	45.8	ISER	783.5	7.10	9.20	5.37	6.49	4.13	7.53		
71 PW	8.08	5.48	11.34	10.46	2.46	11.49	11.35	2.03	12.39	53.2	TO FORT HANCOCK	776.1	7.00	9.10	5.26	6.39	4.01	7.40	Continuous	Continuous
86 P	8.16	5.56	11.42	10.54	2.55	11.55PM	11.41	2.10	12.45	57.9	MENARY	771.4	6.52	9.02	5.17	6.31	3.52	7.30		
71 P	8.25	6.05	11.51AM	11.03	3.04	12.02AM	11.48	2.17	12.52	63.1	MADDEN	766.2	6.45	8.55	5.10	6.24	3.43	7.21		
71 P	8.35	6.18	12.01PM	11.13	3.14	12.12	11.54PM	2.24	12.58	66.7	RAMEY	762.6	6.39	8.49	5.03	6.18	3.34	7.12		
71 P	8.45	6.30	12.11	11.23	3.24	12.20	12.01AM	2.32	1.05	70.7	FINLAY	758.6	6.31	8.41	4.55	6.10	3.24	7.02		
105 PW	9.05	6.51	12.30	11.43	3.45	12.30	12.09	2.41	1.13	75.9	TO SMALL	758.4	6.23	8.33	4.46	6.02	3.10	6.51	Continuous	Continuous
81 P	9.17	7.03	12.42	11.56AM	3.56	12.39	12.17	2.50	1.22	79.6	TOROER	749.7	6.15	8.25	4.37	5.54	3.00	6.41		
72 P	9.30	7.17	12.55	12.08PM	4.09	12.48	12.26	3.00	1.30	83.8	LASCA	745.5	6.07	8.17	4.28	5.46	2.50	6.31		
79 P	9.43	7.30	1.08	12.20	4.22	12.57	12.34	3.10	1.39	88.0	ETHOLEN	741.3	5.59	8.09	4.19	5.38	2.40	6.21		
157 PO	9.55PM	7.38	1.20PM	12.30	4.30	1.10	12.40AM	3.20PM	1.46	92.4	TO-R SIERRA BLANCA	736.9	5.50AM	8.01	4.10PM	5.30	2.30	6.11	Continuous	Continuous
72 P		7.46		12.38	4.38	1.16			1.53	97.1	MALLIE	732.2		7.51		5.21	2.19	5.59		
51 P		7.55		12.47	4.47	1.22			1.59	102.3	GRAYTON	727.0		7.45		5.15	2.11	5.51		
72 P		8.03		12.57	4.55	1.28			2.04	106.7	BOLA	722.6		7.39		5.09	2.03	5.43		
72 P		8.11		1.07	5.03	1.34			2.10	111.3	TORBERT	718.0		7.33		5.03	1.55	5.35		
71 PW		8.19		1.14	5.11	1.39			2.15	115.6	TO HOT WELLS	713.7		7.27		4.57	1.39	5.27	6.00PM 3.00AM	6.00PM 3.00AM
51 P		8.28		1.23	5.19	1.45			2.21	120.6	DALBERG	708.7		7.20		4.50	1.29	5.15		
69 P		8.37		1.32	5.28	1.52			2.28	125.6	COLLADO	703.7		7.12		4.42	1.21	5.07		
71 P		8.45		1.40	5.36	1.57			2.33	129.4	FAY	699.9		7.05		4.35	1.13	4.59		
77 PW		9.00		1.55	5.51	2.09			2.45	133.8	LOBO	695.5		6.58		4.28	1.05	4.51		
50 P		9.12		2.07	6.05	2.19			2.55	139.5	DANUBE	689.8		6.50		4.20	12.55	4.41		
61 P		9.22		2.17	6.18	2.27			3.03	145.1	CHISPA	684.2		6.42		4.12	12.45	4.31		
71 P		9.34		2.29	6.32	2.37			3.13	153.0	WENDELL	676.8		6.32		4.02	12.32	4.19		
51 P		9.41		2.36	6.45	2.42			3.18	156.9	RUBIO	672.4		6.26		3.56	12.24	4.11		
BKWOPY Yard		9.50PM		2.45PM	6.55AM	2.50AM			3.25PM	161.5	TO-R VALENTINE	667.8		6.20AM		3.50PM	12.15AM	4.01PM	Continuous	Continuous
	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily			Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily			
	566	244	564	242	246	6	512	506	2			511	5	507	1	245	241			

.....Time Over Subdivision.....
.....Average Speed per Hour.....

Eastward Trains are Superior to Trains of the Same Class in the Opposite Direction. (See Rule S-72) Except No. 1 is Superior to No. 506, and No. 5 is Superior to No. 512.

Nos. 564 and 566 must obtain a clearance at T. & P. train-order office, El Paso, authorizing movement from Tower 47. Nos. 2, 506, 6 and 512 must obtain a clearance at El Paso (Cotton Avenue).
Schedule time and train orders for trains to or from T. & P. Ry. at Sierra Blanca will apply at T. & P. passenger connection switch, which is the first remote-control switch west of depot.
See Item 42, Special Instructions, Page 12, regarding train movements between Tower 47 and Tower 6.
See Page 15 for additional flag stops to entrain or detrain revenue passengers.

EASTWARD

VALENTINE SUBDIVISION

WESTWARD

Length of sidings in cars, location of bulletin, water and fuel stations, standard clocks, interlocking plants, turn tables, eyes and tele-phones.	SECOND CLASS				FIRST CLASS		Distance From Valentine	TIME TABLE No. 176 December 6, 1942	Mile Post Location	FIRST CLASS		SECOND CLASS			Train Order Office Hours and Hours of Signal Operators at Interlocking Stations			
	244	330	242	246	2	6				5	1	241	329	245	Daily Ex. Sundays and Legal Holidays	Sundays and Legal Holidays Only		
	Freight	Sante Fe Mixed	Freight	Freight	Sunset Limited	Argonaut				Argonaut	Sunset Limited	Freight	Sante Fe Mixed	Freight				
	Leave Daily	Leave Mon., Wed. and Fri.	Leave Daily	Leave Daily	Leave Daily	Leave Daily				Arrive Daily	Arrive Daily	Arrive Daily	Arrive Tues., Thur. and Sat.	Arrive Daily				
BKWOYP Yard	9.45PM		4.20PM	7.25AM	3.35PM	3.00AM	0.0	TO-R VALENTINE 7.5	667.8	6.10AM	3.35PM			2.10PM		1.20AM	Continuous	Continuous
77 P	10.05		4.40	7.45	3.47	3.13	7.5	QUEBEC 8.0	660.8	5.55	3.20			1.55		1.05		
66 P	10.20		4.55	8.00	3.57	3.24	15.5	RYAN 9.9	652.8	5.44	3.10			1.40		12.50		
77 P	10.45		5.15	8.20	4.09	3.36	25.4	ARAGON 9.6	642.4	5.28	2.54			1.20		12.30		
67 PW	11.10		5.35	8.45	4.26	4.01	35.0	MARFA 6.5	632.8	5.13	2.39			12.58		12.07AM	Continuous	Continuous
50 P	11.25		5.50	9.00	4.38	4.13	41.5	NOPAL 6.8	626.8	4.58	2.24			12.46		11.52PM		
80 P	11.40PM	7.10PM	6.05	9.18	4.48	4.23	48.8	PAISANO 7.0	619.5	4.48	2.14			12.35PM	9.25PM	11.40		
75 P						4.32	55.8	TORONTO 4.0	612.5	4.32								
		7.50PM					59.8	ALPINE JUNCTION 1.3	608.5						8.45PM			
77 Yard WP	12.10AM		6.35	9.43	5.08	4.53	60.6	ALPINE 7.0	607.2	4.18	1.46			11.55AM		11.05	Continuous	Continuous
72 P	12.22		6.47	9.55	5.19	5.05	67.6	STROBEL 8.7	600.2	3.59	1.31			11.32		10.50		
72 P	12.34		6.59	10.07	5.31	5.18	76.8	ALTUDA 6.9	591.5	3.46	1.18			11.15		10.35		
72 P	12.46		7.10	10.18	5.40	5.28	83.2	LENOX 8.6	584.6	3.33	1.04			10.59		10.20		
75 POW	1.01		7.25	10.37	5.55	5.43	91.8	MARATHON 8.4	576.0	3.17	12.48			10.37		10.00	Continuous	Continuous
72 P	1.16		7.40	10.52	6.07	5.58	100.2	WARWICK 7.2	567.6	3.01	12.33			10.22		9.43		
76 P	1.30		7.55	11.05	6.18	6.10	107.4	HAYMOND 8.5	560.4	2.49	12.22			10.08		9.28		
75 PW	1.45		8.10	11.18	6.30	6.23	115.9	TESNUS 8.6	551.9	2.35	12.08			9.53		9.12	6.00PM to 8.00AM	6.00PM to 8.00AM
51 P	1.53		8.20	11.26	6.37	6.31	119.5	MAXON 7.4	548.8	2.26	12.01PM			9.41		8.57		
71 P	2.11		8.40	11.47AM	6.49	6.45	126.9	ROSENFELD 8.7	540.9	2.11	11.47AM			9.26		8.40		
71 PW	2.26		8.55	12.02PM	7.00	6.57	135.6	LONGFELLOW 7.8	532.2	1.55	11.32			9.09		8.10		
76 P	2.41		9.10	12.16	7.11	7.09	143.4	EMERSON 8.5	524.4	1.39	11.18			8.52		7.50		
Yard BKWOYP	3.00AM		9.30PM	12.40PM	7.25PM	7.25AM	151.9	SANDERSON	515.9	1.20AM	11.00AM			8.30AM		7.25PM	Continuous	Continuous
	Arrive Daily	Arrive Mon., Wed. and Fri.	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily				Leave Daily	Leave Daily			Leave Daily	Leave Tues., Thur. and Sat.	Leave Daily		
	244	330	242	246	2	6				5	1			241	329	245		

(5.15)	(0.40)	(5.10)	(5.15)	(8.50)	(4.25) Time Over Subdivision	(4.50)	(4.35)	(5.40)	(0.40)	(5.55)
28.6	16.5	29.4	28.6	39.7	36.4 Average Speed per Hour	31.4	33.2	26.4	16.5	25.6

Eastward Trains are Superior to Trains of the Same Class in the Opposite Direction. (See Rule S-72)

Eastward trains entering Sanderson freight yard will use crossover about opposite stock pens, but if necessary for eastward trains to enter yard at the extreme west end, spring switch must be thrown by hand.

See Page 15 for additional flag stops to entrain or detrain revenue passengers.

EASTWARD

SANDERSON SUBDIVISION

WESTWARD

Length of sidings in cars, location of bulletin, water and fuel stations, standard clocks, interlocking plants, turn tables, wyes and tele-phones.	SECOND CLASS			FIRST CLASS		Distance From Sanderson	TIME TABLE No. 176 December 6, 1942	Mile Post Location	FIRST CLASS		SECOND CLASS		Train Order Office Hours		
	242	246	244	2	6				1	5	241	245	Daily Except Sundays and Legal Holidays	Sundays and Legal Holidays Only	
	Freight	Freight	Freight	Sunset Limited	Argonaut				Sunset Limited	Argonaut	Freight	Freight			
	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily				Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily			
WOPYBK Yard	8.25PM	12.55PM	3.35AM	7.40PM	7.40AM	0.0	TO-R SANDERSON	511.9	10.45AM	1.05AM		7.40AM	4.55PM	Continuous	Continuous
71 P	8.45	1.10	3.50	7.52	7.53	8.4	8.4 FEODORA	508.5	10.28	12.48		7.12	4.28		
78 P	9.00	1.25	4.05	8.03	8.05	14.7	6.3 MOFETA	497.2	10.17	12.36		6.57	4.13		
49 WP	9.15	1.40	4.20	8.14	8.16	21.8	7.1 DRYDEN	490.1	10.05	12.24		6.42	3.59	Continuous	Continuous
49 P	9.25	1.50	4.30	8.23	8.26	28.4	6.6 THURSTON	488.5	9.54	12.13		6.27	3.44		
69 P	9.35	2.00	4.40	8.31	8.35	34.1	5.7 WATKINS	477.8	9.44	12.03AM		6.13	3.30		
50 P	9.46	2.11	4.51	8.40	8.46	40.7	6.6 MALVADO	471.2	9.34	11.53PM		6.00	3.17		
55 P	9.55	2.20	5.00	8.47	8.54	45.5	4.8 LOZIER	466.4	9.26	11.45		5.48	3.05		
66 WP	10.20	2.45	5.25	9.02	9.12	53.8	7.3 PUMPVILLE	458.6	9.12	11.32		5.25	2.45		
76 P	10.37	3.02	5.42	9.15	9.26	61.4	4.9 OSMAN	450.5	8.57	11.15		4.53	2.15		
E50 W51 POW	11.01	3.16	5.56	9.25	9.36	68.6	7.2 LANGTRY	448.8	8.45	11.01		4.35	2.00	Continuous	Continuous
50 P	11.20	3.29	6.09	9.36	9.48	74.8	6.2 DOBBO	437.1	8.35	10.50		4.22	1.47		
84 P	11.35	3.41	6.21	9.45	9.58	80.7	5.9 SHUMLA	431.2	8.26	10.42		4.10	1.35		
WP	11.55PM	4.00	6.40	9.56	10.10	84.3	3.6 HIGH BRIDGE	427.6	8.18	10.34		3.55	1.20		
53 P	12.11AM	4.16	6.55	10.03	10.18	88.0	3.7 VIADUCT	423.9	8.03	10.19		3.40	1.05		
51 P	12.21	4.26	7.05	10.10	10.26	92.8	4.8 RONA	419.1	7.55	10.10		3.29	12.54		
54 P	12.32	4.36	7.15	10.20	10.38	98.2	5.4 OOMSTOOK	413.7	7.47	9.58		3.17	12.42	Continuous	Continuous
52 P	12.43	4.46	7.38	10.30	10.48	103.1	4.9 CABRA	408.8	7.38	9.48		3.04	12.29		
48 P	12.53	4.56	7.48	10.38	10.57	107.8	4.7 FEELY	404.1	7.30	9.40		2.52	12.17		
72 P	1.03	5.06	7.58	10.46	11.06	113.1	5.3 BULLIS	398.8	7.22	9.32		2.40	12.05PM		
72 WP	1.15	5.16	8.10	10.56	11.16	118.6	5.5 DEVIL'S RIVER	393.8	7.11	9.20		2.20	11.45AM		
51 P	1.30	5.31	8.25	11.06	11.26	124.6	6.0 MOKKES	387.8	7.01	9.08		2.05	11.26		
WOTPYBK Yard	1.50AM	5.50PM	8.40AM	11.25PM	11.45AM	133.3	8.7 TO-R DEL RIO	378.6	6.50AM	8.55PM		1.50AM	11.00AM	Continuous	Continuous
	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily				Leave Daily	Leave Daily		Leave Daily	Leave Daily		
	242	246	244	2	6				1	5		241	245		

..... Time Over Subdivision (3.55) (4.10)
 Average Speed per Hour 34.0 31.9 (5.50) (5.55)

Eastward Trains are Superior to Trains of the Same Class in the Opposite Direction. (See Rule S-72)

At Langtry, time and train orders for westward trains apply at west switch of east siding, and for eastward trains at east switch of west siding.
 Class F-1, GS-1 and F-5 engines must not go beyond 90 pound rail in old coal track Shumla.
 See Page 15 for additional flag stops to entrain or detrain revenue passengers.

Main tracks at High Bridge will be designated as double track and double track rules will apply. Current of traffic to the left. The limits of double track extend from MP 427.15 to MP 423.10, and car capacity of each track between fouling point is 91 cars. Spring switches located at each end of double track, normal position for movement with the current of traffic. Trains may trail through these switches when normally set.

EASTWARD

DEL RIO SUBDIVISION

WESTWARD

Length of siding in use, location of bulletin, water and fuel stations, standard clocks, interlocking plants, turn tables, wye and tele-phones.	THIRD CLASS				SECOND CLASS			FIRST CLASS		Distance from Del Rio	TIME TABLE No. 176 December 6, 1942	Mile Post Location	FIRST CLASS		SECOND CLASS		THIRD CLASS		Train Order Office Hours and Hours of Signal Operator at Interlocking Stations	
	86	246	244	242	2	6	1	5	245				241	85	Daily Ex. Sun. and Legal Holidays	Sundays and Legal Holidays Only				
	Local Freight	Freight	Freight	Freight	Sunset Limited	Argonaut	Sunset Limited	Argonaut	Freight				Freight	Local Freight						
	Leave Daily Ex. Monday	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Arrive Daily	Arrive Daily			Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily Ex. Sunday					
WBKYOTP Yard		6.20PM	9.30AM	2.30AM			11.40PM	12.05PM	0.0	TO-R DEL RIO	378.6	6.35AM	8.40PM	10.30AM	1.30AM			Continuous	Continuous	
72 P		6.40	9.50	2.50			11.52	12.18	8.4	JOHNSTONE	370.2	6.19	8.23	10.13	1.05					
72 P		6.50	10.03	3.00			11.59PM	12.25	14.8	AMANDA	364.3	6.12	8.15	10.03	12.53					
41 P		7.00	10.13	3.10			12.05AM	12.31	18.9	STANDART	359.7	6.05	8.08	9.53	12.43					
72 P		7.10	10.23	3.20			12.12	12.38	24.6	PINTO	354.0	5.57	8.00	9.42	12.31					
72 WP		7.20	10.33	3.30			12.19	12.45	29.8	LAS MORAS	348.8	5.50	7.53	9.32	12.19AM					
YPOW Yard	6.55AM	7.44	10.53	3.47			12.31	12.57	36.9	TO-R SPOFFORD	341.7	5.40	7.44	9.20	11.58PM	12.45PM	Continuous	Continuous		
67		7.10	8.01	11.06	3.59		12.42	1.08	44.9	ANAOCHO	333.7	5.24	7.25	9.07	11.45	12.28				
72 P		7.20	8.11	11.16	4.07		12.47	1.14	49.2	PAVO	329.4	5.18	7.19	8.59	11.36	12.18				
72 P		7.30	8.21	11.26	4.15		12.53	1.20	53.8	ODLAW	324.8	5.12	7.13	8.51	11.27	12.08PM				
71 WP		7.45	8.31	11.36	4.23		12.59	1.28	59.1	OLINE	319.5	5.04	7.06	8.42	11.17	11.57AM				
45 P		8.00	8.42	11.46	4.33		1.06	1.37	65.0	OBI	313.6	4.57	6.58	8.32	11.07	11.46				
71 P		8.22	8.53	11.56AM	4.48		1.14	1.45	70.6	HACIENDA	307.5	4.48	6.49	8.22	10.55	11.20				
PYW Yard		8.50	9.10	12.16PM	5.05		1.29	2.01	77.5	TO UVALDE	301.1	4.36	6.38	8.10	10.43	11.01	Continuous	Continuous		
173		9.02	9.20	12.26	5.18		1.36	2.09	82.2	INGE	296.4	4.21	6.23	7.54	10.28	10.35				
74 P		9.15	9.32	12.36	5.30		1.44	2.19	88.2	TO KNIPPA	290.4	4.13	6.15	7.45	10.19	10.23	8.00AM to 11.30AM 12.30PM to 5.00PM	Closed		
52 P		9.30	9.45	12.46	5.45		1.52	2.27	94.7	YUCCA	283.9	4.05	6.06	7.35	10.09	10.10				
51 P		9.40	10.01	12.54	5.53		1.58	2.34	99.1	SABINAL	279.5	3.55	5.56	7.27	10.01	9.40				
72 PW		9.55	10.14	1.06	6.05		2.08	2.45	106.6	SECO	272.0	3.46	5.47	7.15	9.48	9.15				
48 P		10.10	10.25	1.16	6.15		2.15	2.55	111.6	TO D'HANIS	267.0	3.37	5.37	7.03	9.33	9.01	9.00AM to 1.01PM 2.01PM to 6.01PM	Closed		
83 P		10.38	10.45	1.31	6.30		2.27	3.10	120.1	TO HONDO	268.5	3.25	5.25	6.50	9.20	8.41	Continuous	Continuous		
75 PW		11.00	10.53	1.38	6.37		2.33	3.17	124.3	QUIHI	264.3	3.10	5.10	6.37	9.07	8.25				
72 P		11.20	11.08	1.53	6.58		2.43	3.28	129.9	DUNLAY	248.7	3.03	5.03	6.25	8.56	8.10				
72 P		11.40AM	11.20	2.13	7.10		2.52	3.38	137.7	NOONAN	240.9	2.52	4.52	6.12	8.42	7.55				
68 P		12.01PM	11.30	2.30	7.20		3.01	3.49	144.5	TO LACOSTE	234.1	2.40	4.41	5.59	8.29	7.40	8.00AM to 11.30AM 12.30PM to 5.00PM	8.00AM to 11.30AM 12.30PM to 5.00PM		
72 PW		12.18	11.40	2.42	7.30		3.10	3.59	152.0	MAODONA	226.6	2.30	4.30	5.47	8.17	7.30				
72 P		12.35	11.52PM	2.54	7.42		3.20	4.10	159.8	WITHERS	218.8	2.20	4.20	5.35	8.05	7.10				
									161.8	DUNCAN FIELD	216.8									
I									165.9	TOWER 105 (I.-G.N. and S.A.B. & T. Crossings)	212.7						Continuous	Continuous		
I									167.5	TOWER 112 (S. A. B. & T. Crossing)	211.1						Continuous	Continuous		
Yard BKP							3.45AM	4.35PM	169.8	TO-R SAN ANTONIO (Commerce Street)	209.3	2.00AM	4.00PM				Continuous	Continuous		
I									170.6	TOWER 121 (Olive St.)	208.0						Continuous	Continuous		
BOKPTWY Yard	1.15PM	12.30AM	3.30PM	8.20AM					171.2	TO-R EAST YARD	207.4			5.00AM	7.30PM	6.30AM	Continuous	Continuous		
	Arrive Daily Ex. Monday	Arrive Daily	Arrive Daily	Arrive Daily			Arrive Daily	Arrive Daily				Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily Ex. Sunday				
	86	246	244	242			2	6				1	5	245	241	85				

(6.20) 21.2 (6.10) 27.8 (6.00) 28.5 (5.50) 29.4 (4.05) 41.5 (4.30) 37.6Time Over Subdivision.... (4.35) 36.9 (4.40) 36.4 (5.30) 31.1 (6.00) 28.2 (6.15) 21.5 ...Average Speed per Hour...

Eastward Trains are Superior to Trains of the Same Class in the Opposite Direction. (See Rule S-72)

See Item 64, Special Instructions, page 12, regarding train movements between Tower 112 and East Yard. Trains will move with caution within Spofford Yard Limits, expecting to find main track occupied. See Page 15 for additional stops to entrain or detrain revenue passengers. Engines larger than F-1 class must not be operated on new tracks 1, 2 or 3 at Hondo.

EASTWARD

SAN ANTONIO SUBDIVISION

WESTWARD

Length of sidings in car, location of bulletin, water and fuel stations, standard clocks, interlocking plants, turn tables, ways and tele-phones.	THIRD CLASS			SECOND CLASS			FIRST CLASS			Distance From San Antonio	TIME TABLE No. 176 December 6, 1942	Mile Post Location	FIRST CLASS			SECOND CLASS		THIRD CLASS		Train Order Office Hours and Hours of Signal Operator at Interlocking Stations	
	84	250	248	242	8	6	2	7	5				1	249	247	83					
	Local Freight	Freight	Freight	Freight	Alamo	Argonaut	Sunset Limited	Alamo	Argonaut				Sunset Limited	Freight	Freight	Local Freight					
	Leave Daily Ex. Sunday	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily Ex. Sunday	Daily Except Sundays and Legal Holidays	Sundays and Legal Holidays Only						
Yard BKP					11.00PM	5.15PM	4.15AM	0.0	TO-R SAN ANTONIO (Commerce Street)	209.8	6.30AM	3.25PM	1.30AM			Continuous	Continuous				
I								1.3	TOWER 121 (Olive St.)	208.0						Continuous	Continuous				
BKYOWPT Yard	7.00AM	7.15PM	6.45PM	2.15PM	11.08	5.23	4.23	1.9	TO-R EAST YARD	207.4	6.15	3.13	1.18	8.50AM	6.15PM	2.00PM	Continuous	Continuous			
P								4.8	SALADO JOT.	204.6											
72 P	7.15	7.30	6.57	2.27	11.17	5.31	4.31	7.5	KIRBY	201.8	6.00	3.06	1.11	8.37	6.02	1.30					
47 P	7.25	7.40	7.06	2.36	11.25	5.38	4.38	12.6	CONVERSE	196.7	5.51	2.59	1.04	8.27	5.52	1.15					
WP					11.30	5.42	4.41	15.1	RANDOLPH FIELD	194.2	5.43	2.55	1.00								
72 P	7.40	7.50	7.13	2.51	11.33	5.45	4.43	16.4	SOHERTZ	192.9	5.35	2.51	12.58	8.20	5.45	1.00					
64 P	8.05	8.05	7.27	3.10	11.43	5.55	4.52	24.8	MARION	185.0	5.10	2.41	12.48	8.05	5.25	12.40					
46 P	8.20	8.15	7.35	3.20	11.50PM	6.02	4.58	29.1	HILDA	180.2	4.58	2.34	12.42	7.57	5.15	12.20					
E71 W30 WP	8.45	8.30	7.50	3.35	12.03AM	6.16	5.07	35.3	TO SEGUIN	174.0	4.41	2.25	12.34	7.45	5.02	12.01PM	Continuous	Continuous			
60 P	8.55	8.38	7.57	3.42	12.08	6.21	5.12	38.6	ILKA	170.7	4.25	2.18	12.29	7.36	4.52	11.35AM					
70 P	9.15	8.50	8.08	3.53	12.21	6.29	5.19	44.8	KINGSBURY	164.5	4.16	2.10	12.21	7.26	4.41	11.20					
68 P	9.30	9.00	8.17	4.02	12.28	6.35	5.25	49.7	SULLIVAN	159.6	4.04	2.02	12.13	7.16	4.28	11.05					
E35 P WY W108 Yard	10.15	9.12	8.30	4.15	12.40	6.45	5.32	56.0	TO LULING	153.8	3.54	1.54	12.05AM	7.04	4.15	10.15	Continuous	Continuous			
61 P	10.30	9.25	8.40	4.25	12.48	6.52	5.39	61.8	IVY	148.0	3.39	1.45	11.57PM	6.54	3.57	10.00					
72 P	10.50	9.33	8.47	4.32	12.56	6.59	5.44	65.3	HARWOOD	144.0	3.33	1.39	11.52	6.47	3.50	9.40					
77 P	11.10	9.43	8.56	4.42	1.07	7.06	5.50	70.1	SANDY FORK	139.2	3.23	1.32	11.46	6.37	3.40	9.20					
71 PW	11.30	9.59	9.13	4.58	1.25	7.18	6.03	78.1	TO WAELDER	131.2	3.12	1.22	11.36	6.25	3.25	9.00	9.00AM to 11.30AM 12.30PM to 6.00PM	Closed			
72 P	11.50AM	10.10	9.23	5.10	1.35	7.26	6.12	84.7	JANICE	124.6	3.00	1.12	11.28	6.12	3.10	8.45					
N64 IPY S71 Yard	12.20PM	10.20PM	9.35PM	5.20	1.50	7.37	6.20	89.3	TO-R FLATONIA Tower 3 (T. & N.O. Cross.)	120.0	2.50	1.05	11.21	5.55AM	3.00PM	8.30	Continuous	Continuous			
62 P	12.53			5.31	2.00	7.45	6.29	95.7	ENGLE	113.6	2.36	1.253	11.12			8.00					
49 PW	1.15			5.43	2.20	7.58	6.38	102.2	TO SCHULENBURG	107.1	2.20	12.37	10.57			7.45	8.00AM to 11.50AM 12.50PM to 5.00PM	Closed			
42 P	1.45			5.58	2.30	8.09	6.48	110.4	WEIMAR	98.9	2.10	12.27	10.47			7.25					
49 P	2.10			6.08	2.45	8.18	6.56	115.7	BORDEN	93.6	2.02	12.19	10.40			7.17					
Yard BKYPTOW	2.30PM			6.20PM	3.00AM	8.27PM	7.05AM	122.2	TO-R GLIDDEN	87.1	1.50AM	12.10PM	10.32PM			7.05AM	Continuous	Continuous			
	Arrive Daily Ex. Sunday	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily				Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily Ex. Sunday					
	84	250	248	242	8	6	2				7	5	1	249	247	83					

(7.30) 18.3 (3.05) 28.9 (2.50) 30.9 (4.05) 28.9 (4.00) 28.8 (3.12) 38.2 (2.50) 41.8Time Over Subdivision.... (4.40) 26.2 (3.15) 37.6 (2.58) 41.1 (2.55) 29.9 (3.15) 26.8 (6.55) 17.4 ...Average Speed per Hour...

Eastward Trains are Superior to Trains of the Same Class in the Opposite Direction. (See Rule S-72)

Trains move with caution within Luling yard limits, and Flatonia yard limits, expecting to find main track occupied.
See Items 64 and 65, Special Instructions, Page 12, regarding train movements between Salado Junction, East Yard and San Antonio.
See Page 15 for additional flag stops to entrain or detrain revenue passengers. Nos. 7 and 8 will stop at Cibolo, on flag.

Length of sidings in cars, location of bulletin, water and fuel stations, standard clocks, interlocking plants, turn tables, wyes and tele-phones.

Main train schedule table with columns for Third Class, Second Class, and First Class (6, 56, 302, 310, 2, 304, 58, 8) and rows for various stations and yard locations.

TIME TABLE No. 176, December 6, 1942. STATIONS list including GLIDDEN, OOLUMBUS, ALLEYTON, RAMSEY, EAGLE LAKE, T. & N. O. CROSS., G. O. & S. F. CROSS., LISSIE, NOTTAWA, EAST BERNARD, TAVENER, RANDON, TOWER 17 (G. O. & S. F. Cross.), ROSENBERG, RICHMOND, FLORA, HARLEM, SUGAR LAND, TOWER 114 (S.L.R.R. Cross.), STAFFORD, MISSOURI CITY, WEST JUNCTION, BELLAIRE JUNCTION, EUREKA (Tower 18), BOULEVARD JOT., HOUSTON (Passenger Station), WEST JUNCTION, STELLA, TOWER 81 (G. O. & S. F. Crossing), HARRISBURG, TOWER 102 (I.-G. N. Crossing), TOWER 86 (H. B. & T. Crossing), ENGLEWOOD, BOULEVARD JOT., NILES, TOWER 26 (T. & N. O. Cross.), TOWER 68, ENGLEWOOD.

Eastward Trains are Superior to Trains of the Same Class in the Opposite Direction. (See Rule S-72) Unless otherwise provided, time and train orders at Harrisburg apply at Tower 30. Time Over Subdivision. Average Speed per Hour.

GLIDDEN SUBDIVISION

WESTWARD

TIME TABLE No. 176

December 6, 1942

FIRST CLASS

SECOND CLASS

THIRD CLASS

Train Order Office
Hours and Hours of
Signal Operators at
Interlocking Stations

STATIONS	Mile Post Location	FIRST CLASS								SECOND CLASS				THIRD CLASS		Train Order Office Hours and Hours of Signal Operators at Interlocking Stations	
		301 Motor	55 G. C. & S. F. Passenger	5 Argonaut	309 Motor	1 Sunset Limited	57 G. C. & S. F. Passenger	303 Passenger	7 Alamo	371 Freight	351 Freight	81 Local Freight					
		Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily Ex. Saturday	Arrive Daily	Arrive Daily Ex. Sunday	Daily Except Sundays and Legal Holidays	Sundays and Legal Holidays Only			
TO-R GLIDDEN 2.8	87.1			12.10PM		10.32PM		1.50AM			1.15PM	Continuous	Continuous				
COLUMBUS 3.1	84.8			12.05PM		10.27		1.42			1.08						
ALLEYTON 7.0	81.2			11.59AM		10.21		1.35			1.00						
RAMSEY 5.7	74.2			11.50		10.13		1.26			12.45						
Tower 115 EAGLE LAKE 0.2	68.5			11.42		10.06		1.18			12.30						
TO T. & N. O. CROSS. 0.3	68.3											Continuous	Continuous				
G. O. & S. F. CROSS. 6.2	68.0																
LISSIE 4.9	61.8			11.30		9.57		1.03			12.10PM						
NOTTAWA 5.1	56.9			11.24		9.51		12.56			11.55AM						
TO EAST BERNARD 4.8	51.8			11.17		9.45		12.49			11.40	7.30AM to 11.30AM 12.30PM to 4.30PM	Closed				
TAVENER 4.4	47.0			11.10		9.39		12.42			11.25						
RANDON 6.7	42.6			11.04		9.34		12.35			11.15						
TO-R TOWER 17 (G. O. & S. F. Cross.) ROSENBERG 3.0	35.9	8.45AM	9.50AM	10.56		9.24	9.31PM	10.37PM	12.23	9.00AM	12.01AM	11.00	Continuous	Continuous			
RICHMOND 1.0	32.9	8.36	9.44	10.47		9.19	9.24	10.30	12.10	8.55	11.50PM	10.00	Continuous	Continuous			
FLORA 2.5	31.9	8.33	9.42	10.45		9.17	9.22	10.28	12.07	8.52	11.45	9.55					
HARLEM 4.7	29.4	8.30	9.38	10.41		9.13	9.18	10.25	12.02AM	8.47	11.40	9.50					
SUGAR LAND 0.2	24.7	8.22	9.32	10.36		9.07	9.12	10.20	11.55PM	8.36	11.30	9.40					
TO TOWER 114 (S.L.R.R. Cross.) STAFFORD 1.3	24.5												7.30 AM to 11.30 PM	7.30 AM to 11.30 PM			
MISSOURI CITY 5.8	18.4	8.13	9.24	10.27		8.58	9.04	10.12	11.42	8.21	11.12	9.17					
WEST JUNCTION 5.1	12.6	8.05	9.16	10.19		8.50	8.56	10.04	11.34	8.09	11.01	9.05					
BELLAIRE JUNCTION 4.2	4.2		Via Tower 81		5.36PM		Via Tower 81			Via Harrisburg	Via Harrisburg	Via Harrisburg					
TO EUREKA (Tower 13) 2.5	5.7	7.53	10.07	5.28	8.37		9.52	11.22					Continuous	Continuous			
BOULEVARD JOT. 2.0	3.2																
TO-R HOUSTON (Passenger Station)	1.2	7.40AM		9.55AM	5.15PM	8.25PM		9.40PM	11.10PM				Continuous	Continuous			
WEST JUNCTION 3.1	12.6		9.16				8.56			8.09	11.01	9.05					
TO-R STELLA Tower 134 (I.-G. N. Crossing) 4.9	9.9		9.11				8.51			8.00	10.50	8.55					
TO-R TOWER 81 (G. O. & S. F. Crossing) 2.9	4.6		9.03AM				8.43PM						Continuous	Continuous			
TO HARRISBURG Tower 30 (G. H. & H. Crossing) 1.6	7.2									7.40	10.30	8.36	Continuous	Continuous			
TOWER 102 (I.-G. N. Crossing) 1.5	5.6												Automatic				
TO-R TOWER 86 (H. B. & T. Crossing) 2.7	4.1									7.25	10.15	8.25	Continuous	Continuous			
TO-R ENGLEWOOD	358.1									7.15AM	10.00PM	8.15AM	Continuous	Continuous			
BOULEVARD JOT. 1.0	3.2																
NILES 2.1	1.4																
TO-R TOWER 26 (T. & N.O. Cross.) 2.1	360.5												Continuous	Continuous			
TOWER 68 0.3	358.4												Continuous	Continuous			
TO-R ENGLEWOOD	358.1												Continuous	Continuous			

.....Time Over Subdivision..... (1.05) (0.47) (2.15) (0.21) (2.07) (0.48) (0.57) (2.40) (1.45) (2.01) (5.00)

.....Average Speed per Hour..... 34.2 39.9 39.2 24.9 41.6 39.1 39.1 33.4 23.2 20.1 14.7

Eastward Trains are Superior to Trains of the Same Class in the Opposite Direction. (See Rule S-72) Unless otherwise provided, time and train orders at Harrisburg apply at Tower 30.

See Item 88, Special Instructions, Page 12, regarding train movements between Bellaire Junction and Eureka, between Eureka and Houston Passenger Station, between Boulevard Junction and Englewood via Niles, and between Englewood and Harrisburg.

EASTWARD

BELLAIRE SUBDIVISION WESTWARD

Table with columns for Second Class (242), First Class (310), Distance From Eagle Lake, Time Table No. 176 (December 6, 1942), Stations, Mile Post Location, and First Class (309). Includes stations like Tower 115, Ohesterville, Wallis, Simonton, Fulshear, Flewellen, Gaston, Olodine, Alief, Jeannetta, Bellaire, and Bellaire Junction.

(2.45) (1.28) Time Over Subdivision (1.84)
20.0 37.3 Average Speed per Hour 35.0

Eastward Trains are Superior to Trains of the Same Class in the Opposite Direction. (See Rule S-72.) Nos. 309 and 310 will stop on flag at Howellville.

See Glidden Subdivision, Pages 8 and 9, for train movements between T. & N. O. crossing and passenger and freight stations at Eagle Lake.

Trains will move with caution within Eagle Lake yard limits expecting to find main track occupied.

EASTWARD

KERRVILLE SUBDIVISION

WESTWARD

Table with columns for Second Class (212), Time Table No. 176 (December 6, 1942), Stations, Mile Post Location, and Second Class (211). Includes stations like Kerrville, Legion, Center Point, Comfort, Fredericksburg Jct., Waring, Welfare, Boerne, Van Raub, Camp Stanley Junction, Leon Springs, Viva, Beckmann, Robards, I-G.N. Crossing, Tower 109, Tower 112, Tower 121, and East Yard.

(8.40) (3.59) Time Over Subdivision (8.59)
20.5 Average Speed per Hour 18.7

Eastward Trains are Superior to Trains of the Same Class in the Opposite Direction. (See Rule S-72.) Except: No. 211 is Superior to No. 212.

Trains must approach Camp Stanley Junction and Beckmann expecting to find main track occupied without flag protection.

See Item 64, Special Instructions, Page 12, regarding train movements between Tower 112, San Antonio and East Yard.

Table with columns for Train-Order Office Hours and Hours of Signal Operators at Interlocking Stations, Daily Except Sundays and Legal Holidays, and Sundays and Legal Holidays Only. Lists stations like Kerrville, Comfort, Boerne, Tower 109, Tower 112, San Antonio, Tower 121, East Yard, Spofford, Eagle Pass, and Glidden.

EASTWARD

EAGLE PASS SUBDIVISION WESTWARD

Table with columns for Second Class (228), Time Table No. 176 (December 6, 1942), Stations, Mile Post Location, and Second Class (227). Includes stations like End Eagle Pass Subdiv., Eagle Pass, Olmos, Paloma, Darling, Nora, and Spofford.

(1.30) Time Over Subdivision (1.30)
23.0 Average Speed per Hour 23.0

Eastward Trains are Superior to Trains of the Same Class in the Opposite Direction. (See Rule S-72.)

The crew assigned to or ordered for the train may assume the schedule of No. 228 at Eagle Pass and leave Eagle Pass without a clearance.

STATIONS AND TRACKS NOT OTHERWISE SHOWN IN TIME TABLE

Table with columns for Distance from, Miles, STATION, M. P. Location, and Car Capacity and Direction Opening if Spur. Lists stations from El Paso to Eagle Pass with their respective mileposts and capacities.

TIME INSPECTORS

Table listing Time Inspectors and their locations: Sidney F. Ball (Chicago, Ill.), C. E. Ross (El Paso), Art Kassel (El Paso), Max Bogusch (Sanderson), S. E. McMath (Del Rio), Carl Gildemeister (San Antonio), O. B. Humble (San Antonio), Wm. L. Dostal (Rosenberg), Houston Watch Company (Houston), and W. E. Connor (Houston).

EASTWARD GONZALES SUBDIVISION

WESTWARD

Table with columns for Second Class (218, 216), Time Table No. 176 (December 6, 1942), Stations, Mile Post Location, and Second Class (217, 219). Includes stations like BOWY, P, and Harwood.

(0.30) (0.30) Time Over Subdivision (0.30) (0.30)
25.0 25.0 Average Speed per Hour 25.0 25.0

Eastward Trains are Superior to Trains of the Same Class in the Opposite Direction. (See Rule S-72.) Except: No. 217 is Superior to No. 218.

Schedules at Harwood will be assumed by crews assigned to or ordered for the train. The crew assigned to or ordered for the train may assume the schedule of No. 218 at Gonzales and leave Gonzales without a clearance.

Table with columns for Train-Order Office Hours and Hours of Signal Operators at Interlocking Stations, Daily Except Sundays and Legal Holidays, and Sundays and Legal Holidays Only. Lists stations like Tower 115, Eagle Lake, Tower 51, Wallis, and Gonzales.

GENERAL

1. Trains displaying signals for a following section must sound one long and two short blasts of engine whistle when passing both engine and caboose of freight trains, which must be acknowledged by two short blasts of whistle and proceed signal from a member of train crew.
2. A train may arrive at a station in advance of its schedule arriving time.
3. When trains, or engines with or without cars, meet in vicinity of highway crossings at grade they must proceed WITH CAUTION, and, if necessary to avoid accident, STOP.
4. Employees are forbidden to ride front foot board of yard engines in direction of movement, or on pilot of road engines.
5. Trains and engines must stop before crossing a railway at grade unless protected by an interlocking plant.
6. Rule 10 (H), revised: A metal signal painted solid green on front and back will be used to mark limit of restriction in lieu of the green metal signal with white border as prescribed in second paragraph of Rule 10 (H).
7. Roadmasters, B. & B. and signal supervisors, signal foremen, linemen, traveling motor-car repairmen, water-service repairmen, operators of roadway machines and any employees who operate motor cars, must use watches as prescribed by Rule 2, and must be provided with current time-table while operating motor cars and roadway machines.
8. On a passenger train when approaching a station where engines are to be changed or train is to be switched, trainman will open steam valve on rear of train one mile or more in advance and sound Communicating Signal 16 (m). Before opening the valve, trainman must look forward on each side of train to observe whether employes or other pedestrians are walking along the track, who might be scalded by the discharge of steam, and consideration must be given to selecting a location for this operation where there is the least possibility of danger to employes or pedestrians, or damage to property. Steam must not be blown from train line approaching or passing over street or highway crossings.
9. At stations, except at Langtry, where there are two or more sidings, eastward trains must take the most westerly siding, and westward trains the most easterly siding, for trains having authority to hold the main track, unless otherwise directed by train order, or the movement made under flag protection.
10. Engines must not be operated over the live rail of any track scale.

LOCAL ALL SUBDIVISIONS

19. Cars, gross weight in excess of limits shown, and engines heavier than class indicated, must not be handled between the points named:

Between	Cars	Class Engine	
		Freight	Passenger
El Paso and San Antonio	210,000	GS-1, F-5	P-13-14, GS-1
San Antonio and Houston (via Glidden Subdivision)	210,000	F-1	P-13-14
Eagle Lake and Houston (via Bellaire Subdivision)	210,000	F-1	P-13-14
Spofford and Paloma	210,000	F-1	P-13-14
Paloma and Eagle Pass	210,000	MK-5	P-13-14
San Antonio and Camp Stanley Jct.	210,000	MK-5	MK-5
Camp Stanley Jct. and Kerrville	210,000	C-24	C-24
Harwood and Gonzales	210,000	T-28	T-28

20. Limits of sidings at stations named are as follows:

- Spofford —West switch to cross-over switch near tool house.
- Hondo —East switch to west switch.
- Luling —East Siding—West switch to cross-over west of Freight Station.
- Harwood —East switch to cross-over switch.
- Rosenberg —East siding—East switch to west switch. Time and train orders for eastward trains apply at east switch to cross-over.
- Alief —West switch to cross-over switch.
- Jeannetta —East switch to cross-over switch.

23. Extra precaution must be used when operating Class MK-5, F-1, F-5 or GS-1 engines on other than main tracks and sidings.

24. Santa Fe trains display markers with red and yellow lights. The yellow lights bear the same significance as do the green lights under T. & N. O. rules.

25. Freight trains must be inspected at each water stop. When conditions are favorable and, in the judgment of the conductor and engineer, it is safe to do so, and when additional stops can thereby be avoided, freight trains may run between water stops without stopping for inspection, provided the distance shall not be greater than indicated below:

Manifest Trains—

60 miles, except may run between El Paso and Small; Fort Hancock and Lobo; Valentine and Alpine; Alpine and Sanderson; Sanderson and High Bridge; Del Rio and Uvalde; Uvalde and East Yard; East Yard and Waelder; Luling and Glidden.

25. Continued—

Other Freight Trains—

50 miles, except may run between El Paso and Small; Valentine and Alpine; Alpine and Tesnus; Sanderson and Pumpville; East Yard and Luling; Luling and Glidden; Glidden and Rosenberg.

Trainmen are not relieved of making inspection as prescribed by Rule 827 when stops are made at a lesser distance.

Freight trains must be thoroughly inspected at High Bridge before crossing.

26. Spring Switches are located as follows:

- Belen —East end double track, normal position for westward track.
 - Madden —East end of siding, normal position for main track.
 - Ramey —East end of siding, normal position for main track.
 - Small —East end of siding, normal position for main track.
 - Torcer —East end of siding, normal position for main track.
 - Lasca —East end of siding, normal position for main track.
 - Marfa —West end of siding, normal position for main track.
 - Sanderson —Main-track switch, extreme west end of yard, normal position for main track.
 - Sanderson —Derail in No. 1 track, west of east crossover, normally to derail eastward movements.
 - High Bridge —West end of double track; normal position for eastward trains.
 - High Bridge —East end of double track; normal position for westward trains.
 - Withers —West end double track, normal position for eastward track.
 - San Antonio —Switch connecting west lead track with westward main track at Victoria Street, normal position for westward main track.
 - East Yard —Switch connecting yard lead with eastward main track, east end of yard, normal position for the lead.
 - Waelder —West end siding, normal position for main track.
 - Rosenberg —East end of east siding, normal position for main track.
 - West Junction —Switch connecting westward track of double track to single track, normal position for single track.
 - Boulevard Jct. —Switch connecting eastward main track of the Freight Route with westward main track from the direction of passenger station; normal position for eastward movement to Freight Route.
 - Boulevard Jct. —Switch connecting westward main track of the Freight Route with westward main track from the direction of passenger station; normal position for through movements from direction of the passenger station.
 - Niles —East end double track; normal position for westward track.
- They are designated by two targets, one hexagon shape, painted white, bearing the letters "SS"; the other a standard red target.
- Trains and engines may trail through spring switches when normally set, but when a stop is made before the entire engine or cars have passed over the points, a reverse movement must not be made until switch has been set by hand. After trailing through a spring switch, a reverse movement must not be made until it is known that both points have moved to proper position as prescribed by Rule 104 (C). Running switches must not be made over spring switches and blow-off cocks, sanders, or injectors must not be operated and boosters must not be started, while engines are standing on or passing over such switches.
- Speed of 15 miles per hour must not be exceeded over spring switches east end of yard, East Yard, and at Victoria Street, San Antonio.
- Where reduction of speed over other spring switches is required, it will be indicated by slow boards, or by other speed restrictions within the same limits.
27. The following signals, equipped with triangular number plates, have included in their control limits, either spring switches, special devices, or both. When indicating STOP, in addition to complying with the provisions of Rule 509, careful inspection must be made of the track, switches and structures as indicated below, and it must be known that the route is safe for passage of trains before proceeding:
- | Signals | Location |
|--|--|
| 9—Freight Route between Boulevard Junction and Tower 26— | Spring switch, east end of double track. |
| 349—Rosenberg— | Spring switch, east end of east siding. |
| 1316—Waelder— | Spring switch, west end of siding. |
| 2188—Withers— | Spring switch, end of double track. |
| 3889—Between McKees and Devils River— | Falling-rock detector, also fusible wire on Bridges 390.77, 390.83 and 390.98. |
| 3896—Between McKees and Devils River— | Falling-rock detector. |
| 3909—Between McKees and Devils River— | Falling-rock detector, also fusible wire on Bridge 390.98. |
| 3916—Between McKees and Devils River— | Falling-rock detector, also fusible wire on Bridges 390.77, 390.83 and 390.98. |
| 4271—High Bridge— | Spring switch, east end double track. |
| 4282—High Bridge— | Spring switch, west end double track. |
| 4469—Between Langtry and Osman— | Falling-rock detector. |
| 4488—Between Langtry and Osman— | Falling-rock detector. |
| 5168—Sanderson— | Spring switch, west end of yard. |
| 5980—Between Altuda and Strobel— | High-water detector, Bridge 597.80. |
| 5975—Between Altuda and Strobel— | High-water detector, Bridge 597.80. |

- 6334—Marfa—
- 7451—Lasca—
- 7491—Torcer—
- 7531—Small—
- 7623—Ramey—
- 7657—Madden—
- 8151—Belen—

- Spring switch, west end of siding.
- Spring switch, east end of siding.
- Spring switch, east end of siding.
- Spring switch, east end of siding.
- Spring switch, east end of siding.
- Spring switch, east end of siding.
- Spring switch, end of double track.

(Note: Spring switches east end of yard, East Yard, and at Victoria Street, San Antonio, not protected by signals.)

28. TAKE SIDING INDICATORS are located on Signals 6065 and 6074, east and west ends of siding at Alpine. (See Rules 705 to 709, inclusive).

29. In addition to location shown on schedule page of time-table, bulletin and circular books are located as follows:

- El Paso —S. P. enginehouse; T. & P. yard office.
- Valentine —Enginehouse.
- Sanderson —Enginehouse.
- Del Rio —Enginehouse.
- San Antonio—Enginehouse; Yardmaster's office, Olive Street.
- Glidden —Enginehouse.
- Houston —Enginehouse; Yardmaster's office, Hardy Street; Union Station (for G. C. & S. F.).
- Hearne —Enginehouse; Train-order office; Yardmaster's office.
- Yoakum —Enginehouse; Train-order office.
- Victoria —Enginehouse; Dispatcher's office.

30. In addition to location shown on schedule page of time-table, standard clocks are located as follows:

- El Paso —S. P. Enginehouse; T. & P. yard office.
- Del Rio —Enginehouse.
- San Antonio—Enginehouse.
- Houston —Enginehouse.

31. Yards located at the following stations are designated by yard-limit boards:

- | | |
|---------------------------|--|
| El Paso — Alfalfa | San Antonio — Withers — Salado Jct. |
| Valentine | Luling |
| Alpine — Alpine Jct. | Flatonia |
| Sanderson | Glidden — Columbus — Talton — Alleyton — Laban |
| | Eagle Lake |
| Del Rio | Rosenberg |
| Spofford | Houston — North Jct. |
| Eagle Pass — Quemado Jct. | Harrisburg |
| Uvalde | |

32. To prevent cars rolling out of yard, hand brakes must be set on freight trains, or cut of cars, before engine is detached as follows:

- El Paso freight yard—At least five cars on east end of train when train, or part of train, is left west of Octavia Street.
- Valentine—At least five cars on west end of train.
- Alpine Junction (P. & S. F. or T. & N. O. transfer tracks)—At least ten cars on east end to prevent rolling into P. & S. F. yard.
- Sanderson—At least twelve cars on east end of train.
- Del Rio—A sufficient number on west end of train.
- East Yard—At least eight cars on east end of train.
- Glidden—At least eight cars on east end of train.

33. A trainman is required to ride rear platform of passenger and freight trains and to watch closely for fire while train is passing over the following bridges:

- Del Rio Subdivision:
 - Bridge 307.79, Nueces River, west of Hacienda.
- San Antonio Subdivision:
 - Bridge 204.64, Salado Creek, east of East Yard.
 - Bridge 193.10, Cibolo River, Schertz.
 - Bridge 178.43, Guadalupe River, east of Hilda.
 - Bridge 156.48, San Marcos River, west of Luling.
- Glidden Subdivision:
 - Bridge 84.06, Colorado River, Columbus.
 - Bridge 32.42, Brazos River, Richmond.
- Kerrville Subdivision:
 - Bridge 267.19, Cibolo Creek, between Van Raub and Boerne.
 - Bridge 280.10, Joshua Creek.
 - Bridge 285.54, Guadalupe River, east of Fredericksburg Junction.
- Bellaire Subdivision:
 - Bridge 49.70, East Bernard River.
 - Bridge 40.87, Brazos River.
 - Bridge 38.70, Crump Creek.

(See Pages 2, 13, 14 and 15 for additional instructions, information and speed restrictions applicable to all subdivisions.)

EL PASO, VALENTINE AND SANDERSON SUBDIVISIONS

41. Employes of the T. & N. O. R.R. Company will be governed by rules and regulations of the El Paso Union Depot Company within the limits of that company.

42. Main tracks between Tower 47 and Tower 6, El Paso, will be used jointly by trains of the San Antonio Division and the Deming and Alamogordo Subdivisions of the Rio Grande Division. Trains between these points will run with caution, expecting to find the main track occupied. Second-class and inferior trains, and engines, may run ahead of first-class trains, but must not occupy the main track when it is known a first-class train will thereby be delayed, and movement against the current of traffic may be made only under flag protection. Signal operator at Tower 6 will not set the route or clear signals for an eastward movement to move against the current of traffic from Tower 6 to El Paso Street crossover except on instructions of the yardmaster, who must know the movement is protected. Trains may run extra, moving with the current of traffic, between Tower 47 and Tower 6 without train-order authority, but must obtain a clearance before commencement of trip if an operator is on duty.

43. The north track of the double track between Tower 47 and El Paso (Union Depot) will be known as Track No. 1, and the south track as Track No. 2.

44. Westward trains approaching Tower 47 must move from Piedras Street to Tower 47 interlocking limits with caution, expecting to find main track occupied by yard engines.

45. Westward trains entering Pacific Lines yard, El Paso, will head through crossover east of Tower 47, and between sunset and sunrise will receive proceed signal with green light before entering receiving track.

46. Eastward trains checking a regular train on register at El Paso, or identifying a train on opposite track between El Paso (Union Depot) and Belen, will not be required to check against the same train before passing from double to single track.

47. First-class trains may register at El Paso (Cotton Avenue) by register ticket, Form 2642.

48. Ysleta is a train-order office for eastward trains only.

49. The normal position of Distant Signal 8147 governing westward trains at Belen is CAUTION.

50. Freight trains, in cutting crossing just east of station building at Fabens, must leave an opening between white lines each side of crossing.

Loading platform and roof of shed the entire length of the platform on south track, cotton compress at Fabens, will not clear a man on north side of a car or Engine.

51. Trains may register at Sierra Blanca by register ticket, Form 2642, and obtain train-order check, Form R, of superior trains due that have arrived or left.

52. Conductors and engineers of T. & P. westward trains may register watch comparison at Sierra Blanca by delivering Form 1525-A to the operator. (See Rule 3.)

53. Spur track switch from enginehouse lead at Valentine must be left lined for the spur.

54. Oil and water columns between main track and track No. 1, Valentine and Sanderson yards, do not afford standard clearance. Employes must exercise extreme care in riding or getting on or off cars and engines in this vicinity.

55. Class F-1 or heavier type engines must not use west leg of wye or oil track at Del Rio beyond switch point of the switch connecting these two tracks.

56. Engines heavier than MK-5 and P-9 class; i.e., F-1, F-5 and GS-1 type, must not be double headed or coupled together in pairs for operation between Sanderson and Del Rio. When towed or used in trains, engines heavier than MK-5 and P-9 type must be separated by at least two cars.

DEL RIO AND SAN ANTONIO SUBDIVISIONS

61. Class F-1 or heavier engines must not use west leg of wye or oil track at Del Rio beyond the switch point of switch connecting these two tracks.

62. Spofford is a register station only for trains that originate or terminate there.

64. Main tracks between Tower 112, San Antonio (Commerce Street) and East Yard will be used jointly by trains of the San Antonio Division and the Victoria Division. Trains between these points will run with caution, expecting to find the main track occupied. Second-class and inferior trains, and engines, may run ahead of first-class trains, but must not occupy the main track when it is known a first-class train will thereby be delayed, and movements against the current of traffic may be made only under flag protection.

65. Main track between East Yard and Salado Junction will be used jointly by trains of the San Antonio Division and the Victoria Division. Movements between these points will be governed by Positive Block Signal indications.

66. Westward trains of the Del Rio Subdivision, checking a regular train on register at East Yard or San Antonio (Commerce Street), or identifying a first-class train on opposite track between San Antonio (Commerce Street) and Withers, or identifying other trains on opposite track between East Yard and

Withers, will not be required to check against the same train before passing from double to single track.

67. Eastward trains of the San Antonio Subdivision, checking a regular train on register at San Antonio (Commerce Street) or East Yard, or identifying a train on opposite track between these points and the end of double track at East Yard, will not be required to check against the same train before passing from double to single track.

68. San Antonio (Commerce Street) and East Yard are train-order offices only for trains that originate there.

69. San Antonio (Commerce Street) is a register station only for trains that originate or terminate there.

70. First-class trains may register at East Yard by register ticket, Form 2642.

71. Flaton is a register station only for trains that originate or terminate there. Trains may register at Flaton by register ticket, Form 2642, and obtain a train-order check, Form R, of superior trains due that have arrived or left.

72. First-class trains, and extra trains holding running orders through Glidden, may register at Glidden by register ticket, Form 2642, and obtain train-order check, Form R, of superior trains due that have arrived or left, and may leave Glidden without a clearance if train-order signal is changed to indicate PROCEED in accordance with Rule 221.

Trains of the San Antonio and Glidden Subdivisions, with the same conductor and engineer operating through Glidden, may be issued train orders on one subdivision that affect their movements on the other, or both, subdivisions.

73. Engines larger than the C-8-9 class must not be operated beyond the first switch on Government track inside the fence at Randolph Field.

74. Storage track at Sullivan must not be used by engines heavier than Class C-8 or C-9.

75. Class MK-5 and heavier engines must not be operated on the following tracks:

Seguin Brick and Tile Co. tracks near Hilda.

Nolte Mill tracks.

Seguin—Tracks 1, 3, 4 and oil-sump track.

Luling—Gin spur; Magnolia spur beyond the right-of-way fence.

76. Engines must not exceed four miles per hour on compress track, Luling.

77. Class MK-5 and F-1 engines may use track No. 2 at Seguin but must not exceed eight miles per hour.

78. Tail track switch east end of East Yard must be left lined for tail track.

GLIDDEN AND BELLAIRE SUBDIVISIONS

79. G. C. & S. F. 3450 class engines in passenger service between Tower 81 and Rosenberg must not exceed 35 MPH between Tower 81 and West Junction.

80. No. 2 will stop at Rosenberg to discharge passengers destined Palacios from points west of San Antonio.

81. First-class trains, and extra trains holding running orders through Glidden, may register at Glidden by register ticket, Form 2642, and obtain train-order check, Form R, of superior trains due that have arrived or left, and may leave Glidden without a clearance if train-order signal is changed to indicate PROCEED in accordance with Rule 221.

Trains of the San Antonio and Glidden Subdivisions, with the same conductor and engineer operating through Glidden, may be issued train orders on one subdivision that affect their movements on the other, or both, subdivisions.

82. Engines weighing in excess of 155,000 pounds on drivers must not use rice mill warehouse track at Eagle Lake, this being the track nearest to the G. C. & S. F. main track. Engines must not use the crossover between the rice mill elevator track and warehouse track at Eagle Lake.

83. See BELLAIRE SUBDIVISION, Page 10, for movements of Nos. 309 and 310, to and from passenger station at Eagle Lake. Transfer and siding must be kept clear. Trains will move with caution within Eagle Lake yard limits expecting to find main track occupied.

84. Rosenberg and Tower 81 are register stations only for trains that originate or terminate there.

85. Trains may register at Tower 81 by register ticket, Form 2642, and obtain train-order check, Form R, of superior train due that have arrived or left.

86. Trains originating at Houston Passenger Station, enroute to Bellaire Subdivision at Bellaire Junction, must obtain a clearance at Houston Passenger Station, authorizing movement from Bellaire Junction.

87. Trains moving to or from Glidden Subdivision at Harrisburg will be governed by train-order signal located near Tower 30. The train-order signal located near Houston Division main track near switch leading to Glidden Subdivision governs trains moving exclusively on Houston Division.

88. Main tracks between Bellaire Junction and Eureka will be used jointly by trains of the Glidden and Bellaire Subdivisions. Main tracks between Eureka and Houston Passenger Station and between Boulevard Junction and Tower 26 via Niles will be used jointly by trains of the San Antonio Division and Dallas and Austin Divisions, and between Tower 26 and Englewood by trains of the

San Antonio Division, Dallas and Austin Divisions, and Houston Division and between Englewood and Harrisburg by trains of the San Antonio Division and Houston Division. Trains between these points will run with caution, expecting the main track to be occupied. Second-class and inferior trains, and engines, may run ahead of first-class trains, but must not occupy the main track when it is known a first-class train will thereby be delayed, and movements against current of traffic may be made only under flag protection. Between Bellaire Junction and Houston Passenger Station; between Boulevard Junction and Englewood via Niles, and between Englewood and Harrisburg, trains may run extra moving with the current of traffic, on double track, without train order authority.

89. The main track between Tower 17 and cross-over switch of the east siding, Rosenberg, will be used jointly by trains of the Victoria and San Antonio Divisions and the G. C. & S. F. Movements between these points must be made with caution expecting to find main track occupied. Second-class and inferior trains, and engines, must not occupy the main track when it is known that a first-class train will thereby be delayed.

90. Westward trains between Englewood, Houston Passenger Station, Bellaire Junction or West Junction, checking a regular train on register at Englewood or Houston Passenger Station or receiving a train order check, Form R, of a regular train at Eureka or Harrisburg, or identifying a train on opposite track, will not be required to check against the same train before passing from double to single track at Bellaire Junction or West Junction.

91. Trains to or from the Bellaire Subdivision at Bellaire Junction, authorized to use a schedule, or run as a section of a schedule, on the Bellaire Subdivision, may assume the corresponding schedule, or corresponding section of schedule, on the Glidden Subdivision between Bellaire Junction and Houston Passenger Station and between Bellaire Junction and Englewood, displaying green signals when required.

92. Trains operating between Eureka and Englewood will move via Freight Route between Boulevard Junction and Tower 26 unless otherwise directed.

93. Overlap posts are located—Stafford (to the left of main track), governing eastward trains. Richmond—(to the left of main track) governing westward trains.

94. Trains and engines must approach passenger yard, Houston, with caution and be governed by signals from switch tender as follows: PROCEED signal with green flag by day and green light by night before entering passenger yard; PROCEED signal with yellow flag by day and yellow light by night before leaving passenger yard. The following whistle code will be sounded at Houston Avenue Underpass for guidance of switch tender in handling switches at entrance to passenger station yard:

San Antonio Division trains ——— o

Victoria Division trains o o ——— o

95. Engines heavier than F-1 class must not be operated over White Oak Bayou bridge on Freight Route, west end of Hardy Street yard, Houston.

96. Speed of 15 miles per hour must not be exceeded by trains or engines over diamond-shaped crossing at Tower 26, which is the crossing of the westward main track toward Houston Passenger Station and the eastward main track from Hardy Street yard.

97. When using Holico Spur stop must be made before making any movements over highway and member of crew must protect crossing with red flag by day and red lantern by night to give warning to highway traffic of approaching movement.

98. F-1 and MK-5 class engines must not head through curve side of puzzle switches Englewood yard except those on west lead, back lead and new lead at west end of yard.

99. Drawbridge not shown in time-table between Tower 102 and Tower 86, mile post location 5.2:

Buffalo Bayou (Interlocked)

100. See Page 15 for additional flag stops to entrain or detrain passengers.

101. Eureka is a train-order office for westward trains only.

EAGLE PASS, KERRVILLE AND GONZALES SUBDIVISIONS

103. Westward trains of the Kerrville Subdivision, checking a regular train on register at East Yard or San Antonio (Commerce Street), or identifying a train on opposite track between East Yard and Tower 112, will not be required to check against the same train before passing from double to single track.

104. Engines must not move over track scales, Gonzales Cotton Oil & Manufacturing Co. at Gonzales.

106. Train and engine movements over Main and Quarry Streets, Eagle Pass, must be protected by flagman.

Train and engine movements on the Quemado Spur, Eagle Pass Subdivision, must be made with caution; maximum speed for forward movement 20 miles per hour, and for backup movement 15 miles per hour.

Class MK-5 or heavier engines must not use short leg of wye at Eagle Pass.

SPEED

BETWEEN	Passenger Trains Handled by Passenger Engines			Gas Electric Motor			Passenger Trains Handled by Engines with Two Wheel Engine Trucks			Manifest Freight Trains when not handling any of the restricted cars shown in Item 161.			Freight and Mixed Trains			Trains handling derricks, ditching machines, steam shovels, drag lines, pile drivers scale test cars and machines of similar kind on own wheels.		
	Miles per hour			Miles per hour			Miles per hour			Miles per hour			Miles per hour			Miles per hour		
	Straight Track	Unprotected Curves	Protected Curves	Straight Track	Unprotected Curves	Protected Curves	Straight Track	Unprotected Curves	Protected Curves	Straight Track	Unprotected Curves	Protected Curves	Straight Track	Unprotected Curves	Protected Curves	Straight Track	Unprotected Curves	Protected Curves
El Paso and Houston.....	60	60	GOVERN	60	60	GOVERN	45	45	FREIGHT TRAIN SPEED ON SLOW BOARDS	45	45	GOVERN	40	40	GOVERN	25	25	25
Eagle Lake and Bellaire Jct.....	45	45		55	50		40	40					30	30		25	18	18
West Junction and Harrisburg.....	35	35		38	38		35	35					25	25		20	15	15
Eagle Pass and Spofford.....	40	40		45	45		30	30					30	30		25	18	18
Kerrville and Van Raub.....	30	30		33	33		25	25					25	25		20	15	15
Van Raub and San Antonio.....	35	35		38	38		30	30					30	25		20	15	15
Gonzales and Harwood.....	30	30		33	33		25	25					25	25		20	15	15

152. MAXIMUM SPEED OF ENGINES

Yard engines in service, running forward or backward with or without cars, and road engines in service, running backward, with or without cars, or when showing cars ahead of engine _____ 20 miles per hour.

Yard engines, not equipped with engine trucks, in tow in charge of messenger, and under sufficient steam to lubricate, moving forward or backward, rods in place or removed 20 miles per hour.

Road engines in tow in charge of messenger, and under sufficient steam to lubricate: Moving forward or backward, rods in place _____ Freight train speed.

Moving forward or backward, main or side rods, or both, removed _____ 20 miles per hour.

Road engines running forward, light, unless otherwise directed _____ Freight train speed.

STATIONS	Miles Per Hour
El Paso.....	25
Marfa.....	15
Alpine.....	15
Del Rio.....	18
San Antonio.....	18
Seguin.....	6
Luling.....	10
Flatonia.....	6
Schulenburg.....	20
Weimar.....	10
Columbus.....	10
Eagle Lake.....	6
Rosenberg.....	6
Richmond.....	6
Sugar Land.....	15
Houston.....	18

153. Trains must not exceed 15 miles per hour through crossovers, junctions and other diverging switches; 25 miles per hour over drawbridges; and 45 miles per hour over railroad crossings at grade not otherwise further restricted.

154. Trains and engines must proceed with caution between Dakota and Wyoming streets and between Crockett and East Houston Streets, San Antonio, looking out for cross-over movements to and from passenger yard, and during the hours named below, must not exceed six (6) miles per hour over the following street crossings and, if necessary, send a flagman ahead before proceeding:

- San Antonio:**
 Sherman, Bursleson, Lamar, Burnet, Montana, Wyoming, Dakota 12:01 A.M. to 6:00 A.M.
 Pine, Hackberry, Dawson, Houston, Crockett, Center, East Commerce, South Presa, South St. Mary's, South Flores and South Brazos Streets have crossing gates operated at all hours.
- San Antonio (Kerrville Subdivision):**
 West Laurel and Probandt Street..... All Hours
- Luling:** All Streets All Hours
- Gonzales:** St. Joseph Street..... All Hours

156. GS-1 class engines, when used in passenger service, must not exceed 55 miles per hour on straight track and unprotected curves. Engines not equipped with trailer trucks, when used in passenger service, must not exceed 55 miles per hour.

157. Trains must stop before crossing High Bridge (428.13) Sanderson Subdivision, and must not exceed a speed of 12 miles per hour until entire train is over bridge. Application of brakes while train is on bridge should be avoided except in emergency. In picking up, setting out and switching at High Bridge, engines or cars must not be stopped on bridge. Flagman must ride on platform of rear car and signal when train has passed over bridge, keeping a close look-out for fire.

159. Passenger trains leaving or entering El Paso Union Depot must not exceed six (6) miles per hour between lead track out of Union Depot and crossover just west of Tower 6.

160. Movements of all trains on and through the various crossovers and in interlocking limits of Tower 47 must be made with caution not exceeding 10 miles per hour.

161. Speed shown under "Manifest Freight Trains," Item 150, may be observed when not handling:

- Loaded tank cars, except tank cars of 10,000 gallons capacity or less when not containing gasoline, naphtha, or other highly inflammable commodities;
- Any open-top car loaded with transformers, rail, poles or piling, twin or other multiple loads;
- Any other open-top cars where lading projects above ends or sides of car, unless car foreman or lead inspector, after careful inspection, certifies load in good condition for fast speed;
- Machines on own wheels such as cranes, derricks, ditching machines, or any other car restricted by rule or special instructions;
- Cars with arch bar type trucks.

162. LOCATIONS WHERE SLOW BOARD RESTRICTIONS APPLY TO MORE THAN ONE CURVE, STRUCTURE OR EXTENDED SECTION OF TRACK.

FOR EASTWARD TRAINS			FOR WESTWARD TRAINS		
Location of Slow Board M P	Beginning of Restriction M P	End of Restriction M P	Location of Slow Board M P	Beginning of Restriction M P	End of Restriction M P
81.95	81.20	74.20	73.45	74.20	81.20
251.67	250.92	249.70	248.95	249.70	250.92
396.87	396.12	394.49	393.74	394.49	396.12
397.70	396.95	396.35	395.60	396.35	396.95
401.87	401.12	401.04	400.29	401.04	401.12
411.11	410.36	410.08	409.28	410.08	410.36
411.91	411.16	410.39	409.64	410.39	411.16
414.07	413.16	411.16	410.41	411.16	413.16
414.43	413.68	412.41	412.41	413.16	413.68
418.95	416.20	413.68	412.93	413.68	416.20
417.47	416.72	415.45	415.45	416.20	416.72
421.27	420.52	416.72	415.97	416.72	420.52
428.83	428.08	421.45	420.70	421.45	428.08
431.51	430.76	429.07	428.57	429.07	430.76
436.31	435.56	434.57	434.57	435.32	435.56
437.24	436.43	435.87	435.12	435.87	436.43
439.34	438.59	437.00	436.25	437.00	438.59
440.32	439.57	438.73	437.98	438.73	439.57
442.50	441.75	440.28	439.51	440.28	441.75
449.48	448.73	447.60	446.85	447.60	448.73
456.71	455.96	454.21	453.46	454.21	455.96
458.12	457.37	456.11	455.36	456.11	457.37
461.00	460.25	459.92	459.17	459.92	460.25
461.96	461.21	460.50	459.75	460.50	461.21
463.37	462.62	461.75	461.00	461.75	462.62
464.58	463.83	463.58	462.83	463.58	463.83
466.33	465.58	464.54	463.79	464.54	465.58
470.06	469.31	468.01	467.26	468.01	469.31
473.82	473.07	472.35	471.60	472.35	473.07
477.18	476.43	474.61	473.86	474.61	476.43
481.46	480.71	479.59	480.34	480.34	480.71
486.27	485.51	484.75	484.00	484.75	485.51
487.87	487.12	486.47	485.72	486.47	487.12
500.87	500.12	498.54	497.79	498.54	500.12
511.49	511.39	507.75	507.00	507.75	511.39
522.63	521.88	518.90	518.15	518.90	521.88
544.06	543.30	542.71	541.96	542.71	543.30
545.36	544.61	543.98	543.23	543.98	544.61
546.63	545.88	545.32	544.57	545.32	545.88
548.20	547.45	546.49	545.74	546.49	547.45
551.77	551.02	549.79	549.04	549.79	551.02
560.82	559.87	559.07	558.32	559.07	559.87
576.46	575.71	575.25	574.50	575.25	575.71
589.53	589.08	588.50	587.75	588.50	589.08
600.28	599.53	599.01	598.26	599.01	599.53
603.38	602.63	601.49	600.74	601.49	602.63
605.52	604.77	604.23	603.48	604.23	604.77
610.35	609.60	608.46	607.71	608.46	609.60
618.63	617.88	617.14	616.39	617.14	617.88
620.82	620.07	618.33	617.58	618.33	620.07
748.92	748.17	743.66	742.91	743.66	748.17
753.69	752.94	748.52	747.77	748.52	752.94
758.07	757.32	756.47	755.72	756.47	757.32
763.08	762.33	760.57	759.82	760.57	762.33
765.57	764.82	763.01	762.26	763.01	764.82
785.83	785.08	784.66	783.97	784.66	785.08
824.48	823.73	823.18	822.53	823.18	823.73

163. Location of slow boards not located at the distance prescribed by Rule 10 (J):

Slow board location (Mile Post)	Distance from beginning of restriction (mile)
206.82	0.58
301.17	0.50
418.83	0.67
437.24	0.81
503.16	0.59
511.49	0.10
532.93	0.99
WESTWARD TRAINS:	
428.57	0.50
620.09	0.56
766.54	0.54
783.97	0.69
822.53	0.65

164. Between El Paso and Houston, T. & P. I-1 class engines, numbers 600 to 669, inclusive, equipped with valve-pilot and nickel-steel rods, and T. & N. O. MK-5 class engines and F-1 class engines, recounterbalanced, except engines 958, 972, 980, 981, 987, 991, 994 and 997, when handling passenger trains, may make 55 miles per hour on straight track and 50 miles per hour on unprotected curves where speed is not otherwise further restricted, and will be governed by restrictions applying to freight trains on protected curves.

SPEED TABLE

This table is for information in determining speed per mile and is in no way affects rules or special instructions governing speed of trains.

Miles per Hour	1 Mile in		Miles per Hour	1 Mile in		Miles per Hour	1 Mile in	
	Min.	Sec.		Min.	Sec.		Min.	Sec.
6	10	0	30	2	0	49	1	13
8	7	30	31	1	56	50	1	12
10	6	0	32	1	52	51	1	10
12	5	0	33	1	49	52	1	9
15	4	0	34	1	45	53	1	7
16	3	45	35	1	42	54	1	6
17	3	31	36	1	40	55	1	5
18	3	20	37	1	37	56	1	4
19	3	9	38	1	34	57	1	3
20	3	0	39	1	33	58	1	2
21	2	51	40	1	30	59	1	1
22	2	43	41	1	27	60	1	0
23	2	36	42	1	25	65	0	55
24	2	30	43	1	23	70	0	51
25	2	24	44	1	21	75	0	48
26	2	18	45	1	20	80	0	45
27	2	13	46	1	18	85	0	42
28	2	8	47	1	16	90	0	40
29	2	4	48	1	15	95	0	38
						100	0	36

CENTRALIZED TRAFFIC CONTROL SYSTEM

(C. T. C. S.)

VALENTINE SUBDIVISION

GOVERNING THE MOVEMENT OF TRAINS BETWEEN ALPINE AND PAISANO.

Centralized Traffic Control Signals have semaphore arms painted the same as interlocking signals and their indications are the same as those displayed by interlocking signals.

The following special instructions will govern operation of trains through centralized traffic control territory:

CENTRALIZED TRAFFIC CONTROL SYSTEM LIMITS

Between Signal 6073, main track at Alpine, and Signal 6200, main track at west switch of siding at Paisano.

OPERATION — CENTRALIZED TRAFFIC CONTROL SYSTEM

Trains and engines will operate within centralized traffic control system limits in accordance with Centralized Traffic Control Signal indications, which supersede the superiority of trains, and should run to a signal indicating STOP but not pass it without first securing permission by telephone from the operator at Alpine, and then be governed by the provisions of Rules 663 and 509, and before passing it, must see that the switch is properly lined and not exceed twelve miles per hour until entire train has cleared the switch.

The lower arm of a three-arm signal governs movements into sidings at Toronto and Paisano and to P. & S. F. Railway at Alpine Junction; the lower arm of the two-arm signal at junction switch at Paisano governs movements to P. & S. F. Railway; dwarf signals govern movements out of sidings; one-arm signal 6085 at Alpine Junction governs movements from P. & S. F. Railway and T. & N. O. transfer and one-arm signal 6196 at Junction switch, Paisano, governs movements from P. & S. F. Railway. All other signals govern main-track movements.

Westward P. & S. F. trains must approach west switch T. & N. O. transfer, Alpine Junction, with caution, looking out for T. & N. O. engines using transfer track.

Signals 6201 and 6203 at west end of siding Paisano govern movements over, but not beyond, the switch.

At Paisano:—The yellow arm on Signal 6200 governing eastward trains at west end of siding, when in restrictive position, will indicate Home Signal 6198 at junction switch, or Home Signal 6194 at east end of siding, or both, are in STOP position.

The yellow arm on Signal 6193 governing westward trains at east end of siding when in restrictive position, will indicate Home Signal 6197 at junction switch, or Home Signal 6201 at west end of siding, or both, are in STOP position.

At Toronto:—Distant Signal 6132, 2983 feet west of west switch of siding, governing eastward trains, when in restrictive position, will indicate Home Signal 6128 at west end of siding, or Home Signal 6120 at east end of siding, or both, are in STOP position.

Within Centralized Traffic Control System limits trains may run extra without running orders.

Operator at Alpine will not line the switch and clear the signal for trains from the P. & S. F. Railway to enter main track at Paisano or at Alpine Junction without first securing permission from the train dispatcher.

Trains from and to the P. & S. F. Railway at Alpine Junction will enter and leave the main track at the switch located at signals 6085 and 6084.

The siding switches at Toronto and Paisano, the main track switch at Alpine Junction and the junction switch at Paisano, are power operated by the operator at Alpine. If necessary to operate a power switch by hand, a crank is located in a box on one end of the instrument case at the switch and printed instructions are located in telephone box on other end of instrument case. The crank must be replaced in box and box locked after having been used.

Sand must not be used over movable parts of power-operated switches. Trains must not blow out boilers when passing over power-operated switches, or when passing signals.

Trains or engines desiring to do switching or other work on the main track within Centralized Traffic Control System limits will secure permission by telephone from the operator at Alpine. The length of time the block may be occupied will be indicated by the operator, and at the expiration of this time the block must be vacated or an extension of time secured.

Trains or engines entering the main track at the west end of siding or house track Alpine and at P. & S. F. transfer tracks must secure permission from the operator at Alpine before fouling the main track and then be governed by position of switch indicator located at west switch of siding, Alpine, and crossover switch at P. & S. F. transfer tracks, west of Alpine, before lining the switch of either track.

Trains or engines, after having cleared the main track and lined the switch and derail to permit a main track movement at the crusher track Toronto, must secure permission from the operator at Alpine before re-entering the main track, and then be governed by position of switch indicator before lining the switch and derail.

Indicators between Toronto and Paisano are for information of maintenance of way forces, and not for train operation.

Intermediate home signals 6078, 6079, 6097 and 6102 between Alpine and Toronto and 6141, 6146, 6159, 6164, 6171 and 6176 between Toronto and Paisano are automatic block signals, and trains stopped by such signals will be governed by Rule 509.

GLIDDEN SUBDIVISION

Train and engine movements on single track of the Freight Route between Tower 26 and Niles will be in accordance with Centralized Traffic Control signal indications, which supersede the superiority of trains. Such signals are of the light type, bearing number plate. Trains, after stopping, may pass a signal indicating "stop" only in compliance with Rule 663.

Trains may operate between Tower 26 and Niles without train-order authority, but such trains originating at Englewood must obtain a clearance at that station.

Signal No. 3, located at the west interlocking limits of Tower 26, just west of Maury Street, governs westward movements; Signal No. 16, located at the fouling point on eastward track, and Signal No. 14, located at the fouling point on westward track, at Niles govern eastward movements entering Centralized Traffic Control System limits.

Other Centralized Traffic Control signals to govern westward and eastward movements are located as follows:

Signal No. 3, westward)	near Old Signal Shop
Signal No. 4, eastward)	
Signal No. 5, westward)	near North Main Street underpass
Signal No. 6, eastward)	
Signal No. 9, westward)	
Signal No. 10, eastward)	at Houston Avenue

Telephones for communication with the signal operator at Maury Street and with the assistant yardmaster at Hardy Street, are located as follows:

SA Yard Crossover west of Hardy Street
Signal No. 4
Old Freight House Lead
Signal No. 6
West end Shop Lead
Signal No. 10
Niles

Westward trains departing from Hardy Street Yard, Houston, and moving on to the freight route between Tower 26 and Niles, through either No. 1 or No. 2 shop lead at the west end of the Hardy Street Yard, must obtain permission from the signal operator at Maury Street and switch indicator must indicate "block clear," before fouling the main track. This permission can be obtained over any of the telephones, the locations of which are shown above.

Trains must not exceed 15 miles per hour between Tower 26 and Niles and must proceed with caution, expecting to find governing signals indicating "stop."

REMOTE SWITCH CONTROL

EL PASO UNION DEPOT

The switches just east of El Paso Union Depot yard governing movements into and out of El Paso Union Depot tracks and cross-over movements from westward and eastward main tracks, Nos. 1 and 2, are electrically operated from Tower 6. Interlocking Signals and Interlocking Rules will govern movements over these switches.

The top, or longer arm, on interlocking home signal governing westward movements at El Paso Street governs through crossover and into El Paso Union Depot yard; the lower, or shorter arm, governs continuous movements on westward track.

When the signals are not cleared or the switch is not set for the route required, train or enginemen will communicate with the signal operator at Tower 6 by telephone located in box on westward signal mast at El Paso Street, on signal mast near east lead El Paso Union Depot or on iron fence El Paso Union Depot. Instructions for operating the switch by hand, when so authorized by the signal operator, are located in telephone boxes.

When necessary for a yard engine to use a route that has been lined for an approaching passenger train, the signal operator must immediately be so advised by telephone, in order that he may restore the route and clear signals for the passenger train.

The engine foreman in charge of switching of passenger equipment at east end of El Paso Union Depot yard will advise signal operator by telephone when he is ready to start switching over El Paso Union Depot connection, and signal operator will set this switch and clear signal, leaving same in that position until engine foreman advises switching has been completed.

Conductors of eastward passenger trains will advise signal operator by telephone, located in box on El Paso Union Depot fence, when train is ready to leave.

TOWER 47—EL PASO

The switch just east of east interlocker limits, Tower 47, governing movements to and from the lead to El Paso S. P. freight yards is electrically operated from Tower 47. Interlocking signals and interlocking rules will govern movement over this switch.

SIERRA BLANCA

T. & P. freight switch located 1893 feet east of the west switch of siding, and T. & P. passenger switch located 3623 feet east of T. & P. freight switch at Sierra Blanca are electrically operated from train-order office. Interlocking Signals and Interlocking Rules will govern movements over these switches. Movements from T. & P. tracks to main track will be governed by light-type signals located a short distance east of the switches.

When the signals are not cleared or the switch is not set for the route required, train or enginemen will communicate with the operator by telephone located in box on post near the switch. Instructions for operating the switch by hand, when so authorized by the operator, are located in telephone box.

Movements to and from T. & P. tracks through electrically-operated switches must not exceed fifteen miles per hour.

Cars or engines must not be left standing on electrically-operated switches, or between the home signals located east and west thereof, thereby preventing the operator from operating the switches.

SANDERSON

The switch at east end of Sanderson yard is electrically operated from the train-order office. Interlocking Signals and Interlocking Rules will govern movements over this switch.

When the signals are not cleared or the switch is not set for the route required, train or enginemen will communicate with the operator by telephone located in box on iron post on north side of track just east of the switch; one long ring for operator; two long rings for maintainer. Instructions for operating the switch by hand, when so authorized by the operator, are located in telephone box.

When making a movement into or out of yard over No. 1 extension switch, the switch will automatically return to normal position for main-track movement and the derail located west of the switch will automatically be set to derail an eastward movement from track No. 1 as soon as the train or engine for which the route was lined has cleared the home signals located just east and

west of the switch and derail, and trains moving westward into yard must not make a reverse movement until the signal has been cleared or the operator has authorized the movement.

FLATONIA, EAGLE LAKE AND ROSENBERG

The west switches of north and south sidings at Flatonia are electrically operated from Tower 3.

The west switch of siding at Eagle Lake is electrically operated from Tower 115.

The west switch of west siding at Rosenberg is electrically operated from Tower 17.

Interlocking signals and interlocking rules will govern movements over these switches.

When the signal is not cleared or the switch is not set for the route required, train or enginemen will communicate with the signal operator by telephone, but inferior eastward trains approaching any of these switches and finding the switch set for main-track movement, and the governing signal clear, are authorized to proceed with caution on the main track to the next signal governing in direction of movement.

EAST YARD

The switch at east end of double track, East Yard, is electrically operated from the train-order office at East Yard; the normal position is for the westward track. Interlocking Signals and Interlocking Rules will govern movements over this switch.

When the signal is not cleared, or the switch is not set for the route required, trainmen or enginemen will communicate with the operator at East Yard by telephone, one of which is located in a box on the east side of instrument case opposite power switch, and the other on Signal 2070. When authorized by the operator, switch may be manipulated by hand, instructions for which are located in the telephone box on instrument case.

WEST JUNCTION

The switch connecting the single main track with the eastward main track of double track is electrically operated from Tower 13, Eureka; the normal position is for single track movement. Interlocking signals and interlocking rules will govern movements over this switch.

When signal is not cleared or the switch is not set for the route required, trainmen or enginemen will communicate with the operator at Tower 13 by telephone which is located in the box on west end of instrument case opposite power switch. When authorized by the operator, switch may be manipulated by hand, instructions for which are located in telephone box.

Westward trains moving with the current of traffic from double to single track shall be governed by Signal 95 and trail through spring switch, and when the signal is not cleared to authorize movement through the switch, trainmen or enginemen will communicate with the operator at Tower 13 by telephone, for instructions.

Movements to or from double track through electrically-operated switch, or spring switch, with governing signal indicating proceed are restricted to maximum speed of fifteen miles per hour.

Westward trains, not receiving a check against, or identifying superior trains at or before arriving West Junction, shall communicate with train dispatcher by telephone at West Junction for check of such train; except, westward second-class or inferior trains from either route, arriving at West Junction when a westward superior train from the other route is due, and unable to identify the superior train may, when the governing signal is clear, proceed to the next open train-order office to obtain Form R check of such train, but must carefully look out for the superior train following, and if seen approaching, the inferior train must arrange for the superior train to promptly pass.

BOULEVARD JUNCTION

Both switches of the crossover just east of Heights Boulevard are electrically operated from Tower 13, Eureka.

Dwarf light Signal X-35-SA, located to the north of Chaney Yard lead track west of Harvard Street, governs westward movements entering the interlocking limits from any of the Chaney Yard tracks; normal position is stop. The route must be set against conflicting movements by the operator at Tower 13, Eureka, and the west switch of the lead must be set for the lead by a member of the crew before Signal X-35-SA will indicate proceed. Trains or engines must not enter main track from lead, Chaney Yard, unless so authorized by telephone by signal operator at Tower 13, Eureka, when telephone communication is possible.

Location of local telephones connected with Tower 13:

Mechanism case at signal bridge.

Mechanism case east of Harvard Street.

Crossing watchman's booth, Heights Boulevard.

Before moving over an electrically-operated switch with the signal indicating "stop," it must be known the switch is properly set, and a speed of twelve miles per hour must not be exceeded until the entire train has passed over the switch.

SPECIAL INSTRUCTIONS

POSITIVE BLOCK

Positive block signals have semaphore arms painted the same as interlocking signals, and their indications are the same as those displayed by interlocking signals.

Trains and engines will operate within positive block signal limits in accordance with positive block signal indications, which supersede the superiority of trains, but second-class and inferior trains, and engines, will not occupy a positive block or overlap in connection therewith, when it is known a first-class train will thereby be delayed.

To enter a positive block when the signal indicates STOP, the movement must be made in accordance with the provisions of paragraph (d) or paragraph (e), Rule 509, but before applying paragraph (e), trainmen, and engineers must assure themselves, either by means of vision or telephonic communication, that the block is not occupied by an opposing train.

Automatic block signals located within positive block limits will be respected in accordance with automatic block system rules.

POSITIVE BLOCK LIMITS

BETWEEN EAST YARD AND SALADO JUNCTION:

Signal 2066 at east end of double track, East Yard, governs movements from that point to Salado Junction.

Signal 2043 on San Antonio Subdivision, 550 feet east of Salado Junction switch, and Signal 1361 on the Victoria Division at Salado Junction, govern movements Salado Junction to end of double track, East Yard.

Overlap extends east of Salado Junction to Signal 2027. Westward inferior trains of the San Antonio Subdivision, waiting for superior trains from the Victoria Division to enter the positive block at Salado Junction, or East Yard, must wait east of Signal 2027.

Trains entering positive block from Victoria Division at Salado Junction, as per paragraph (d) or (e), Rule 509, with Signal 1361 at STOP and indicator at switch indicating block occupied, must protect themselves against westward trains on San Antonio Subdivision.

ADDITIONAL FLAG STOPS TO ENTRAIN OR DETRAIN REVENUE PASSENGERS

Train	At Stations	Entrain Passengers to or Beyond	Detrain Passengers from or Beyond
1	Between Houston and El Paso	West of El Paso	Points East and North of New Orleans
	Sugar Land		Schedule stops east of Houston and from trains connecting at Houston
	Randolph Field	El Paso	East of Houston
2	Between El Paso and Houston	Atlanta, Birmingham, Memphis, Florida	West of El Paso
	Randolph Field	East of Houston	El Paso
	Sugar Land	Schedule stops east of Houston and schedule stops for trains connecting at Houston	
5	Between Houston and El Paso		Connecting Lines at New Orleans
	Between Houston and San Antonio	West of San Antonio	East of Houston
	Between Rosenberg and San Antonio		From trains connecting at Houston
	Sugar Land	San Antonio	
	East Bernard	San Antonio	
6	Between San Antonio and El Paso	Any Station	Any Station
	Between El Paso and San Antonio	Any Station	Any Station
	Between San Antonio and Houston	Schedule stops east of Houston and schedule stops for trains connecting at Houston	West of San Antonio
7	Harwood	Houston	San Antonio
	Sugar Land		San Antonio
	Missouri City	West of Rosenberg	Houston
8	Missouri City	Houston	Stations West
	303	Sugar Land	West of Rosenberg
304	Any Station	West of Victoria	
	Any Station		West of Rosenberg

RATINGS OF ENGINES IN FREIGHT SERVICE—IN UNITS OF 1000 POUNDS (Ms) 15

CLASS	ENGINE NUMBERS	El Paso to Valentine	Valentine to El Paso	Valentine to Del Rio	Del Rio to Valentine	Del Rio and San Antonio	San Antonio and Glidden	Glidden and Houston	Eagle Pass to Spofford	Spofford to Eagle Pass	San Antonio and Kerrville	Gonzales and Harwood
		Nominal	Designation									
F-5	F63 29 1/2 32 306/B61SF	906-921	4800	5850	5300	4800	6100	5600	16500	9300	11000	
GS-1	GS73 27/30 262/B58SF	700-707	4150	5200	4500	4150	5200	4800	14000	7900	9400	
F-1	F63 27 1/2 32 278SF	953-999	3650	4400	4000	3675	4800	4400	13000	7350	8750	
MK-5	MK63 26/28 210S	738-794	3000	3650	3300	3050	3750	3500	9000	5090	6060	
C-8-9	C57 22/30 190S	800-850	2200	2690	2450	2250	3200	3050	7500	4240	5060	2360 2130
P-13	P73 25/30 189-B63SF	631-633	2370	2900	2600	2400	2900	2700	7000	4100	4900	
P-9	P73 25/30 183-B63SF	622-630	2370	2900	2600	2400	2900	2700	7000	4100	4900	
P-6	P77 25/28 178/B59SF	610-621	2130	2600	2350	2150	2600	2380	6500	3680	4380	
P-5	P77 22/28 148-B58SF	600-609					2000	1850	4150	2850	3400	1490 1470
M-10	M63 21/28 152S	500-514					2200	2040	5700	3230	3840	1660 1640
M-6	M63 21/28 142S	515-517					2140	1980	5420	3090	3650	1610 1590
C-24	C-50 20/26 152S	885-894					2240	2070	5670	3160	3760	1690 1640
C-23	C-50 20/26 144S	877-884					2100	1940	5320	3010	3580	1610 1550
C-22	C-50 20/26 141S	874					2100	1940	5320	3010	3580	1610 1550
C-21	C-50 20/24 140S	870					2050	1880	5160	2920	3480	1570 1510
C-20	C-50 19/26 124S	867-869					1930	1750	4800	2720	3230	1450 1400
M-19	M-56 19/26 133	497-498					1900	1730	4750	2690	3200	1440 1400
M-17	M-56 19/26 118	495					1800	1640	4500	2560	3040	1360 1330
M-4	M-63 20/28 128S	410-432, 434-459					1950	1780	4850	2740	3280	1470 1400
T-28	T-69 22/28 163S	388-399					2370	2160	5900	3340	4000	1780 1700
T-38	T-62 19/24 93	376						1320	3600	2040	2440	1080 1044
T-27	T-63 20/26 112	377-386					1710	1560	4250	2400	2880	1280 1210
T-25	T-63 19/26 100	364					1540	1400	3840	2170	2600	1140 1080
T-25	T-56 19/26 100	353-358, 361					1540	1400	3840	2170	2600	1140 1080
A-1	A-73 20/28-125 B-52-SF	273-277						1610	4390			1320 1260
A-1	A-77 20/28-125 B-53-SF	278						1520	4170			1250 1200
E-22	E-69 19/24-79S	244-248										
E-22	E-69 19/24-76S	250-252-254-256-257										
E-23	E-73 20/24 93S	261-265						1180	3240			975 930
E-23	E-73 20/24 90S	266-272						1310	3580			1080 1030
E-39	E-62 17/24-64S	205-207-208										870 830
E-40	E-62 18/24-73S	223										975 930

The following table will govern in maximum loading "total weight car and contents" for cars of the size of journals shown regardless of nominal capacity of car.

Nominal Capacity	Journal	Total Weight Car and Contents
40,000 lbs.	3 3/4 x 7	66,000 lbs.
60,000 "	4 1/4 x 8	103,010 "
80,000 "	5 x 9	136,000 "
100,000 "	5 1/2 x 10	169,000 "
140,000 "	6 x 11	210,000 "

Except; Hart convertible type ballast cars, load limit must not exceed 90,000 pounds.

PASSENGER ENGINES

Numbers	Class
700-707	GS-1
050-052	P-14
031-033	P-13
022-030	P-9
610-621	P-6
600-609	P-5
388-399	T-28
273-278	A-1
261-272	E-23

LEGAL HOLIDAYS:

New Year's Day	January 1st.
Washington's Birthday	February 22nd.
Decoration Day	May 30th.
Independence Day	July 4th.
Labor Day	First Monday in September.
Thanksgiving Day	Last Thursday in November.
Christmas	December 25th.

J. D. Kinsler,
Superintendent, San Antonio

W. R. Mann,
Assistant Superintendent, San Antonio

L. B. Welch,
Trainmaster, San Antonio

F. W. H. Wehner,
Trainmaster, Del Rio

Marvin Bell,
Trainmaster, El Paso

J. J. Moore,
Superintendent,
Houston Division, Houston

J. G. McCullar
Traveling Engineer, El Paso

J. H. Acosta,
Traveling Engineer, San Antonio

C. C. Williams,
H. Dickson,
W. O. Strother,
Chief Train Dispatchers, San Antonio

J. F. McDonald,
Terminal Superintendent, El Paso

L. C. Cody,
Assistant Terminal Superintendent, El Paso

H. T. Etheridge,
W. R. Riggs,
Chief Train Dispatchers, El Paso

C. C. Bourgeois,
Chief Train Dispatcher, Houston

D. R. Prince,
Terminal Trainmaster, Del Rio

Traveling Engineers will exercise duties of Trainmaster when on line.

