INSTRUCTIONS

- Before starting engine, crew will inspect the unit checking oil and water level, fuel supply, lights, angle cocks, brake shoes, piston travel, couplers, and cut levers. Look for any loose or broken equipment.
- When shutting engine down for the day, crew will again inspect unit advising office of any problems that need correcting. Reverser lever will be removed from unit and cab locked. The stack should be covered.
- Crew will observe track conditions and report any problems to Agent daily.
- Crew will report any equipment problems to Agent daily.

RAILROAD PHONE NUMBERS

Salem Freight Office	(609)	935-8943
Salem Enginehouse	(609)	935-9040
Salem Fax Number	(609)	935-2652
Corporate Office	(816)	646-6767

SPEED TABLE

Time Per Mile	Miles Per Hour
2 Min. 20 Sec	25.71
2 Min. 30 Sec	. 24
2 Min. 40 Sec	22.5
2 Min. 50 Sec	21.17
3 Min	. 20
3 Min. 10 Sec	18.95
3 Min. 20 Sec	. 18
3 Min. 30 Sec.	17.14
3 Min. 40 Sec	16.36
3 Min. 50 Sec	15.65
4 Min	. 15
5 Min	. 12
6 Min	. 10
7 Min	8.6
8 Min	7.5
10 Min.	. 6
12 Min.	. 5

Switch/Couple Cars at no more than 4 m.p.h. (a speed equal to a brisk walking pace).

SAFETY FIRST

WEST JERSEY RAILROAD CO.

TIMETABLE

NO. 1

effective 12:01 a.m. Eastern Daylight Savings Time Sunday, July 1, 1990



For the Government and Information of Employees Only

G. L. Brenkman, PresidentO. L. Cox, Vice PresidentD. D. Detsch, Treasurer

SALEM MAIN

Mile Post	Stations	Siding Length
10.76	Swedesboro	
11.90	Grasso	500
17.60	Woodstown	750
22.80	Alloway Jct.	
27.0	Mannington	2200
27.80	Glass House	
28.70	Salem	
	17.94 Miles	

LOCAL INSTRUCTIONS

SPEED LIMITS:

Main Line	15 mph
Siding	5 mph
All Grade Crossings	2 mph
Oldmans Creek Trestle	5 mph

CAR RESTRICTIONS:

Cars weighing over 270,000 pounds gross weight will not be handled without special authority. Cars placarded as "Hazardous Materials" will not be handled without special authority.

CLOSE CLEARANCE:

Crews are warned of close clearances at the following locations:

Woodstown / Agway Track Woodstown / S.J.F.E. Track Alloway Jct. / Dock Salem / Dock, Acme Warehouse

INTERCHANGING CARS AT SWEDESBORO:

The interchange point is on P W J main line south of Bridgeport Road clearing circuit for flashers. Sufficient handbrakes are to be used as well as metal chock.

FLAGGING CROSSING:

Crews will flag any protected crossing not properly operating. In addition all movements pushing cars over crossings will be protected.

INSTRUCTIONS:

Crew will obtain instructions from Agent in Salem before beginning operations. Report any unidentified cars on interchange tracks.

EMERGENCY TELEPHONE NUMBERS:

Salem County Fire & Rescue	935-4505
Salem Police	
State Police	769-0774
PW J Office	935-8943

GLASS HOUSE BRANCH

Mile Post	Stations	Siding Length
0	Glass House	
.13	Anchor Glass	
1.10	Port	
	1.1 Miles	

LOCAL INSTRUCTIONS

SPEED LIMITS:

Entire Branch	4 mph
Industry Tracks	2 mph

CAR RESTRICTIONS

Cars weighing over 270,000 pounds gross weight will not be handled without special authority. Cars placarded as "Hazardous Materials" will not be handled without special authority.

CLOSE CLEARANCES:

Anchor Glass / Tracks Alu-Chem / All Tracks Salem Marine / All Tracks

FLAGGING CROSSINGS:

All crossings are to be flagged.

INSTRUCTIONS:

Crews will receive switching instructions for branch from agent in Salem yard.



OPERATE WITH CARE