

Norfolk & Western Railway Company.

Shenandoah Division.

Time Table No. 18.

(Nos. 16 and 17 Omitted.)

**EFFECTIVE 12:01 A. M.
Sunday, May 15, 1910.**

EASTERN STANDARD TIME.

General Rules, Regulating the Movement of Trains, are contained in Book of Rules for the Government of the Operating Department,
a copy of which must be in possession of each employe in train service while on duty.

This Time Table is not intended for the information of the public nor as an advertisement of the time or hours of any train. The Company reserves the right to vary from it at pleasure. It is for the information of employes only.

Roanoke to Shenandoah.—Northbound.

Telegraph Office.		Telegraph Signal.	Distance from Roanoke.	Passing Sidings Clearance Length.	Station Sidings Clearance Length.	Time Table No. 18 EFFECTIVE Sunday, May 15th, 1910.												
						First Class.						Second Class.		Third Class.		Fourth Class.		
						STATIONS.	28 Passenger Ar. Daily A. M.	102 Passenger Ar. Daily A. M.	104 Passenger Ar. Daily A. M.	14 Passenger Ar. Daily P. M.	106 Passenger. Ar. Daily P. M.	2 Passenger Ar. Daily P. M.	88 Stock Freight Ar. Daily A. M.	98 Blue Ridge Dispatch Ar. Daily P. M.	64 Through Frt. Ar. Daily P. M.	86 Through Frt. Ar. Daily A. M.	62 Local Freight Ar. Daily Ex. Sunday P. M.	108 Local Freight Ar. Daily Ex. Sunday P. M.
DN	ASH	132.6	Yard		SHENANDOAH TWC	6.55			4.40		11.35	10.30	5.35 ⁹⁵	7.30	2.30	3.10		
DN	KO	126.8	2376	1015	Elkton	6.45			4.29		11.26	10.14	5.09	7.15	2.07 ⁸⁵	2.50		
D	DN	121.1	2275	226	Island Ford				4.15		11.16	10.02	4.59	7.00	1.48	2.25		
		114.7	2200	260	Lewis				4.03		11.05	9.48	4.42	6.32 ⁹⁵	1.28	2.00		
D	PE	112.2	1991	400	Port Republic				3.58		11.01	9.42	4.36	6.05	1.22	1.50		
D	GO	109.9	2700	1022	Crottoes				3.53		10.57	9.37	4.31	6.00	1.16	1.42		
		107.4		194	Harriston				3.48		10.52	9.32	4.25	5.54	1.08	1.30		
		103.9	3698		Sampson				3.40		10.46	9.23	4.15	5.39	1.00	1.15		
D	CM	102.4		694	Crimora				3.38		10.44	9.20	4.13	5.35	12.50	1.05		
DN	BC	96.2	2660	717	Basio				3.26		10.35	9.08	4.00	5.20	12.35	12.45 ¹³		
D	MU	91.4	1275	537	Lyndhurst				3.14		10.24	8.57		5.10	12.24	11.48		
D	SX	86.3	2700	570	Stuart's Draft				3.05		10.17	8.45 ⁶¹		5.00	12.12 ⁴	11.35		
DN	GI	79.8	2214	1559	Greenville				2.52		10.05	8.25		4.40	11.50	11.15		
		76.7	1426	380	Lofton				2.46		10.00	8.15		4.25	11.40	11.06		
D	MF	71.7	2117	1158	Vesuvius				2.33		9.49	7.45		3.36	11.05	10.40		
D	MY	64.4	2678	226	Midvale				2.18		9.35	6.46 ¹		2.55	10.24	10.10 ⁶¹		
D	RQ	69.7	1744	393	Riverside				2.09 ¹³		9.27	6.30		2.40	10.10	9.55		
D	JS	64.3	Yard		Buena Vista				1.57		9.15	6.05		2.20 ¹³	9.45	9.35		
DN	J	58.2	2681		Loch Laird		7.50	11.44	1.53 ⁶⁴	6.10	9.09 ⁸⁶	5.34 ⁸³		1.53 ¹⁴	9.09 ²	8.55	1.13	
D	BF	48.4	2100	220	Buffalo		7.38	11.31 ⁶¹	1.46	6.02	9.01	5.22		1.30	8.40	8.42	12.59	
DN	GA	44.1	2840	175	Glasgow		7.28 ¹	11.20	1.39	5.55	8.53	5.12		1.16	8.29	8.30 ¹⁰⁷	12.45	
		41.0	2719	848	Graves				1.33		8.46	5.05		1.08	8.22	8.13		
		40.7			Natural Bridge				1.31		8.45	5.03		1.05	8.20	8.10		
D	ZN	32.1	2850	248	Solitude				1.15		8.28	4.45		12.40 ⁶¹	7.59	7.52 ¹		
D	HA	25.1	2700	790	Buchanan				1.02 ⁶¹		8.14	4.27		12.20	7.42	7.15 ⁸⁸		
D	CH	20.1	2440	1098	Lithia				12.52		8.03	4.15		12.05 ⁶	7.27	6.55		
D	WS	14.7	8727	580	Nace				12.42		7.53	3.55		11.45	7.02	6.40		
DN	MJ	11.4	1544	1117	Troutville				12.35		7.46	3.45		11.35	6.53	6.32		
D	QA	7.1	2200	481	Cloverdale				12.26		7.36	3.20		11.10	6.28	6.12		
		5.7		390	Hollins				12.23		7.32	3.16		11.05	6.25	6.05		
DN	MH UD				ROANOKE				12.10		7.20	2.50		10.35	6.00	5.40		
DN	DO		Yard		West Roanoke							2.30		10.10 ⁸⁸	5.45	5.30		
					STATIONS.	A. M. 28 Lv. Daily	A. M. 102 Lv. Daily	A. M. 104 Lv. Daily	P. M. 14 Lv. Daily.	P. M. 106 Lv. Daily.	P. M. 2 Lv. Daily	A. M. 88 Lv. Daily.	P. M. 98 Lv. Daily	A. M. 64 Lv. Daily.	P. M. 86 Lv. Daily	A. M. 62 Lv. Daily Ex. Sunday.	P. M. 108 Lv. Daily Ex. Sunday.	

Northbound trains are superior to trains of the same class in the opposite direction. See Rule 81.

C. & O. trains while upon the tracks of the N. & W. Railway will be regarded in every respect as N. & W. trains.

XA—Stop to let off passengers from beyond East Radford, Martinsville or Lynchburg, or to pick up passengers for Connecting lines at Shenandoah Junction and Hagerstown.

XD—Stop to let off passengers from Buena Vista or beyond, or to pick up passengers for Basio or points beyond which are stops for No. 2.

Shenandoah to Roanoke.—Southbound.

Telegraph Office.		Telegraph Signals.	Distance from Shenandoah.	Passing Sidings, Clearance Length.	Station Sidings, Clearance Length.	Time Table No. 18 EFFECTIVE Sunday, May 15th, 1910.										
						First Class.						Second Class.		Fourth Class.		
						STATIONS.						1 Passenger Lv. Daily A. M.	101 Passenger Lv. Daily A. M.	13 Passenger Lv. Daily A. M.	103 Passenger Lv. Daily P. M.	105 Passenger Lv. Daily P. M.
DN	ASH	Yard	SHENANDOAH TW CO	4.50					9.05	1.50	5.35 ⁹⁸		5.30
DN	KO	5.8	2876	1015	Elkton	5.00					9.15	2.07 ⁸⁶	5.55		5.50
D	DN	11.5	2275	226	Island Ford	5.08						2.22	6.10		6.05
		17.9	2200	250	Lewis	5.17						2.37	6.32 ⁶⁴		6.30
D	PR	20.4	1991	400	Port Republic	5.20						2.43	6.40		6.38
D	GO	22.7	2700	1022	Grottoes	5.24						2.48	6.45		6.45
		25.2	194	Harriston	5.28						2.54	6.51		6.52
		28.7	3698	Sampson	5.34						3.15	7.11		7.04
D	LM	30.2	694	Crimora	5.35						3.20	7.15		7.10
DN	BC	36.4	2660	717	Basio	5.48						3.34	7.40		7.45
D	HU	41.2	1275	537	Lyndhurst	5.55						3.44			8.00
D	SX	46.8	2700	570	Stuart's Draft	6.06						3.55			8.45 ⁸⁸
DN	GI	52.8	2214	1559	Greenville	6.16						4.15			9.05
		55.9	1426	380	Lifton	6.23						4.30			9.20
D	MF	60.9	2117	1158	Vesuvius	6.33						4.45			9.40
D	MY	68.2	2678	226	Midvale	6.46 ⁸⁸						5.05			10.10 ⁶²
D	RQ	72.9	1744	398	Riverside	6.55						5.16			10.25
D	JS	78.3	Yard	Buena Vista	7.05						5.28			10.45
DN	J	79.4	2881	Loch Laird	7.09	10.25	2.26	5.10	7.20		5.34 ⁸⁸		8.02	11.10
D	BF	84.2	2100	220	Buffalo	7.18	10.38	2.33	5.21	7.31		6.15		8.17	11.31 ¹⁰⁴
DN	GA	88.5	2840	175	Glasgow	7.28 ¹⁰²	10.50	2.40	5.30	7.40		6.25		8.30 ⁶²	11.45
		91.6	2719	848	Graves	7.34						6.34			11.55
		91.9	Natural Bridge	7.36						6.36			12.05 ^{PM}
D	ZN	100.5	2850	243	Solitude	7.52 ⁸²						6.54			12.40 ⁶⁴
D	HA	107.5	2700	790	Buchanan	8.06						7.15 ⁶²			1.02 ¹⁴
D	CH	112.5	2852	1098	Lithia	8.16						7.40			1.30
	WS	117.9	3727	580	Nace	8.29 ⁸⁹						8.29 ¹			1.55
DN	MJ	121.2	1544	1117	Troutville	8.37						9.10			2.10
D	QA	126.5	2200	431	Cloverdale	8.45						9.30			2.25
		126.9	390	Hollins	8.49						9.35			2.30
DN	MH	182.6	ROANOKE	9.00						10.05			2.45
DN	UD	Yard	West Roanoke							10.10 ⁶⁴			3.00
STATIONS.						A. M. 1 Ar. Daily.	A. M. 101 Ar. Daily.	P. M. 13 Ar. Daily.	P. M. 103 Ar. Daily.	P. M. 105 Ar. Daily.	P. M. 27 Ar. Daily.	A. M. 83 Ar. Daily.	P. M. 95 Ar. Daily.	A. M. 107 Ar. Daily Ex. Sunday.	P. M. 61 Ar. Daily Ex. Sunday.	

TELEGRAPH OFFICES WILL BE OPEN AS FOLLOWS:

Buena Vista... Open 6:00 A. M. until 2:00 A. M.
 Loch Laird... Open continuously.
 Buffalo... Open 7:00 A. M. until 6:00 P. M.
 Glasgow... Open continuously.
 Solitude... Open 6:30 A. M. until 5:30 P. M.
 Buchanan... Open 6:30 A. M. until 2:30 A. M.
 Lithia... Open 2:00 A. M. until 10:00 P. M.
 Nace... Open 6:45 A. M. until 8:00 P. M.
 Troutville... Open continuously.
 Cloverdale... Open 6:00 A. M. until 8:00 P. M.
 Roanoke... Open continuously.

Northbound trains are superior to trains of the same class in the opposite direction. See Rule 8r.

C. & O. trains while upon the tracks of the N. & W. Railway will be regarded in every respect as N. & W. trains.

XB—Stop to let off passengers from connecting lines at Hagerstown or Shenandoah Junction, or to pick up passengers for beyond East Radford, Martinsville or Lynchburg.
 XE—Stop to let off passengers from Basio or beyond or to pick up passengers for Buena Vista or points beyond which are stops for No. 1.

Sh

Southbound.

Between Hagerstown and Shenandoah.

Northbound.

Distance from Hagerstown	Telegraph Office.	Telegraph Signals.	Distance from Shenandoah.	Passing Sidings, clearance length.	Station Sidings, clearance length.	Time Table No. 18 EFFECTIVE Sunday, May 15th, 1910.					STATIONS.								
						Fourth Class		Second Class		First Class		First Class		Second Class		Third Class	Fourth Class		
						71 Local Freight Lv. Daily Ex. Sunday A. M.	83 Time Freight Lv. Daily P. M.	95 Blue Ridge Dispatch Lv. Daily A. M.	27 Passenger Lv. Daily P. M.	13 Passenger Lv. Daily A. M.	1 Passenger Lv. Daily A. M.	2 Passenger Ar. Daily A. M.	28 Passenger Ar. Daily A. M.	14 Passenger Ar. Daily P. M.	88 Stock Freight Ar. Daily P. M.	98 Blue Ridge Dispatch Ar. Daily A. M.	86 Thro. Freight Ar. Daily A. M.	72 Local Freight Ar. Daily Ex. Sunday P. M.	
0.6	DN	DX	106.7	Yard		5.30	5.30	10.15 ²⁸	5.00	7.45	1.45	HAGERSTOWN T W C O	3.10	11.05	8.45	5.15	2.50	11.00 ²⁸	2.45
5.9	DN	H A	106.1	Yard		5.40	6.00	11.15 ⁸⁶	5.02 ⁸⁸	7.47	1.47	Hagerstown Junc.	3.07	11.01	8.41	5.02 ²⁷	2.45	10.40 ⁸⁶	2.35
8.9	D	M A	100.8	1680		5.52	6.11	11.27	5.10	7.54	1.54	St. James	2.57	10.51	8.31	4.45	2.09	10.25	2.20
14.1			97.8	2068 2000		6.00	6.18	11.33	5.17	7.59	1.58 ⁹⁸	Grimes	2.51	10.44	8.25	4.38	1.58	10.15	2.05
16.8	D	Q D	89.9	2418 717		6.20	6.33	11.46	5.27	8.09	2.05	Antietam	2.40	10.34	8.12	4.28	1.17	10.00	1.50
23.1	DN	J A	88.6	2380		6.38	6.41	11.53	5.34	8.14	2.10	Shepherdstown	2.33	10.27	8.04	4.20	12.44	9.50	1.35
28.8	D	C N	78.4	2322 1410		7.30	7.38 ¹⁴	12.25 ^{P M 28}	5.45 6.00	8.25 8.32	2.20 ² 2.28	Shenandoah Junc. T W C O	2.20 ¹ 2.12	10.15 10.05	7.50 7.38 ⁸⁸	4.00	12.10 ^{AM}	9.25	1.00 12.25 ^{M 95}
33.7	D	K G	78.0	1700 700		7.50	7.53	12.39	6.15	8.43 ⁸⁶	2.39	Charlestown	1.59	9.52	7.28	3.23	11.38	8.43 ¹³	11.55
39.8	DN	H V	66.9	8075 2100		8.15 ⁸⁶	8.07	12.52	6.26	8.52	2.47	Rippon	1.50	9.41	7.15	3.09	11.21	8.15 ⁷¹	11.5
46.1	D	D K	60.6	594 1740		8.35	8.25	1.06	6.38	9.03	2.56	Berryville	1.41	9.29	7.04	2.54	11.05	8.00	11.00
49.2	D	S Q	57.5	3280 480		8.50	8.45	1.21	6.51 ¹⁴	9.15 ²⁸	3.05	Boyce	1.31	9.15 ¹³	6.51 ²⁷	2.40	10.50	7.38	10.37
53.1	D	A Y	58.8	1774 278		9.05 ²⁸	9.03	1.39	7.00	9.24	3.18	White Post	1.23	9.05 ⁷¹	6.42	2.27	10.35	7.23	10.22
58.6			48.1	1600		9.15	9.11	1.47	7.07	9.30	3.18	Ashby	1.17	8.56	6.35	2.19	10.27	7.13	10.10
59.1	DN	R Y	47.6	257		9.40 ¹¹	9.25	2.04 ⁸⁸	7.20	9.40 ⁷¹	3.26	Carson	1.07	8.42	6.24	2.04 ⁸⁵	10.10	6.53	9.40 ¹³
62.0	D	F K	44.7	2116 575		10.00	9.27	2.08	7.22	9.41	3.27	Riverton	1.06	8.41	6.22	2.03	10.08	6.50	9.30
66.2			40.5	1928		10.15	9.35	2.15	7.29	9.48	3.33	Front Royal	1.00	8.34	6.15	1.55	9.58	6.40	9.10
72.9	D	H D	33.8	2716 880		10.30	9.48 ⁸⁶	2.24	7.37	9.57	3.40	Manor	12.53	8.25	6.07	1.40	9.48 ⁸³	6.15	8.50
79.1	D	V Y	27.6	2583 290		11.00	10.20	2.48	7.51	10.12	3.52	Bentonville	12.41	8.12	5.55	1.20	9.20	5.55	8.30
82.4			24.8	2741 90		11.20	10.33	3.03	8.05	10.24	4.00	Rileyville	12.32	7.58 ⁷²	5.45	1.00	9.05	5.40	7.58 ²⁸
85.0			21.7	727 500		11.40	11.10	3.31	8.12	10.31	4.05	Vaughn	12.26	7.52	5.37	12.45	8.47	5.20	7.40
88.8	DN	F H	17.9	718 985		11.50	11.15	3.36	8.17	10.37	4.08	Elgin	12.22	7.45	5.32	12.35	8.40	5.10	7.30
95.5	D	C A	11.2	4378 1150		12.25 ⁸⁶	11.25	3.45	8.25 ⁹⁸	10.44	4.15	Luray	12.15	7.38	5.24	12.25 ⁷¹	8.25 ²⁷	4.53	7.15
101.7			5.0	900 905		1.00	12.04 ²⁰	4.08	8.40	10.59	4.26 ⁸⁶	Stanley	12.04 ^{AM 28}	7.25	5.11	12.10 ^{P M}	7.50	4.26 ¹	6.15
106.7	DN	S H A N	5.0	900 905		1.30	12.30	4.25	8.52	11.12	4.37	Ingham	11.49	7.10	4.55	11.35	7.15	3.45	5.50
106.7	DN	S H A N	5.0	900 905		2.00	12.50	4.45 ¹⁴	9.02	11.22 ⁸⁸	4.45	SHENANDOAH T W C O	11.40	7.00	4.45 ⁸⁵	11.22 ¹⁸	7.00	3.30	5.30

Northbound trains are superior to trains of the same class in the opposite direction. See Rule 81.

When trains 1 and 2 meet at Shenandoah Junction by rule or train order, the meeting point will be at the main junction switch. First train arriving will go to the station ahead of the opposing train.

TELEGRAPH OFFICES WILL BE OPEN AS FOLLOWS:

Hagerstown Junction	Open continuously.	White Post	Open 8:00 A. M. until 3:00 A. M.
St. James	Open 6:30 A. M. until 2:30 A. M.	Ashby	Open 8:00 A. M. until 7:00 P. M.
Shepherdstown	Open 7:00 A. M. until 11:00 P. M.	Riverton	Open continuously.
Shenandoah Junction	Open continuously.	Front Royal	Open 8:00 A. M. until 8:00 P. M.
Charlestown	Open 7:00 A. M. until 11:00 P. M.	Bentonville	Open 7:00 A. M. until 3:00 A. M.
Rippon	Open 7:00 A. M. until 11:00 P. M.	Rileyville	Open 3:00 A. M. until 11:00 P. M.
Berryville	Open continuously.	Luray	Open continuously.
Boyce	Open 8:00 A. M. until 7:00 P. M.	Stanley	Open 6:00 A. M. until 2:00 A. M.
Shenandoah	Open continuously.		

Southbound.

Between Roanoke and Winston-Salem.

Northbound.

Distance from Roanoke.	Telegraph Office.	Telegraph Signal.	Distance from Winston-Salem.	Passing Sidings, Clearance Lgth.	Station Sidings, Clearance Lgth.	Southbound					Time Table No. 18 EFFECTIVE Sun., May 15th, 1910.		Northbound		Fourth Class		
						Third Class					First Class		First Class		Third Class	Fourth Class	
						51 Local Freight. Lv. Daily Ex. Sunday A. M.	87 Through Frt. Lv. Daily P. M.	85 Through Frt. Lv. Daily P. M.	83 Through Frt. Lv. Daily A. M.	81 Through Frt. Lv. Daily Ex. Sunday A. M.	23 Passenger. Lv. Daily Ex. Sunday P. M.	21 Passenger. Lv. Daily A. M.	24 Passenger. Ar. Daily Ex. Sunday A. M.	22 Passenger. Ar. Daily P. M.	84 Time Freight. Ar. Daily A. M.	52 Local Freight. Ar. Daily Ex. Sunday P. M.	
	DN	DO	Yard			5.30	8.45	2.15	9.40	4.00		West Roanoke			2.10	4.55	
	DN	CD	121.4			5.40	9.00	2.30	9.55	4.10	5.00	ROANOKE	11.45	7.00	1.55	4.40	
2.2			119.2			5.50	9.12	2.40	10.05	4.18	5.07	Belt Line Junction	11.39	6.53	1.45	4.30	
6.9	D	AF	114.6	2498	335	6.10	9.45	3.15	10.45	4.55	5.17	Starkey	11.29	6.42	1.30	3.52	
10.5			110.9	1170		6.22	10.00	3.35 ⁵²	11.22 ²⁴	5.10	5.24	Hester	11.22 ⁸³	6.34	1.20	3.35 ⁸³	
15.4	D	PD	106.0	1271	590	6.45	10.30	4.05	11.55	5.33	5.37	Boone's Mill	11.12	6.26	12.57	3.15	
20.6			100.8	3821	945	7.05	10.50	4.25	12.15 ^P	5.53	5.48	Wirtz	11.02	6.15	12.45	2.40	
27.1	D	RY	94.8	1435	443	7.35	11.12	4.50	12.35	6.20	6.01 ²²	Rocky Mount	10.49	6.01 ²³	12.25 ^A	2.05	
32.1			88.5	2502	207	7.55	11.57 ⁸⁴	5.45 ²²	1.24 ⁵²	7.00	6.22	Waldsboro	10.34 ²¹	5.45 ⁸⁵	11.57 ⁸⁷	1.24 ⁸³	
38.8	D	QM	84.6	1209	884	8.15	12.09 ^A	6.00	1.36	7.12	6.31	Ferrum	10.24	5.37	11.45	1.05	
43.8	D	MR	77.6	1271	694	8.50	12.30	6.25	1.57	7.33	6.46	Henry	10.07	5.20	11.10	12.30	
48.2	D	B	73.2	2079		9.04	12.45	6.38	2.11	7.47	6.55	Philpott	9.57	5.11	10.57	12.10 ^P	
51.6	D	KB	69.8	1496	392	9.15	12.57	6.50	2.22	7.59	7.04	Bassett	9.48	5.03	10.45	11.55	
56.6			64.8	2580	165	9.37 ²⁴	1.12	7.14 ²³	2.37	8.14	7.14 ⁸⁵	Paynes	9.37 ⁵¹	4.54	10.30	11.25 ²¹	
58.3	D	KN	63.2		80	9.50	1.17	7.27	2.42	8.19	7.17	Koehler	9.34	4.51	10.27	11.17	
61.6	D	VM	69.8	1880	467	10.50 ⁵²	1.45	7.52	3.07	8.44	7.30	Martinsville	9.26	4.44	10.15	10.50 ⁵¹	
66.6			64.8	2320		11.05	2.03	8.10	3.27	9.12 ²⁴	7.40	Fontaine	9.12 ⁸¹	4.29	9.55	10.00	
71.5	D	HR	49.9	2380	759	11.30	2.45	8.50	4.19 ²²	9.40 ⁵²	7.51	Ridgeway	9.02	4.19 ⁸³	9.35	9.40 ⁸¹	
76.1	D	RA	45.3	2087	376	11.50	3.03	9.05 ⁸¹	4.34	10.10	8.00	Price	8.51	4.09	9.05 ⁸⁵	9.10	
81.6	D	SN	39.8	2370	293	12.39 ^{PM}	3.23	9.28	4.51	10.30	8.10	Stoneville	8.40 ⁵²	3.58	8.47	8.40 ²⁴	
87.9	D	MN	33.5	1255	389	1.15	3.43	9.48	5.11	10.50	8.22 ⁸⁴	Mayodan	8.27	3.46	8.22 ²⁴	8.05	
89.8	D	AM	31.6		475	1.25	3.50	9.54	5.17	10.58	8.26	Madison	8.23	3.43	7.53	7.54	
98.1	D	DF	23.8	1680	386	1.52	4.15	10.24	5.43	11.24	8.41	Pine Hall	8.05	3.26	7.25	7.28	
104.0	D	W	17.4	1629	1060	2.15	4.40	10.43	6.03	11.46	8.52	Walnut Cove	7.51	3.15	7.03	7.03	
109.3			12.1		395	2.33	5.10	11.10	6.20	12.14 ^P	9.02	Dennis	7.38	3.04	6.47	6.44	
112.7	D	HF	8.7	2348	480	2.58 ²²	5.30	11.25	6.36 ⁸⁴	12.35	9.10	Walkertown	7.30	2.58 ⁵¹	6.36 ⁸³	6.32	
124	D	FO	Yard			3.30	6.00 ⁵²	11.55	7.10	1.05	9.30	WINSTON-SALEM	7.10	2.40	6.10	6.00 ⁸⁷	
						P. M. 51 Ar. Daily Ex. Sunday	A. M. 87 Ar. Daily	P. M. 85 Ar. Daily	P. M. 83 Ar. Daily	P. M. 81 Ar. Daily Ex. Sunday	P. M. 23 Ar. Daily Ex. Sunday	P. M. 21 Ar. Daily	STATIONS.	A. M. 24 Lv. Daily Ex. Sunday.	P. M. 22 Lv. Daily	P. M. 84 Lv. Daily	A. M. 52 Lv. Daily Ex. Sunday

Northbound trains are superior to trains of the same class in the opposite direction. See Rule 81.

TELEGRAPH OFFICES WILL BE OPEN AS FOLLOWS:

Starkey	Open 5:00 A. M. until 1:00 A. M.	Ridgeway	Open 7:45 A. M. until 8:00 P. M.
Boone's Mill	Open 7:00 A. M. until 7:00 P. M.	Price	Open 8:00 A. M. until 8:00 P. M.
Rocky Mount	Open 7:00 A. M. until 3:00 A. M.	Stoneville	Open 8:00 A. M. until 8:00 P. M.
Ferrum	Open 8:00 A. M. until 7:00 P. M.	Mayodan	Open 8:00 A. M. until 7:00 P. M.
Henry	Open 8:00 A. M. until 7:00 P. M.	Madison	Open 8:00 A. M. until 7:00 P. M.
Philpott	Open 8:00 A. M. until 7:00 P. M.	Pine Hall	Open 2:00 A. M. until 10:00 P. M.
Bassett	Open 8:00 A. M. until 7:00 P. M.	Walnut Cove	Open 6:30 A. M. until 2:30 A. M.
Koehler	Open 8:00 A. M. until 7:00 P. M.	Walkertown	Open 6:00 A. M. until 2:00 A. M.
Martinsville	Open 7:00 A. M. until 3:00 A. M.	Winston-Salem	Open 4:00 A. M. until 12:00 Midnight.

No. 52 will note time of No. 23 at Roanoke.

ROANOKE YARD.

Time Table No. 18—Effective Sunday, May 15th, 1910.

Westbound.

RADFORD DIVISION.

Eastbound.

Fourth Class.	Second Class.		First Class.								STATIONS.	First Class.								Third Class.		Fourth Class.
	91 Local Frt. Lv. Daily Ex. Sunday A. M.	85 Thro. West. Frt. Lv. Daily P. M.	83 Thro. So. Frt. Lv. Daily P. M.	17 Passenger Lv. Daily P. M.	13 Passenger Lv. Daily P. M.	3 Passenger Lv. Daily P. M.	25 Passenger Lv. Daily A. M.	1 Passenger Lv. Daily A. M.	41 Passenger Lv. Daily A. M.	15 Passenger Lv. Daily A. M.		29 Passenger Lv. Daily A. M.	42 Passenger Ar. Daily P. M.	16 Passenger Ar. Daily A. M.	18 Passenger Ar. Daily A. M.	14 Passenger Ar. Daily A. M.	4 Passenger Ar. Daily A. M.	26 Passenger Ar. Daily P. M.	2 Passenger Ar. Daily P. M.	30 Passenger Ar. Daily P. M.	86 Stock Frt. Ar. Daily A. M.	
6.30	{ 3.50 5.05	{ 11.00 A 12.10	4.40	{ 4.15 4.35	{ 4.20 4.30	{ 10.50 11.00	{ 8.50 9.10	{ 5.00 5.15	{ 3.55 4.20	4.05	ROANOKE 2.0	{ 12.05 11.55	{ 12.30 12.18	11.30	{ 12.10 11.40	{ 12.01 11.50	{ 5.48 5.40	{ 7.10 6.55	10.45			
			4.48	4.42	4.36	11.06	9.17	5.21	4.27	4.11	W.ROANOKE	11.48	12.10	11.20	11.30	11.41	5.34	6.44	10.35	{ 6.30 3.45	{ 7.45 5.30	11.50

Westbound.

NORFOLK DIVISION.

Eastbound.

Fourth Class.	Second Class.			First Class.						STATIONS.	First Class.						Fourth Class.
	75 Local Freight Ar. Daily Ex. Sunday P. M.	85 Time Freight Ar. Daily P. M.	83 Time Freight Ar. Daily A. M.	87 Thro. Freight Ar. Daily Ex. Monday A. M.	5 Passenger Ar. Daily P. M.	3 Passenger Ar. Daily P. M.	25 Passenger Ar. Daily A. M.	1 Passenger Ar. Daily A. M.	41 Passenger Ar. Daily A. M.		15 Passenger Ar. Daily A. M.	42 Passenger Lv. Daily A. M.	16 Passenger Lv. Daily A. M.	6 Passenger Lv. Daily A. M.	4 Passenger Lv. Daily P. M.	26 Passenger Lv. Daily P. M.	
12.01	3.40	10.40	2.15	9.30	{ 4.20 4.30	{ 10.50 11.00	{ 8.50 9.10	{ 5.00 5.15	{ 3.55 4.20	ROANOKE 2.0	{ 12.05 11.55 PM	{ 12.30 12.18	6.40	{ 12.01 11.50 AM	{ 5.48 5.40	{ 7.10 6.55	7.10
12.15	{ 3.50 5.05	{ 11.00 12.10 PM	2.30		4.36	11.06	9.17	5.21	4.27	West Roanoke	11.48	12.10		11.41	5.34	6.44	7.00

Southbound.

SHENANDOAH DIVISION.—Between Shenandoah and Roanoke.

Northbound.

Fourth Class.	Second Class.		First Class.		STATIONS.	First Class.		Second Class.	Third Class.		Fourth Class.	
	61 Local Freight Ar. Daily Ex. Sunday P. M.		83 Time Freight Ar. Daily A. M.			13 Passenger Ar. Daily P. M.	1 Passenger Ar. Daily A. M.		14 Passenger Lv. Daily P. M.	2 Passenger Lv. Daily P. M.		88 Stock Freight Lv. Daily A. M.
2.45			10.05		ROANOKE 2.0	{ 12.10 11.40 AM	{ 7.20 6.55		2.50	10.35	6.00	5.40
3.00			10.10 ⁶⁴		WEST ROANOKE	11.30	6.42		2.30	10.10 ⁸⁸	5.45	5.30

Southbound.

SHENANDOAH DIVISION.—Between Roanoke and Winston-Salem.

Northbound.

Fourth Class.	Third Class.				First Class.		STATIONS.	First Class.		Third Class.	Fourth Class.	
	51 Local Freight Lv. Daily Ex. Sunday A. M.	87 Through Frt. Lv. Daily P. M.	85 Through Frt. Lv. Daily P. M.	83 Time Freight Lv. Daily A. M.	81 Through Frt. Lv. Daily Ex. Sunday A. M.	23 Passenger Lv. Daily Ex. Sunday P. M.		21 Passenger Lv. Daily A. M.	24 Passenger Ar. Daily Ex. Sunday A. M.		22 Passenger Ar. Daily P. M.	84 Through Frt. Ar. Daily A. M.
5.50	9.12	2.40	10.05	4.18		5.07	9.22	BELT LINE JUNCTION 2.2	11.39	6.53	1.45	4.80
5.40	9.00	2.30	9.55	4.10		5.00	9.15	ROANOKE 2.0	11.45	7.00	1.55	4.40
5.30	8.45	2.15	9.40	4.00				WEST ROANOKE			2.10	4.55

SHENANDOAH DIVISION.

SPECIAL INSTRUCTIONS.

STANDARD TIME.

1. Clocks showing standard time will be found in:
Superintendent's Office, Roanoke.
Telegraph Office, Passenger Station, Roanoke.
Yardmaster's Office, West Roanoke.
Yardmaster's Office, Shenandoah.
Round House, Shenandoah.
Telegraph Office in Passenger Station, Hagerstown.
Yardmaster's Office, Hagerstown.
Telegraph Office, Winston-Salem.
Telegraph Office, Loch Laird.
(See Rules 3 and 3-a)

REGISTERING.

2. Conductors only will examine registers.
All first class trains and passenger extras will register at passenger station, Hagerstown, Shenandoah and Roanoke and telegraph office at Winston-Salem.
All freight trains will register at the tower, Hagerstown Junction, Yard Office, Shenandoah, Dispatcher's Office, Roanoke and telegraph office at Winston-Salem.
Nos. 27 and 28 will register at Elkton.
Nos. 95 and 98 will register at telegraph office at Basic.
All northbound second, third and fourth class trains and extras will examine register at Elkton.
ALL TRAINS except northbound first class trains will examine register at Glasgow. When practicable, Dispatchers will transmit to Nos. 1 and 13 and southbound passenger extras, the register of northbound first class trains and passenger extras arriving at Glasgow. In the absence of this advice, conductors of Nos. 1 and 13 and southbound passenger extras will personally examine this register.
All northbound third and fourth class trains and freight extras will examine register at Basic, unless register of Nos. 95 and 98 has been transmitted by Dispatcher.
All southbound second, third and fourth class trains and extras will examine register at Loch Laird.
Conductors of trains Nos. 1, 2, 13 and 14 and passenger extras will throw off register of their trains to Operators at Glasgow and Loch Laird who will register for them.
Conductors of northbound freight trains will throw off register of their trains to Operators at Loch Laird who will register for them.
Northbound C. & O. trains will register and examine register at Glasgow. Southbound C. & O. trains will register and examine register at Loch Laird. Northbound C. & O. trains will throw off register at Loch Laird and southbound C. & O. trains will throw off register at Glasgow and Operators will register for them.
When practicable, Dispatchers will transmit to Nos. 1 and 13 registers of northbound first class trains arriving at Loch Laird.
In transmitting the register of trains by wire, the same must be repeated back and recorded in train order book.

BULLETIN BOARDS.

3. Bulletin Boards are at the following points:
Hagerstown:
Engine House.
Yardmaster's Office.
Telegraph Office, Passenger Station.

Shenandoah:

Engine House.
Yardmaster's Office.
Roanoke:
Dispatcher's Office.
Engine House.
Passenger Station.
Yardmaster's Office, West Roanoke.
Winston-Salem:
Telegraph Office.
Office of Foreman.
Loch Laird:
Telegraph Office.

MAXIMUM SPEED.

4. Between Roanoke and Winston-Salem, first class trains 35 miles per hour, or 1 minute and 43 seconds per mile. Third and fourth-class trains, freight and work extras, 20 miles per hour, or 3 minutes per mile.
Between Roanoke and Hagerstown second class trains, 35 miles per hour, or 1 minute and 43 seconds per mile. Third and fourth class trains, freight and work extras, 30 miles per hour or 2 minutes per mile.
Freight trains must reduce speed crossing high trestles on Winston District to 10 miles per hour, and passenger trains to 20 miles per hour.
Engines backing on the Winston District, must not exceed a speed of 15 miles per hour.
This rule does not apply to a two engine train when the leading engine is headed and the second engine backing.
When consolidation engines are used to haul passenger trains or used as helpers therein, the maximum speed thereof must be disregarded, and a speed of 25 miles per hour must not be exceeded.
Passenger trains using the junction track at Shenandoah Junction must not exceed 10 miles per hour in either direction.
Northbound freight trains will not exceed speed of 20 miles per hour between Stanley and Luray.
Northbound freight trains will not exceed speed of 10 miles per hour between Compton and Overall and between Mondel and Grimes.
Southbound freight trains will not exceed 20 miles per hour between Graves and south end of James River Bridge.
Northbound freight trains will reduce speed to 10 miles per hour through dip north of Bridge 490, north of Harrison, to summit north of Mile Post 131.
Southbound freight trains will not exceed speed of 15 miles per hour between Island Ford station and summit one-half mile south of station and must not increase speed until entire train has passed over this summit.
Speed of 15 miles per hour over the Southern Railway crossing at Riverton must not be exceeded.
Speed of 10 miles per hour on Crimora and Hatch Branches must not be exceeded.

STATIONS FOR WHICH NO TIME IS SHOWN.

5. Trains 1 and 2 will stop at Arcadia on signal.
Trains 13 and 14 will stop at Grove Hill, Yancey, Dooms and Arcadia on signal.
Trains 27 and 28 will stop at Spielman, Mondel, Wheatland, Gaylord, Briggs, Success, Cedarville, Vannatta, Limeton, Overall, Compton, Long and Grove Hill on signal.
Trains 21 and 22 will stop at Wright, Taylor, Blaine, Saunders, Prilliman, Edgewood, Phospho Lithia, Avalon, Fulp and Daisy on signal, and on Sundays 21 and 22 will make all flag stops on signal.
Avalon will be regular stop for trains 23 and 24.
Trains 23 and 24 will stop at Wright, Taylor, Blaine, Saunders, Prilliman, Edgewood, Phospho Lithia, Sharp, Fulp and Daisy on signal.

GENERAL.

6. Passenger trains will be moved only under absolute block with reference to preceding and following trains, except that where block system is not in effect, passenger trains may be moved under permissive block with reference to other than passenger trains preceding, in case there is an intervening siding at which there is no telegraph office.
7. Circus trains will be moved only under absolute block.
8. Should wires fail where block system is in use, operators must stop all trains and notify them of the fact and issue clearance cards stating that block is permissive and trains will proceed under their time table rights as if they received permissive block cards. (See Rule 707.)
9. Whenever the passenger service is disarranged, the public shall be informed of the probable length of time of the interruption, and, when ascertained, the time the service will be restored. Advices from the Superintendent received by Station Masters and Station Agents must be posted in a conspicuous place at the station. Announcement must also be made in waiting rooms and on platforms, and to passengers when purchasing tickets. Conductors of delayed trains must also inform passengers.
10. Yardmasters are authorized to start all regular freight trains and direct signals to be displayed for following sections, using the prescribed form.
11. Fourth class trains may proceed ahead of third-class trains, and freight extras may proceed ahead of third and fourth class trains. When overtaken at stations, local freights, will permit through freights to pass promptly.
12. Rule No. 88, Book of Rules, is modified to the extent that extra trains will have the right to stand within station limits, yard limits, coaling and water stations without protecting against third and fourth class trains, and fourth class trains will have the right to stand at such named points without protecting against third class trains.
As an additional safe guard during foggy weather, at all points between station limits, coaling stations and water tank limits, wherein the rear of a train can not be plainly seen, flagging will be necessary.
These instructions in no way relieve train and enginemen from observing all rules in connection with approaching and running through stations, water tank and coaling station limits under full control.
13. Rule No. 11, Book of Rules, is modified as follows: When a fusee is found on or near the track burning, a train will at once come to a full stop, place two torpedoes on the rail ten yards apart, wait one minute, and proceed to the next automatic or telegraphic block signal under full control, expecting to find track obstructed.
14. Within the limits of automatic block territory only, Rules 89-a, 89-b and 91 are hereby withdrawn and trains will be governed by Rule 89.
15. Cross-over switches at all double sidings must be left adjusted for trains to pull through from east to westbound siding, or from west to eastbound siding.
16. The air whistle signal must not be used to start trains unless a signal is given by hand and lamp also.
17. Engineers of passenger trains are authorized to allow section foremen in the performance of their duties on their respective subdivisions, to ride on the engine.
18. Foremen must not allow any person to ride on their push or lever cars, except those employed by them without an order from the proper officer, or in case of accident.
19. When a 31 order is delivered by an operator, the party to whom delivered will read his copy aloud to the operator.
20. Should wire fail before a train is ready to leave a terminal station, if no orders, or no further orders therefor, operator may issue a clearance card.
21. Where telegraph offices are located at sidings, or distant from stations of the same name, the time shown on time table is at telegraph office. Notwithstanding which, passenger trains scheduled or advertised to stop at such places must not leave the point at which passengers are received or discharged before the time shown.

22. Signals, where switch tenders are stationed, indicate the position of switches only, and do not confer any rights over trains.

23. All men in train service will submit their watches once each week to the Local Watch Inspector or other designated party for comparison with the standard time and secure Weekly Comparison Card (Form 30), which should be promptly turned over to the proper officer.

24. Before headlights of engines are covered, as required by Rule No. 17, information that rear of train is clear of main track must be communicated to engineer by word of mouth from the rear.

25. Indication of "C" boards shown in Rule 16 (a) is modified to read as follows: Abrupt curves over which speed must be reduced to 25 miles per hour for passenger trains and 15 miles per hour for freight trains.

26. The following signs when placed in columns provided in the time table, will have the following indication:

Letters under "Telegraph Signals," indicate the Telegraph Calls for Stations. Letters under "Telegraph Offices," indicate:

- "D" Day Telegraph Station.
- "N" Night Telegraph Station.
- "DN" Day and Night Telegraph Station.
- Letters placed after the names of the Stations, indicate:
- "W" Water Station.
- "X" Railroad Crossing.
- "O" Track Scale.
- "C" Coaling Station.
- "T" Turn table.
- "Y" Wyes.

27. Employees are prohibited from riding on pilots of engines in road service, and they must not under any circumstances, ride on yard engine foot boards between engine and cars.

AIR-BRAKES.

28. Engineers, Trainmen, and Yardmen must familiarize themselves with the operation of the air brake.

29. Engineers must know by a personal examination that the air brake equipment on their engine is in good order.

30. Conductors must know that the air brake on their train is in good order; or if disabled and cut out on the road, report the fact.

FREIGHT TRAINS.

31. When all cars in a freight train are not equipped with air brakes, those which are so equipped and in working order must be switched together and placed next to engine, unless otherwise directed by the Superintendent or other officer authorized to give such instructions.

32. When there are sufficient air cars (which must not be less than 75 per cent.), the engineer will control the speed of the train by the use of air-brakes, but trainmen must be at their post ready to assist in stopping train, if signalled to apply hand-brakes; and also to keep look-out for signals, derailments, etc. Before reaching the summit of long grades, the brakes must be tested and known to be in working-order, as provided in air-brake Rule No. 8. All retaining valves must be turned up and kept turned up until the foot of the grade is reached. The double-pressure retaining valve must be used in the 30-pound position. When a train is stopped, for any cause, on a grade, hand-brakes must be applied immediately, as provided in air-brake Rule No. 35.

33. In case of emergency, should engineer signal for assistance of hand brakes the trainman nearest thereto should open the rear angle cock or emergency valve on cab, and then apply hand-brakes.

34. Engineers and trainmen must consider a train composed partly of air and partly non-air cars as broken in two when approaching a stop, and trainmen must apply brakes on non-air cars beginning at the rear car, to prevent a sectional collision should train have parted.

35. When air brakes are used to stop approaching a water tank brakes must not be released after first applied until engine returns from tank and is recoupled to train.

Before cutting the engine off, in all cases the brakeman must turn the angle cock so as to hold the air in train.

INTERLOCKING.

ENGINEERS AND TRAINMEN.

36. At points where telephones are located, engineers will bring their trains to a full stop if "stop" signal is displayed, and communicate with the Operator or Leverman at telegraph office for instructions. They should not pass any derailing switch under stop signal, unless they personally assure themselves that switch has been properly spiked up. If they receive a hand signal as provided in Rule 803, they may accept this signal and proceed over switches.

LOCAL.

100. Definition of Named Limits:—

Station Limits: Between switches of passing tracks, clear of fouling points.

Water Tanks and Coaling Stations: Only one train protected by rule.

Yard Limits: Between yard limit signs.

101. All passenger trains will get a "31" order, or a clearance card at Passenger Station, Hagerstown, Shenandoah and Roanoke; all freight trains will get a "31" order or a clearance card at the Tower, Hagerstown Junction, at the Yard Office, Shenandoah and at Superintendent's Office, Roanoke, and ALL trains will get a "31" order or a clearance card at the Telegraph Office, Winston-Salem.

No. 28 will get a "31" order or a clearance card at Elkton.

No. 98 will get a "31" order or a clearance card at Basic.

ALL southbound trains will get a "31" order or a clearance card at Loch Laird.

ALL trains will get a "31" order or a clearance card at Glasgow.

102. Rules governing operation of Block Signals 700 to 732, inclusive, are effective between Loch Laird and Glasgow.

103. Trains must NOT foul the main line connection switches at Glasgow or Loch Laird until it has been ascertained that all overdue superior trains have been represented.

104. Conductors and Engineers of all trains using track in C. V. Yard at Hagerstown, between Hagerstown Junction and North Crossing must have copy of Hagerstown Yard Time-Table in their possession and conform thereto.

105. C. & O. trains while upon the tracks of the N. & W. Railway will be regarded in every respect as N. & W. trains.

106. All passenger trains using the main junction track at Shenandoah Junction will leave main track switch set for the junction while in the junction.

All trains using main track while passenger trains are in the junction will do so expecting to find main junction switch set for the junction.

107. Southbound freight trains taking water at Rocky Mount Tank must pull their entire train through the cut north of this tank, stopping rear just south of road crossing at south end of cut.

108. All trains using passing sidings at Buena Vista, Basic, Elkton, Front Royal, Shenandoah Jct., Philpott and Price must do so expecting to find cars thereon.

109. Crews of the N. & W. Ry. will not invade the transfer tracks at Basic until having first ascertained whether or not a crew of the C. & O. Ry. is at work thereon, and if so, a definite understanding has been had between the respective Conductors as to what tracks each will use so that there can be no possible misunderstanding resulting in an accident.

110. In future, when a train going to Campbell Street (Roanoke Yard) to be met by two or more trains, either by rule or train order, and having more cars in train than will clear the siding, making it necessary to saw the first train out, will protect itself against the second train unless it has arrived and arrangements made between the crews of respective trains whereby the movement will be protected.

111. Special instruction No. 20 in current time table is hereby modified to the extent that passenger trains must not leave passenger stations at Shenandoah Junction and Winston-Salem until advertised departing time.

112. Derailing switches in passing sidings at St. James, Fort Republic, Hester, Waidsboro, Philpott, Price and Tice, will be kept closed when no cars are left on those sidings.

113. Movements on double track in yards must not be made against the traffic unless absolutely necessary, for a short distance, and then only under protection of a flag.

114. When a train is on a siding to be passed by another train, or waiting for block, operators will issue clearance cards to such train when the block is "clear" or "permissive," keeping the signal at normal position, to prevent another train, which might be approaching, from accepting the signal.

115. Form H, Rules for movement by train orders, Book of Rules, is modified to the extent that work trains, when working on double track, will protect against the current of traffic only, unless otherwise directed.

116. Rule No. 90 (b), Book of Rules, first paragraph; also paragraph (n) of Rule 14 and paragraph (i) of Rule 16, are modified as follows:

Conductors of passenger trains must give two long and one short blasts of the air whistle signal at meeting points made by rule with trains of same or superior class, and at all points at which they have telegraphic orders to meet trains of any class, or to get a 31 order; also at points where they hold "Wait" or "Right-over" orders. This signal must be given one mile distant from such points and must be acknowledged by the engineer giving the same signal with the engine steam whistle.

117. Speed regulations must be observed through incorporated towns as follows:

Berryville.....	8 miles per hour
Hagerstown.....	4 miles per hour
Shepherdstown.....	8 miles per hour
Luray.....	8 miles per hour
Shenandoah.....	12 miles per hour
Basic.....	8 miles per hour
Buena Vista.....	12 miles per hour
for passenger trains.	
Buena Vista.....	15 miles per hour
for freight trains.	
Buchanan.....	6 miles per hour
Stoneville.....	15 miles per hour
Winston-Salem.....	6 miles per hour

RAILWAY CROSSINGS AND JUNCTION POINTS.

118. Rule No. 98 will govern the movement of trains at the following named points:

Cumberland Valley Railroad Connection, Hagerstown Junction.
Western Maryland Railroad Connection, Hagerstown Junction.
Baltimore and Ohio Railroad Crossing, Charlestown.
Southern Railway Crossing, Riverton.
Chesapeake-Western Railway Connection, Elkton.
Virginian Railway Crossing, Roanoke.
Southern Railway Crossing, Rocky Mount.
Southern Railway Crossing, Walnut Cove.

TONNAGE RATING FOR LOCOMOTIVES.

	Class F. or I.	Class G.	Class High Pressure G. or T.	Class W. or M.
NORTHBOUND				
Roanoke to Shenandoah				
Slow Freight	500 tons.	530 tons.	600 tons.	775 tons.
Time Freight	425 tons.	475 tons.	550 tons.	725 tons.
SOUTHBOUND				
Roanoke to Winston-Salem	500 tons.	550 tons.	600 tons.	750 tons.

NORTHBOUND

Shenandoah to Hagerstown				
Slow Freight	675 tons.	700 tons.	800 tons.	1000 tons.
Time Freight	600 tons.	625 tons.	700 tons.	900 tons.

SOUTHBOUND

Hagerstown to Roanoke				
Slow Freight	500 tons.	530 tons.	600 tons.	750 tons.
Time Freight	425 tons.	475 tons.	525 tons.	675 tons.

NORTHBOUND

Winston-Salem to Roanoke				
Local Freight	500 tons.	550 tons.	600 tons.	750 tons.
over entire division in both directions	400 tons.	430 tons.	500 tons.	650 tons.

Engines with full rating will be assisted by a helper engine, Shenandoah to Mile Post 98. When helper is not provided two hundred tons will be deducted for each engine.

ROANOKE YARD.

200. Trains or engines must not pass over Jefferson Street or Commerce Street unless gates are down, nor Tazewell Avenue between seven A. M. and seven P. M. unless the gates are down.

201. The dropping of cars by gravity on main tracks or lead in Park Street Yard is prohibited.

202. Before trains depart from Park Street and West End yards Conductors in charge thereof must see that a sufficient number of brakes are set on cars in rear of their trains to prevent them from dropping out by gravity.

203. Conductors of trains entering Roanoke Yard must see that sufficient brakes are applied (commencing at caboose) before engine is detached to prevent train from dropping back.

204. The speed of passenger trains through Roanoke Yard must not exceed twenty (20) miles per hour when passing over facing point switches.

205. All trains leaving Roanoke Yard, in either direction at night before cabin car has been attached to train, must be protected by a man with a red lantern light on rear car.

206. Rule 98 will govern the movement of trains at the following points:

The railroad crossing of the Virginian Railway Company at Walnut Street, Roanoke Yard, and at Belt Line near Roanoke River Bridge.

207. Hereafter, when northbound Shenandoah Division trains take siding in the North Yard, a flagman should be sent ahead to protect against the southbound movement. This is made necessary by reason of the fact that southbound trains use this siding, and on account of the descending grade, would gain considerable speed quickly after releasing brakes to enter the siding.

COMPANY SURGEONS.

- Dr. Joseph A. Gale.....Chief Surgeon.....Roanoke, Va.
- Dr. J. N. Lewis.....Surgeon.....Roanoke, Va.
- Dr. S. S. Gale.....Surgeon.....Roanoke, Va.
- Dr. A. J. Black.....Surgeon.....Roanoke, Va.
- Dr. T. D. Armistead.....Assistant Surgeon...Roanoke, Va.
- Dr. W. S. Slicer.....Assistant Surgeon...Roanoke, Va.
- Dr. J. R. Garrett.....Oculist.....Roanoke, Va.
- Dr. E. M. Herbert.....Assistant Oculist...Roanoke, Va.
- Dr. E. A. Jenkins.....Surgeon.....Natural Bridge, Va.
- Dr. J. H. Mapp.....Surgeon.....Buena Vista, Va.
- Dr. W. B. Dodge.....Assistant Surgeon...Stuarts Draft, Va.
- Dr. R. S. Griffith.....Surgeon.....Basic, Va.
- Dr. J. M. Ropp.....Surgeon.....Shenandoah, Va..
- Dr. W. L. Hudson.....Surgeon.....Luray, Va.
- Dr. T. B. Amiss.....Assistant Surgeon...Luray, Va.
- Dr. D. M. Kipps.....Surgeon.....Front Royal, Va.
- Dr. A. B. Tucker.....Surgeon.....Berryville, Va.
- Dr. Richard E. Venning.....Surgeon.....Charlestown, W. Va.
- Dr. O. H. W. Ragan.....Surgeon.....Hagerstown, Md.
- Dr. E. A. Wareham.....Assistant Surgeon...Hagerstown, Md.
- Dr. W. B. Morrison.....Assistant Surgeon...Hagerstown, Md.
- Dr. J. M. Williams.....Surgeon.....Rocky Mount, Va.
- Dr. W. T. Chitwood.....Assistant Surgeon...Rocky Mount, Va.
- Dr. C. H. Ross.....Surgeon.....Bassett, Va.
- Dr. J. W. Simmons.....Surgeon.....Martinsville, Va.
- Dr. J. M. Shackelford.....Assistant Surgeon...Martinsville, Va.
- Dr. Drewry H. Mason.....Surgeon.....Ridgeway, Va.
- Dr. A. G. Jones.....Surgeon.....Walnut Cove, N. C.
- Dr. Chas. L. Summers.....Surgeon.....Winston-Salem, N. C.
- Dr. D. N. Dalton.....Assistant Surgeon...Winston-Salem, N. C.

FIRST AID TO INJURED.

A. In accidents to persons the ranking employe of the road present will take command, and direct proceedings for the relief of the injured.

B. When there is danger from fire, remove all persons promptly from the train, looking first to those who may be helpless from injury or jammed in the wreck.

C. Take hold of the injured gently, but firmly, and without fear. Lay the injured one down on cushions, blankets, clothing, or straw where he will have perfect ventilation and not be in a draught or strong current of air. Loosen the clothes about the neck and body to permit easy breathing, and place the injured part in the position most comfortable to the sufferer. Do not permit strangers to approach and talk to or ask the injured one questions. Place him if possible, in charge of one or two friends, and keep him warm with proper covering.

D. As soon as practicable summon the nearest Surgeon of the Company, and notify the Superintendent by telegraph. State the number of persons injured and the nature and extent of the injuries

as clearly as time will allow, in order that the Surgeon may come with what is needed.

E. BLEEDING.—If the bleeding is from the limbs, keep them bent and the bleeding points elevated as much as practicable.

F. In case of broken bones, place the injured part in the most natural position, or, if this can not be done, then in the position most comfortable to the patient. Having done this, seek to steady the limb, either by splints of wood or by a pillow folded around the limb and tied in the desired position. In case of broken ribs, relief will be afforded by a wide bandage around the chest drawn as tightly as can be borne. When a broken bone is suspected, do not move the limb about to find out if this is so.

G. In case of burns or scalds, cover the parts with a paste made of baking soda and water.

H. When there is much weakness from an injury, whiskey may be given in small quantities, say from one to two tablespoonfuls, to be repeated at short intervals, if necessary. Large quantities must not be given, and no whiskey must be given if the head is injured. In all cases of weakness from shock or loss of blood, keep the patient warm.

I. Cold water, ice, tea, coffee, milk, or soup may be freely allowed to all injured ones who wish them.

J. In moving an injured person, place a board, door, shutter, or mattress, with one end at the patient's head, and lift or slide him gently on it. If the patient can sit up, he may be carried in a chair or upon the locked hands of two persons, around whose necks he throws his arms to steady himself.

K. When forwarding a patient who has been seen by a Surgeon obtain from the Surgeon a written statement as to his opinion of the nature and extent of the injuries, and attach this statement along with the name of the injured one (if it can be obtained) securely to his clothing.

L. When the injured person is able to be moved, take or send him to the nearest Surgeon of the Company in the direction in which the first train is moving. It can then be decided whether the patient will be treated there or taken to some other point.

M. When the injured person is not able to be moved, place him in charge of the Station Agent, Section Master, or some official of the road, and summon the Surgeon of the Company most easily obtained.

N. In urgent cases, if no Surgeon of the Company can be promptly had, summon the nearest Physician to take charge of the case until the Company's Surgeon arrives.

O. In a general emergency, summon the Surgeons of the Company in both directions and wire the Superintendent if more Surgeons are needed.

D. E. SPANGLER,
Superintendent Transportation,
ROANOKE, VA.

A. C. NEEDLES,
General Superintendent, Eastern General Division,
ROANOKE, VA.

E. A. BLAKE,
Superintendent,
ROANOKE, VA.

BOYCE RAILWAY DEPOT FOUNDATION



The Boyce Railway Depot Foundation (BRDF) was chartered on January 20th, 2017. It is organized as a non-profit Virginia corporation for preservation of the historic Norfolk & Western Railway's 1913 train station building and pump house at Boyce, Virginia. The BRDF has received Internal Revenue Code 501(C)(3) non-profit status.

The chief focus during 2021 is developing a strong, capable membership base. Those who welcome leadership roles can be nominated by members to the Board of Directors. Officer positions will be filled from the Directors. Elections to the Board of Directors will be made during the fourth membership meeting during November 2021|

Annual membership dues are \$10, payable to the **BOYCE RAILWAY DEPOT FOUNDATION**. A life membership is available for \$250. Members and volunteers will initially support grounds-keeping and exterior building maintenance. The longer term vision is for the BRDF to lease the building and grounds, then arrange space rentals for special events and meetings as income sources for preservation efforts.

Come join us! Please write to:

BOYCE RAILWAY DEPOT FOUNDATION
brdf@railwaymailservicelibrary.org
117 EAST MAIN STREET
BOYCE VA 22620-9639

A HISTORICAL OVERVIEW OF BOYCE RAILWAY STATION

The Town of Boyce and its railway depot have enjoyed a long history together. Nearly as old as the town, the 1913 structure has served as its public gathering place, the portal through which travel and commerce passed, as well as becoming Boyce's icon.

Indeed, it was the crossing of a newly-built Shenandoah Valley Railroad with the Winchester and Berry's Ferry Turnpike that prompted the birth of a new community in formerly dense, forested land. Unlike Berryville, White Post, and Millwood, the Boyce community –briefly named Boyceville—sprung forth around a stop along the tracks relatively late in Clarke County's development. The town would not have existed were it not for the arrival of the Shenandoah Valley Railroad in 1879.

The current depot, constructed by John P. Pettyjohn & Co. of Lynchburg, Virginia, replaced an 1880s wooden station adjacent to the turnpike, now named East Main Street and county route 723. The Norfolk & Western Railway (N&W), which acquired the Shenandoah Valley Railroad in 1890, undertook improvements during the early 1900s, including depot replacement. In 1912, it announced plans to construct a new station on the west side of the track, within the boundaries of the newly-incorporated town. The station was planned to be a modest building similar to those in other villages of less than 1,000 residents, at a projected cost of \$7,500. It would have been of wood construction with stoves for heating, oil lamps, and outside facilities.

Mr. Peter H. Mayo negotiated with the N&W to build a "first class" station instead of a smaller structure. Principal enhancements included masonry construction, clerestory windows for better air circulation during summer months, a fashionable stucco design, with electric lighting, central heating, and inside restrooms. It was spacious, modern, and comfortable –rivaling the best contemporary railway stations in small cities.

These improvements were added at substantial cost. Mr. Mayo, along with Ms. Hattie Gilpin and Mr. R. Powell Page, contributed \$17,500, bringing the station's value to \$25,000 –a sizeable sum in 1913!

The station not only served passengers traveling locally or beyond Hagerstown and Roanoke. It was the Western Union telegraph office, Railway Express Agency, handled carload and less-than-carload freight, livestock loading, exchanged U.S. Mail from Railway Post Office routes, and supported N&W Railway operations.

During its 45 years of operation, four agents were assigned to the station: Morton J. Dunlap, Theodore M Sheetz, Sylvester M. Lane, and Lee C. Murray. Mr. Dunlap was also a Boyce Town Council member.

Boyce depot was sold to a private owner during 1959. The larger of the two waiting rooms was rented to the Post Office Department as the town's Post Office. Thus, it continued as a community hub until the Post Office moved to its present location on West Main Street in 1984. Benjamin Harrison, Russell B. Lloyd, and Eva P. Kibler were Postmasters during the 29 years that the Post Office was at the station. Several clerks and Rural Free Delivery carriers also worked there.

The N&W agency, Railway Express, and Western Union services closed on or before December 31st, 1958. The building was sold again and passed through several owners between then and 2003. It had multiple uses, such as farm supply storage, a FISH charity, restaurant, and a woodworking shop. It is now looking toward to future preservation and community uses under the stewardship of the Boyce Railway Depot Foundation!



BOYCE RAILWAY DEPOT FOUNDATION

N&W RAILWAY AND TOWN HISTORY - BUILDING PRESERVATION

<https://boycedepot.com/>

(571) 379-3409 - *TEXT MESSAGE*

(540) 837-9090 - *TELEPHONE*

brdf@railwaymailservicelibrary.org - *e-MAIL*

117 EAST MAIN STREET

BOYCE VA 22620-9639

MEMBERSHIP APPLICATION

Your membership in the Boyce Railway Depot Foundation will support preservation and community use of the historic 1913 Norfolk & Western Railway station. Annual dues are \$10 and a life membership is \$250. Please provide the information below for the membership roster:

First, Middle Initial, Last Name:

Mailing Address:

City, State, Postal Code, Country:

Telephone Number:

eMail Address:

Donations are also invited. The Boyce Railway Depot Foundation is a 501(c)(3) public charity and donations or contributions are tax deductible as provided for and to the extent provided by law. Please check this box if your employer will match your donation: If the employer requires an invoice, please provide contact information.

Thank you very much for your interest. If you have questions, please call or write.

Sincerely yours,

Frank R. Scheer
Secretary-Treasurer